

# GENERAL INSTALLATION, OPERATION AND MAINTENANCE INSTRUCTIONS FOR OVENS

## TABLE OF CONTENTS

1	SHIPPING DAMAGE & HANDLING
2	PROPER OVEN APPLICATION
	2-1 General
	2-2 Flammable Solvents
	2-3 Combustible Material
	2-4 Personnel Hazards
	2-5 Maintenance and Inspection
3	INSTALLATION
	3-1 Location
	3-2 Building Considerations
	3-3 Clearances
	3-4 Ventilation
	3-5 Exhaust Ductwork
	3-6 Fuel Gas Supply
	3-7 Electrical
4	PRIOR TO PLACING OVEN IN SERVICE
5	PROCESSING
6	SAFETY EQUIPMENT
7	MAINTENANCE
8	TROUBLE SHOOTING
9	APPENDIX A - SAFETY EQUIPMENT, DESCRIPTION & OPERATION
10	APPENDIX B - REFERENCES
11	APPENDIX C - MINIMUM PERIODIC MAINTENANCE REPORT
12	APPENDIX D - SAFETY SHUT OFF VALVE LEAK TEST PROCEDURE
13	APPENDIX E - WARRANTY AND LIMITATIONS OF REMEDIES

Following these **GENERAL INSTRUCTIONS** in your manual are the following:

- OPERATING INSTRUCTIONS SPECIFIC FOR YOUR EQUIPMENT
- MECHANICAL PARTS LIST
- ELECTRICAL WIRING AND COMPONENT PARTS LIST
- LITERATURE AND INSTRUCTIONS ON COMPONENTS

These **GENERAL INSTRUCTIONS** have been written for many different types of ovens, therefore, some equipment or components referred to may not be present on your particular piece of equipment.

After reading these **GENERAL INSTRUCTIONS**, also read the specific **OPERATING INSTRUCTIONS** written for your equipment. An additional copy of the **OPERATING INSTRUCTIONS** is provided in a plastic cover. Post these instructions at the oven for the operator to reference.

## **1 SHIPPING DAMAGE AND HANDLING**

### **DO NOT RETURN DAMAGED MERCHANDISE TO US. FILE YOUR CLAIM AS OUTLINED BELOW.**

This merchandise has been thoroughly inspected and carefully packed before leaving our plant. The carrier assumed responsibility for its safe delivery at the time of shipment. Claims for loss or damage to the contents must be made with the carrier, as follows:

#### **1-1 VISIBLE LOSS OR DAMAGE**

Any external evidence of loss or damage must be noted, at the time of delivery, on the freight bill or express receipt and signed by the carrier's agent. Failure to adequately describe such external evidence of loss or damage may result in the carrier refusing to honor a damage claim. Make a written request for inspection by the carrier's agent within fifteen days of the delivery date. Review the inspection report and do not sign it unless it adequately describes the damage.

A claim must be filed with the carrier since such damage is the carrier's responsibility.

#### **1-2 CONCEALED LOSS OR DAMAGE**

Concealed loss or damage means loss or damage, which does not become apparent until the merchandise has been unpacked. The contents may be damaged in transit due to rough handling even though the carton may not show external damage. When the damage is discovered upon unpacking, contact the carrier and make a written request for inspection by the carrier's agent within fifteen days of the delivery date. Review the inspection report and do not sign it unless it adequately describes the damage.

A claim must be filed with the carrier since such damage is the carrier's responsibility. By following these instructions carefully, we guarantee our full support of your claims to protect you against loss from concealed damage.

#### **1-3 RETURNING DAMAGED EQUIPMENT**

Damaged equipment will not be accepted at our factory unless we have been advised and instructions provided on how it should be returned. A copy of the freight claim must be provided prior to returning the equipment.

#### **1-4 HANDLING**

After inspection, store and handle all equipment and components in their original crates until ready for installation. Handle with care. The equipment may be heavy but some components are of a delicate nature. If the equipment is to be stored, keep it in the original crates and store in a location free from excessive dust, heat and moisture until ready for installation.

## 2 PROPER OVEN APPLICATION

### 2-1 GENERAL

**2-1.1** While ovens are extremely versatile, they are usually purchased with a specific application in mind. If your process has changed significantly or if you should have reason to doubt that a specific application is a proper use of the equipment, consult the factory before proceeding.

**2-1.2** Explanatory Material (Annex A1.1) of National Fire Protection Association Publication 86 "Standard for Ovens and Furnaces" states; in part:

"Explosions and fires in fuel-fired and electric heat utilization equipment constitute a loss potential in life, property and production."

"Most failures can be traced to human error. The most significant failures include inadequate training of operators, lack of proper maintenance, and improper application of equipment.

**2-1.3** To protect the oven, oven contents, property and personnel, a responsible person should be in attendance during operation. **Do not operate oven unattended.** Special attention must be paid to:

-Setting correct temperature.

-Placing flammable solvents in an oven not designed for that purpose.

-Placing combustibles in an oven that does not have adequate fire protection.

-Allowing the product to remain in the oven too long, thereby encouraging combustion.

-Using an oven for a process other than that for which it was designed.

**2-1.4** Oven operator should shut down the oven immediately and notify their supervisor if there are changes in oven performance, a safety interlock trips or, in the case of fuel fired equipment, the smell of natural gas or propane is present. The oven should not be put back into production until the causes are found and corrected.

### 2.2 FLAMMABLE SOLVENTS

**2-2.1** Processing solvents in a non-solvent oven, exceeding the design temperature, or exceeding the maximum amount of solvent allowed in an oven, could result in **fire or explosion** and bodily injury or property loss.

If flammable solvents or vapors will be present in an oven, the Occupational Safety & Health Administration (OSHA) requires that it have a separately powered forced exhauster of adequate size and other related safety devices not supplied as standard equipment. Ovens designed for this purpose have a caution plate and Safety Design Form showing the maximum gallons of solvent, or pounds of powder coating, and the maximum operating temperature for which that specific oven has been designed. If in doubt, consult factory for details.

**2-2.2** It shall be the user's responsibility to ensure that the amount of flammable solvent placed in the oven and the operating temperature does not exceed the design capacity -- see Safety Design Form and oven caution nameplate.

- 2-2.3** In areas outside of the oven where flammable solvents are given off by material prior to entering the oven, provisions shall be made to exhaust these vapors to atmosphere to prevent them from being pulled into the oven or collecting and creating a flammable mixture.

## **2-3 COMBUSTIBLE MATERIAL**

- 2-3.1** Introduction of combustible materials (such as paper, cardboard or wood) into the oven should be avoided because it might cause a fire. Do not use combustible racks, trays, holders, spacers, etc. Periodically, clean all combustible material from non-combustible racks, trays, holders, spacers, etc. If combustible products must be processed in an oven, extreme care must be taken to ensure that the operating temperature does not exceed the ignition temperature of the product.

- 2-3.2** Ovens containing or processing sufficient combustible materials (including consideration for combustible drippings or deposits) to sustain a fire shall be equipped with an automatic fire protection system including areas in exhaust ducts that could accumulate combustible material. Fire protection systems should be installed in accordance with the applicable National Fire Protection Guidelines:

- sprinkler systems in accordance with NFPA 13
- water spray systems in accordance with NFPA 15
- carbon dioxide extinguishing systems in accordance with NFPA 12
- foam extinguishing systems in accordance with NFPA 11
- dry chemical extinguishing systems in accordance with NFPA 17
- water mist systems in accordance with NFPA 750

The extent of protection required will depend upon the construction and arrangements of the oven as well as the materials handled. Fixed protection, such as automatic sprinklers or other types of fire extinguishing systems should be designed and installed by a qualified contractor.

- 2-3.2.1** Activation of fire protection system shall comply with NFPA 86 11.5 providing

- safety shut down of oven
- discontinue introduction of flammable or combustible material
- position dampers to maintain minimum air flow through oven to prevent combustible concentration from exceeding 25% of lower flammable limit (LFL)
- keep fans in operation to maintain required safety ventilation to prevent combustible concentration from exceeding 25% of lower explosive limit (LEL)
- shut down recirculation and exhaust fans and close dampers where type of fire protection requires that ventilation be discontinued.

- 2-3.3** Drip pans shall be provided to collect any combustible materials that may accumulate beneath the product. A maintenance program must be developed to remove any such accumulation before a substantial build up occurs that could spontaneously ignite and cause a fire. If you cannot acquire drip pans locally, contact us for a quotation.

## **2-4 PERSONNEL HAZARDS**

- 2-4.1** You must analyze your use of this equipment and determine if it creates a confined space hazard, as defined by OSHA, in your work place. You are responsible for posting appropriate warnings and complying with applicable OSHA STANDARDS pertaining to confined space hazards. Reference ANSI Z117-1 "Safety Requirements for Confined Spaces"; see Appendix B.
- 2-4.2** If inert atmospheres are to be used, keep in mind that inert gases displace air and create oxygen-deficient atmospheres. For this reason, they can cause suffocation. Moreover, some inert gases, such as argon, are heavier than air and can collect in low lying or sealed areas creating oxygen-deficient pockets within the work place. Use inert atmospheres only in large work places with good ventilation. Do not breathe in or enter an inert atmosphere piece of equipment until it has been thoroughly purged with air.
- 2-4-3** Explosion venting door latches will allow oven doors to open if pressure develops in the oven. For this reason doors should face away from main aisles and work areas.
- 2-4.4** Heat processing equipment must always be used with caution. Proper equipment such as insulated gloves, safety goggles and tongs should be used for reaching into hot equipment. Proper supervision is essential and only trained personnel should be allowed to operate the oven.

Always remember you are working with elevated temperatures.

-Do not touch surfaces - they could be hot and burns could result.

-Do not breathe hot oven air. Heated air could burn lungs.

-Many items become dangerous when heat is applied. Explosion or fire could result. Make sure you know what you are putting in the oven can be heated safely at the oven operating temperature.

- 2-4.5** Disconnect power before servicing equipment. Ovens operate under high voltage and electrical shock is possible. Proper panel lockout procedures should be followed.
- 2-4.6** Disconnect other sources of potential energy such as compressed air, before servicing. Proper lockout procedures should be followed.
- 2-4.7** Do not operate mechanical or electrical equipment with guards removed. Operating with guards removed could result in bodily injury.
- 2-4.8** Ovens with vertical lift doors or top-loading doors must be blocked open before passing beneath them. A falling door may cause bodily injury. A safety pin or support strut is provided for this purpose.

## **2-5 MAINTENANCE AND INSPECTION**

- 2-5.1** Regularly scheduled inspection and maintenance of all safety devices shall be performed by user. Failure to do this may result not only in fire or explosion damage, but also contribute to accidental shutdowns and loss of production. See Section 7 "Maintenance" and Appendix C "Minimum Periodic Maintenance Report".

**2-5.2** Regularly scheduled inspection of the oven interior, heat chamber and ductwork shall be performed by user to determine need for cleaning and repair. Failure to do this may result in internal fires or component failure resulting in oven damage and loss of production.

**2-5.3** It shall be the sole responsibility of the user to establish, schedule and enforce the frequency of and the extent of the inspection/maintenance program (as well as the corrective action to be taken) because only the user can know what the actual operating conditions are. Contact your insurance authority, Factory Mutual or the National Fire Protection Association, whose addresses are listed in Appendix B, for more information on inspection/maintenance programs.

**2-5.4** It shall be the responsibility of the end user to determine that current processing is within the scope of the original design of the equipment.

## **2-6 RETROACTIVITY**

This equipment has been designed and manufactured in accordance with applicable National Codes in effect as of the date of manufacture. It is the responsibility of the end user to update equipment as necessary to comply with future code changes. If you are in doubt, contact manufacturer to review your equipment design against current National Codes.

### **3 INSTALLATION**

#### **3-1 LOCATION**

- 3-1.1** Ovens shall be located to protect them from damage by external heat, vibration and mechanical hazards.
- 3-1.2** Ovens shall be located to make maximum use of natural ventilation, to minimize restrictions to adequate explosion relief, and to provide sufficient air supply for personnel. Room volume should be at least 10 times the oven volume.
- 3-1.3** Ovens shall be located to minimize exposure to power equipment, process equipment and sprinkler risers. Unrelated stock and combustible materials shall be maintained at a fire-safe distance but not less than 10 feet from an oven, an oven heater or ductwork.
- 3-1.4** Ovens shall be located to minimize exposure to people from the possibility of injury from fire, explosion, asphyxiation, and hazardous materials and shall not obstruct personnel travel to exit ways.
- 3-1.5** If the oven control panel is located away from the oven, operators must be allowed access to the control panel and/or main disconnect to allow them to shut down the oven in an emergency.
- 3-1.6** Ovens shall be located to prevent an ignition source to flammable coating dip tanks, spray booths and storage and mixing rooms for flammable liquids, and to prevent exposure to flammable vapor or combustible dust clouds. Ovens should not be located in hazardous (classified) locations unless they are designed to comply with the applicable requirements of NFPA 70 "National Electrical Code" (see Appendix B).
- 3-1.7** Equipment shall be protected from corrosive external processes and environments, including fumes or materials from adjacent processes or equipment that produces corrosive conditions when introduced into the oven environment.
- 3-1.8** The oven is not intended for outdoor installation and must be sheltered from weather. Unheated shelters may result in non-uniform temperatures or insufficient heat to attain maximum operating temperature. Condensation may also occur which would be detrimental to the steel structure and electrical components.
- 3-1.9** Suitable portable fire extinguishers should be available and operators trained in their use. All such fire protection equipment should be inspected periodically in accordance with appropriate standards. Reference NFPA 10 "Standard for Portable Fire Extinguishers" (see Appendix B).

#### **3-2 BUILDING CONSIDERATIONS**

- 3-2.1** When selecting the location for an oven, consideration must be given to the possibility of fire, building damage and personal injury. Hazards to be considered include overheating of material in the oven and escape of fuel gas or exhaust into the work place.
- 3-2.2** Ovens shall be located and erected so that the maximum anticipated temperature does not affect the building structural members adversely or by the additional loading caused by the oven and load.

- 3-2.3** Ovens should be placed on noncombustible floors or on structures approved for use over combustible floors such as concrete floor slabs or hollow tiles.
- 3-2.4** If necessary, level the oven using shims. Due to expansion, larger ovens may change shape when heated and require the shims to be adjusted when the oven is hot. Where mounting holes are provided, anchor the oven securely. Shims should be permanently mounted to the oven after installation.

### **3-3 CLEARANCES**

- 3-3.1** Ovens shall be located with adequate space above and on all sides to allow for inspection, maintenance and operator access. Provisions also shall be included for unobstructed discharge of building sprinklers, the installation of automatic fire protection system within the oven, if necessary, and the proper functioning of explosion relief doors and panels.
- 3-3.2** Do not place the oven up against a wall. A minimum air space of 3 inches must be provided on all sides to allow for air circulation, with additional space being provided for ovens operating over 450°F (232°C) to keep temperature at adjacent structures and materials below 160°F (71°C). Local, city and state codes may specify building requirements and special provisions for locating ovens.
- 3-3.3** The oven should be located so there is unrestricted air circulation around all motors for proper cooling.
- 3-3.4** Do not store material on top of oven. Material may get hot, ignite and cause a fire. The oven is not designed to carry exterior loads and, if equipped with explosion venting roof panels, material stored on top of the oven will restrict explosion venting panel operation.
- 3-3.5** To prevent ignition of combustible material, combustible material shall be located at a safe distance from the oven and oven ductwork. The National Fire Protection Association (NFPA) Standard 86 specifies a minimum distance of 2-1/2 feet; Factory Mutual (FM) specifies at least 10 feet.
- 3-3.6** The oven doors have explosion-venting latches, which will allow the doors to open if pressure develops in the oven. The door travel must not be restricted and should face away from main aisles, work areas and automatic sprinkler risers, feeds and cross mains.
- 3-3.7** If the oven is equipped with explosion venting roof panels, the panels must not be obstructed in any way. Explosion venting roof panels will have the panel edges exposed - if in doubt, consult factory. Sufficient headroom must be provided for the panels to lift completely out of the oven. Minimum clearance is the oven wall thickness plus 12".

### **3-4 VENTILATION**

- 3-4.1** Where ovens are located in basements or enclosed areas, sufficient room ventilation shall be supplied to provide required combustion air for fuel-fired equipment and to prevent the hazardous accumulation of vapors from processing.



- 3-4.2** Ovens designed for use with fuel gas having a specific gravity greater than air (such as propane) shall be located at or above grade and shall be located to prevent the escape of the fuel gas from accumulating in basements, pits, or other areas below the oven.
- 3-4.3** Fresh air inlets and exhaust outlets must never be restricted. If filtered air is provided, there must be adequate filter capacity to prevent any reduction in airflow even under adverse loading of the filter. The filters must be periodically inspected and replaced as required.
- 3-4.4** A sufficient quantity of building make-up air should be admitted to oven rooms and buildings to provide the air volume required for oven safety ventilation and adequate combustion air for fuel fired equipment. Buildings should not operate under a negative pressure.
- 3-4.5** The oven is equipped with an exhaust outlet. This outlet must be connected to an exhaust stack for discharge to an outside location, and in a manner in accordance with local codes and requirements; or connected to outside indirectly through a fume incinerator or other approved pollution device. The exhaust outlet is sized to fit standard stove pipe components. Exhaust gas temperature is the same as internal oven temperature. Caution must be taken to protect combustible building materials from coming in contact with the hot exhaust stack.
- 3-4.6** The minimum safe exhaust rate must be confirmed for ovens equipped with a powered forced exhauster to handle flammable solvent vapors or products of combustion from fuel fired equipment. The exhaust rate has been set at the factory and dampers cut off and screwed in place or in some other manner limited to prevent exhaust rate from being reduced below safe minimum exhaust rate.

After installation, this exhaust rate must be confirmed. This must be done at the outlet of the stack from the building. The exhaust rate must meet or exceed the minimum rate indicated on the Safety Design Form located on the side of the oven. If it is necessary to open the exhaust damper to increase the exhaust rate, it must be cutoff or locked in position to prevent accidental closing.

Exhaust rate must be checked again if any changes are made to ventilation system, duct work, or building ventilation. Adding additional equipment, which requires ventilation, to the building will require additional make up air to the building to prevent the building from operating under negative pressure. Operating building under negative pressure will reduce exhaust rate from oven to below safe minimum exhaust rate.

- 3-4.7** For additional ventilation information, refer to NFPA 31 "Standard for the Installation of Oil-Burning Equipment", NFPA 54 "National Fuel Gas Code" and NFPA 91 "Standard for Exhaust Systems for Air Conveying of Vapors, Gases, Mists and Noncombustible Particulate Solids" (see Appendix B).

### **3-5 EXHAUST DUCTWORK**

- 3-5.1** Wherever oven ducts or stacks pass through combustible walls, floors, or roof, either non-combustible insulation or clearance (or both) shall be provided to prevent combustible surface temperatures from exceeding 160°F (72°C).
- 3-5.2** Where ducts pass through non-combustible walls, floors or partitions, the space around the duct shall be sealed with non-combustible material to maintain the fire resistance rating of the barrier. Ducts that pass through fire walls should be avoided. Local, city and state codes may apply to duct installation.

- 3-5.3** Exhausts systems should be installed in accordance with Chapter 1, 2 and 3 of NFPA 91 "Standard for Exhaust Systems for Air Conveying of Vapors, Gases, Mists, and Noncombustible Particulate Solids" (see Appendix B).
- 3-5.4** Ducts shall be constructed entirely of sheet steel or other non-combustible material capable of meeting the intended installation and conditions of service. The installation shall be of adequate strength and rigidity and shall be protected where subject to physical damage.
- 3-5.5** Ducts handling fumes that leave a combustible deposit shall be provided with clean-out doors and such doors should be equipped with tight fitting doors or covers. It is important that ovens and ducts be kept clean if they are subjected to a build-up of flammable deposits of condensed solvent, oil vapors, dust or other combustible debris. The build-up of condensed vapors or combustible debris is a major cause of fires. Frequency of cleaning should be based on never allowing build-up to exceed 1/8" thickness in any location.
- 3-5.6** No portions of the building shall be used as an integral part of the duct.
- 3-5.7** All ducts shall be made tight throughout and shall have no openings other than those required for the operation and maintenance of the system. All interior laps in the duct joints should be made in the direction of the flow.
- 3-5.8** All ducts shall be thoroughly braced where required and substantially supported by metal hangers or brackets.
- 3-5.9** Ducts handling flammable vapors shall be designed to minimize the condensation of the vapors out of the exhaust stream onto the surface of the ducts. One method is to insulate the ducts. If flammable condensation cannot be avoided, ducts should be pitched to drain to suitable traps or other safe locations.
- 3-5.10** Ducts handling combustible solids shall be designed to minimize the accumulation of solids within the ducts.
- 3-5.11** Exhaust ducts that will contain combustible deposits of any type require automatic sprinklers in accordance with NFPA 13 "Standard for Installation of Sprinkler Systems" (see Appendix B).
- 3-5.12** Exhaust ducts shall not discharge near building openings or other air intakes that allow re-entry of effluents into the building.
- 3-5.13** Clearance between metal ducts and stored combustible material should be at least 2-1/2 feet. Guards should be installed to assure this clearance.
- 3-5.14** Multiple exhaust fans manifolded together should have manifold designed so that operation of one or more exhaust fan does not create a hazard such as back flow to an idle oven or reduced exhaust flow due to increased manifold pressure.
- 3-5.15** Duct work should not include dampers that could be closed and restrict flow within the ductwork.

### **3-6 FUEL GAS SUPPLY**

- 3-6.1** Piping from the point of delivery to the equipment should comply with NFPA 54, National Fuel Gas Code. Local, city and state codes should be followed. Gas source pressure must be less than 60 psig.
- 3-6.2** A gas filter or strainer and sediment trap with vertical leg (drip leg) at least 3 pipe diameters long (3 inch minimum) of same size as supply piping, shall be installed in the fuel gas supply piping to protect the downstream safety shutoff valves and regulator from materials that could interfere with their operation.
- 3-6.3** All gas-heated equipment shall be provided with an individual gas pressure regulator properly sized to supply the pressure and volume required. The oven nameplate lists the gas pressure and the burner capacity. Gas pressure regulator should have the following characteristics:
- The regulator must be of the full lock-up type; gas pressure must be regulated even under no flow condition.
  - Incoming pipe size should not exceed 2" diameter
  - Self contained with no external static or control piping
  - Single port with correctly sized orifice for the maximum gas pressure at the regulator inlet.
  - Valve seat is of resilient material designed to withstand abrasion of gas, impurity in gas, cutting by the valve and to resist permanent deformation by the valve port
  - Capable of regulating downstream pressure under no flow conditions to not more than 150 percent of the discharge pressure under flow conditions.
- If these criteria are not met, a pressure relieving or limiting device is required as outlined in NFPA 54 National Fuel Gas Code.
- 3-6.4** A remotely located emergency manual shutoff valve shall be provided to allow the fuel to be turned off in an emergency and shall be located so that fire or explosion at the oven does not prevent access to this valve. Operators should be instructed on the location of this valve and allowed access to shut off fuel flow in an emergency. Valve shall have permanently affixed visual indication of position and operable without tools.
- 3-6.5** An equipment isolation shutoff valve must be provided at each piece of equipment. Valve shall be quarter turn with stop, permanently affixed visual indication of position, and operable without tools. Valve handle must remain affixed and be parallel to pipe when open and perpendicular to pipe when closed.
- 3-6.6** Regulators and high or low gas pressure switch vent lines shall be piped to a safe location outside the building according to local codes. Protect outlet from water entry and provide bug screen.
- 3-6.7** Vent lines from regulator and switches of a single oven may be manifolded together in such a manner that diaphragm rupture of one regulator or switch does not back load others. Cross-sectional area of manifold shall not be less than the greater of either
- cross-sectional area of largest vent line plus 50%, or
  - sum of cross-sectional area of two largest vent lines
- 3-6.8** Vent lines from multiple ovens shall not be manifolded together.
- 3-6.9** A normally open vent valve between safety valves shall not be combined with other vents. Care must be taken to terminate a vent valve line in a safe approved location..

**3-6.10** Over pressure protection shall be provided if supply pressure exceeds pressure rating of any downstream component or if failure of any single upstream regulator could result in supply pressure exceeding pressure rating of any downstream component. Refer to NFPA 86 (2015) 6.2.7 for acceptable oven pressure protection.

### **3-7 ELECTRICAL**

**3-7.1** All electrical connections should be made in accordance with the appropriate local and national codes. Refer to NFPA 70 "National Electric Code" (see Appendix B).

**3-7.2** Properly size the electrical supply using information provided on the oven nameplate. Electric supply must include a safety shut off such as a circuit breaker or fused disconnect switch between your power supply and the equipment.

**3-7.3** The oven must be adequately grounded. Grounding wire must be sized in accordance with local codes. Where more strict codes do not exist, refer to the National Electrical Code - NFPA 70. A grounding lug has been provided near the power input terminals.

**3-7.4** Care must be taken during installation of electrical service to the control panel that metal chips or filings do not get into electrical components. Cover components when drilling or cutting control panel.

### **3-8 STEAM SUPPLY**

**3-8.1** Piping and fittings of steam supply shall be in accordance with ASME B31.1 "Power Piping" (see Appendix B).

#### **4 PRIOR TO PLACING THE OVEN IN SERVICE**

- 4-1** Read instruction manual completely. Additional copies of the "Operating Instructions" have been provided in plastic covers for posting at the oven.
- 4-2** The excess temperature limit interlock should be connected to your alarm system. The wiring schematic indicates where the alarm relay should be located for this alarm circuit.
- 4-3** After the installation is completed, replace all doors, covers and guards that had been removed for shipment or installation. At no time should equipment be operated if covers or guards are open, removed or partially closed.
- 4-4** When the equipment is placed in operation, check all blowers for proper rotation. Rotation directional arrows are located near each blower. Three phase motors may be reversed by interchanging any two (2) of the three (3) wires, which supply power to the oven. Do not switch leads at the motor starter or motor. Single-phase motors are correctly set at the factory but correct rotation should still be confirmed.
- 4-5** The exhaust rate must be checked on ovens equipped with a powered forced exhauster to handle flammable solvent vapors or products of combustion from gas heated equipment. This must be done at the outlet of the stack from the building with all dampers in minimum position. The exhaust rate must meet or exceed the minimum rate indicated on the Safety Design Form located on the side of the oven. If it is necessary to open the exhaust damper to increase the exhaust rate, it must be cutoff or locked in position to prevent accidental closing.
- 4-6** Check incoming voltage against that shown on the nameplate.
- 4-7** Check operating current against the amperage shown on the nameplate.
- 4-8** On gas-heated equipment, purge gas line to oven of all air. While purging gas line of air, purged gas must be vented to an approved location outside the building.
- 4-9** Check gas pressure against that shown on the oven nameplate.
- 4-10** Tighten all terminals, especially on power connections, to minimize terminal and component failure due to poor contact. Connections should be checked periodically for tightness and signs of overheating.
- 4-11** All ovens will produce smoke and odors when first heated. The smoke and odors come from three sources:
  - 1) Surfaces that have been painted after test;
  - 2) Binders that remain in the insulation;
  - 3) Moisture that has been absorbed by the insulation.

If during the initial run of the oven, the smoke and odors become objectionable, set the temperature at 300°F and allow the oven to remain at 300°F until the smoke is no longer generated. Increase the temperature in steps until you've reached the maximum operating temperature. It may take several days of running at the maximum operating temperature to eliminate all smoke and odors.

If the oven is not heated for an extended time period, moisture may accumulate in the insulation. When heated, this moisture will be driven out and the above process may have to be repeated.

**4-12** Commissioning is required prior to releasing equipment for production. The party responsible shall insure that installation is complete and done correctly. Safety systems should be tested and operators trained. At the time of commissioning the first Periodic Maintenance Inspection should be performed to familiarize personnel with the equipment. See Section 5 - PROCESSING and Section 7 - MAINTENANCE.

**4-12.1** Set points of all safety interlocks shall be documented for future reference.

**4-12.2** Supply fuel piping shall be checked for leaks.

**4-12.3** Personnel operating, maintaining or supervising shall be instructed and trained in their job functions and be required to demonstrate an understanding of the equipment, its operation and safe operating procedures including emergency shutdown.

**4-12.4** Equipment shall be operated in accordance with original design parameters.

**4-12.5** Personnel operating, maintaining or supervising shall be informed of the danger of removing, or rendering ineffective, safety devices.

## 5 PROCESSING

### 5-1 **DO NOT LEAVE THIS EQUIPMENT IN OPERATION UNATTENDED**

When using any heat processing equipment there is always the risk of overheating due to a component malfunction. A trained operator should always be present. If this is not possible, the oven should be located where overheating will not cause damage to the building, adjacent stock or endanger personnel. Special consideration should be made for the potential of smoke damage should a fire ensue. Fire suppression equipment should be installed to protect the oven and building. The excess temperature limit interlock should be connected to the building alarm system.

5-2 For start-up, emergency shut down and operation of optional equipment refer to the specific operating instructions for your equipment located elsewhere in the manual. A second set of these specific operating instructions is provided for posting at the oven for the operator.

5-3 When loading an oven care must be taken to avoid touching or insulating the thermocouple or temperature sensor. Free air movement around this sensor is essential for safe and correct temperature control.

5-4 The excess temperature limit interlock should be set slightly above the operating temperature to protect the workload. Overheating of material is a major cause of fire loss. Excess temperature limit interlock should indicate in the same temperature units (°F or °C) as the main controller.

5-5 An alarm should be installed that will sound upon the excess temperature limit interlock being activated. This alarm should be installed in an area where it will attract the attention of plant personnel properly trained to take corrective action. The wiring schematic provided in this manual indicates where the alarm relay should be located for this alarm circuit.

5-6 Ovens handling flammable solvents and fuel-fired ovens have a minimum safe exhaust rate. These ovens have cut off dampers on fresh air and exhaust. Do not close the fresh air or exhaust beyond these settings.

5-7 Ovens that are designed for flammable solvent processing and/or are fuel fired, include a purge timer. This timer is factory set based upon a specific application. DO NOT change the purge timer setting. Purge time is calculated to exhaust four (4) oven volumes of fresh air prior to allowing the heat to be turned on. Reducing purge time could result in failure to remove combustible vapors from oven before heat is turned on. This could result in an explosion and fire. A caution nameplate is located next to the purge timer indicating the correct setting.

5-8 Do not overload the oven. Air circulation is very important to the proper operation of an oven.

5-8.1 Ovens designed for shelf loading should not have parts placed on floor of workspace. This surface could be hotter than air temperatures and it is not designed to support a load.

5-8.2 Leave space between articles on each shelf to allow air to move between parts.

5-8.3 Parts should be staggered from one shelf to another, to prevent dead spots in the air pattern.

- 5-9** Open the exhauster and fresh air dampers enough to prevent fouling of the work. Where significant amounts of smoke or moisture are being driven off in the oven process, it is necessary to exhaust enough air to remove this material. Failure to provide sufficient ventilation may result in condensation of oil or solvent vapors inside oven walls with a resulting risk of fire.
- 5-9.1** When the exhaust is increased, the fresh air intake must also be increased. Failure to do this will result in cold spots within the oven, particularly around the doors, since air will be drawn in past the gaskets. When the fresh air intake damper is properly adjusted, there will be a slight leaking of hot air out of the door gaskets. The fresh air intake damper is located on the wall of the heat chamber or around the blower shaft opening.
- 5-9.2** Proper balance of the fresh air inlet and exhaust outlet are essential for uniform air temperature. Room air entering the fresh air inlet expands when heated and pressurizes the workspace forcing air out the exhaust or past the door gasket. Too much fresh air (or too little exhaust) can result in excessive leakage of hot air at the door seal.
- 5-10** Where ovens are equipped with louvered ductwork, the louvers may be adjusted to give the best performance for your particular process. The louvers were originally set at the factory in an empty oven. Loading of your parts may affect uniformity. These louvers are not designed for frequent adjustment and should only be changed when absolutely necessary. Louvers should be opened where the workspace is cold and closed where it is hot.
- 5-11** Hot loads, tongs and other hot tools or fixtures such as shelves and loading trucks, should be located in areas clearly marked to warn plant personnel of the potential danger of burns or fires caused by the hot parts.



## **6 SAFETY EQUIPMENT**

- 6-1** Practically all explosions and fires in ovens can be traced back to human error. It should be noted that:
- 6-1.1** For the protection of personnel and property, careful consideration should be given to the supervision and monitoring of conditions that could cause, or could lead to, a real or potential hazard on any installation.
  - 6-1.2** The presence of safety equipment on an installation cannot, in itself, ensure absolute safety of operation.
  - 6-1.3** There is no substitute for a diligent, capable, well-trained operator.
  - 6-1.4** Highly repetitive operational cycling of any safety device can reduce its life span.
- 6-2** Electric relays and safety shutoff valves should not be used as substitutes for electrical disconnects and manual shutoff valves.
- 6-3** Regularly scheduled inspection, testing, and maintenance of all safety devices shall be performed. (See Section 7 - MAINTENANCE and Appendix C - MINIMUM PERIODIC MAINTENANCE REPORT)
- 6-4** Safety devices shall not be removed or rendered ineffective by bypassing them electrically or mechanically.
- 6-5** New equipment includes the safety equipment listed below as required by NFPA 86 for ovens not processing flammable solvents or vapors. Additional safety equipment is required for ovens processing flammable solvents or vapors. Other processes may require additional safety equipment. See Appendix A – SAFETY EQUIPMENT DESCRIPTION & OPERATION for detailed explanation of each item.
- 6-5.1** For electric ovens:
    - manual reset excess temperature limit interlock
    - separate heating element control contactors
    - recirculating blower air flow switch
  - 6-5.2** For gas heated ovens:
    - manual reset excess temperature limit interlock
    - recirculating blower airflow switch
    - powered forced exhauster
    - exhauster airflow switch
    - purge timer
    - combustion air flow switch
    - high gas pressure switch
    - low gas pressure switch
    - two (2) main safety shut off valves and test stations
    - two (2) pilot safety shut off valves and test stations
  - 6-5.3** For steam heated ovens:
    - manual reset excess temperature limit interlock
    - separate back-up steam valve
    - recirculating blower air flow switch
- 6-6** No matter how much safety equipment is provided on the oven, it cannot protect the operator, other personnel or property from unsafe conditions caused by poor judgement or misapplication. Common sense must be used for safe operation. If in doubt, contact the factory. Check the process periodically to ensure oven is being used as originally intended.

## **7 MAINTENANCE**

**7-1** For safe oven operation, a preventive maintenance program must be developed and followed for each individual oven application. The user should review recommendations from their insurance underwriters. We suggest the review of Factory Mutual (FM) Specification 6-9 on Industrial Ovens and Dryers and the National Fire Protection Association (NFPA) Specification 86 on Ovens and Furnaces. We also recommend a Maintenance Report be developed which lists tests and inspections performed. A copy of this report should be kept on file for future review.

A Minimum Periodic Maintenance Report is provided in Appendix C as an example for developing your own periodic maintenance schedule and report.

**7-2** Regularly scheduled inspection and maintenance (preventative maintenance) of all safety devices shall be performed by the user to ensure proper function. At a minimum, the unit should be fully inspected annually. This interval should be shortened for units operating more than 40 hours per week or when previous inspections have shown a need for more frequent inspections.

**7-3** Disconnect fuel, electric power, steam, compressed air and any other energy source before servicing equipment. Ovens operate under high voltage and electrical shock is possible. Proper OSHA required lockout procedures should be followed.

**7-4** Ovens with vertical lift doors or top-loading doors must be blocked open before entering. Falling door may cause bodily injury. A safety pin or support strut is provided for this purpose.

**7-5** Do not operate mechanical or electrical equipment with guards removed. Operating with guards removed could result in bodily injury.

**7-6** The oven work space or heat chamber may constitute a confined space as defined by OSHA. If so, comply with OSHA confined space hazard requirement (ANSI Z117-1).

### **7-7 RECOMMENDED MAINTENANCE ITEMS**

It shall be the sole responsibility of the user to establish, schedule and enforce the frequency of and the extent of the inspection/maintenance program (as well as the corrective action to be taken) because only the user can know what the actual operating conditions are. Personnel who are familiar with the equipment should make the tests. It is usually better that maintenance personnel from mechanical and electrical departments check the equipment rather than regular oven operators. These additional observers may find changes that may be otherwise overlooked.

The following are minimum maintenance items we recommend be covered. Your list will vary depending upon the specific oven and operating conditions.

#### **7-7.1 Application**

**7-7.1.1** The user is responsible to ensure that the oven process has not changed from the conditions for which it was designed and that the oven is not modified. Specifically, it must be ensured that the design exhaust rate is obtained, and that amount of flammable solvents placed in the oven and the operating temperature does not exceed the design capacity.

## **7-7.2 Electrical**

- 7-7.2.1** Periodically tighten all terminals, especially on power connections, to minimize terminal and component failure due to poor contact.
- 7-7.2.2** Periodically inspect contacts in contactors, relays, motor starters, etc., for signs of wear or sticking.

## **7-7.3 Oven Body**

- 7-7.3.1** The exterior of the oven should be touched up whenever scratches occur to prevent rusting.
- 7-7.3.2** Do not allow accumulation of combustible material or other foreign matter in the work space, heat chamber (including heating element or steam coil surfaces) ductwork, air inlets, exhaust outlets, filters, control enclosures, motors, safety switches, door latches, and door hinges. Care must be taken in cleaning any combustible build-up to avoid creating a source of ignition (spark). Scraping with non-sparking tools or melting with steam is suggested. Lint and dust should be removed by vacuum cleaning. Blowing with compressed air or steam should be avoided if there is a possibility of explosion from a combustible dust cloud.
- 7-7.3.3** Do not allow accumulation of combustible material on work holders, drip pans or on floor of oven.
- 7-7.3.4** Temperature control and excess temperature limit interlock thermocouples must be inspected periodically for damage. Location of the thermocouples cannot be changed. Thermocouples must be located in free air not touching any portion of oven body, load-handling material such as shelves, racks, or the work load.
- 7-7.3.5** Roof and wall explosion relief panels with or without latches must not be restricted by storage material or other items placed on or near panels, which can limit operation.
- 7-7.3-6** Oven repair by cutting, welding or any other method that could produce a source of ignition (spark) should be avoided and only then after all combustible deposits or debris have been removed.

## **7-7.4 Duct Work**

- 7-7.4.1** It is important oven ducts be kept clean. If they are subjected to a build-up of flammable deposits of condensed solvent, oil vapors, dust or other combustible debris they must be periodically cleaned. The build-up of condensed vapors or combustible debris is a major cause of fires. Cleaning frequency should be determined by process requirements.

## **7-7.5 Lubrication**

- 7-7.5.1** Electric motors having oil holes require lubrication after every 25,000 hours or 3 years of light duty operation. Use a good grade of SAE 10 electric motor oil or as recommended by the manufacturer of the motor. Larger motors in the integral horse power range, which require grease, should be greased every six (6) months or more frequently where the severity of the service would dictate. No special heat resistant grease is necessary.

**7-7.5.2** All bearings, including those on blowers, exhauster or conveyor system, should be greased every six (6) months or 500 hours of operation with a good grade of machine grease. No special heat resistant grease is necessary.

**7-7.5.3** Explosion relief door latches must be inspected regularly, at least every two months, for adequate lubrication and freedom of movement. Restricted door movement could result in limited explosion venting. Heavy grease should be applied to the latch spring and cam. SAE 30 grade oil should be used on the pivot joint.

#### **7-7.6 Doors/Gaskets**

**7-7.6.1** The oven doors should be inspected regularly to see that latches are holding the door firmly and uniformly against the oven providing a maximum sealing force. Slots in the mounting brackets and adjusting screws are available for this purpose. **NOTICE:** Before attempting these adjustments, be sure the oven is level. If the oven is not on a solid level base, it could twist out of square resulting in a poor seal, which cannot be corrected by hinge and latch adjustment. If double doors do not line up across the top, it is an indication that the oven is not level. In these cases, shim the front corner of the oven as necessary to allow doors to line up across the top.

**7-7.6.2** The door should be inspected for damage, which would allow excessive leakage of hot air. The gasket should be replaced when damaged or when an adequate seal cannot be maintained.

**7-7.6.3** The door and associated venting latches should be checked periodically. Normally, a moderate push or pull by one person on the door or panel should cause the door and latches to operate. Actual push/pull tests with pressure release measurements or spring-loaded scales should be performed annually. Maximum release pressure is 20 pounds per square foot of door area.

#### **7-7.7 Blowers and Exhausters**

**7-7.7.1** Tighten set screws between bearings and shaft before operating and check periodically. Loose bearings will allow shaft movement resulting in wear to the shaft within the bearing race. Setscrews on blower wheels must also be checked and tightened.

**7-7.7.2** Recirculation and exhaust blowers that are V-belt driven shall be checked for proper sheave alignment to prevent excessive belt wear and to make sure belts are not slipping.

**7-7.7.3** Inspect to make sure all blowers; exhausters and other fans are rotating in the correct direction. Refer to Section 4-4 for changing rotation.

**7-7.7.4** Periodically inspect and clean blower and exhauster wheels to remove any build up of deposits on the blade surfaces. Accumulation of deposits could possibly reduce volume of airflow and cause a dangerous reduction in safety ventilation.

**7-7.7.5** Air flow test should be conducted on the exhaust flow under oven operating conditions, with volume controls at their minimum settings, to ensure that the safety ventilation required is achieved. Reference Safety Design Form for required ventilating. See Section 8 - TROUBLE SHOOTING for inadequate ventilation symptoms.

## **7-7.8 Electric Ovens**

- 7-7.8.1** Temperature controller should cycle main contactor(s), or SCR power controller, only. Separate (back-up) contactor(s) should not cycle.
- 7-7.8.2** All safety switches should open both main contactor(s), or SCR power controller, and separate (back-up) contactor(s).
- 7-7.8.3** Inspect heating elements for contamination, distortion and adequate support.
- 7-7.8.4** Check electrical heating element connections at terminals for tightness.

## **7-7.9 Fuel Gas Ovens**

- 7-7.9.1** Check main safety shut off valves for leakage. (See Appendix D - Main Safety Shutoff Valve Leak Test Procedure)
- 7-7.9.2** Check pilot safety shut off valves for leakage. (See Appendix D - Pilot Safety Shutoff Valve Leak Test Procedure)
- 7-7.9.3** Check that vent valve is closed when main burner is firing. (Note: Vent valve is only installed by specific request of customer.)
- 7-7.9.4** With pilot burner lit, check low gas pressure switch setting by turning gas pressure switch setting up until pilot is shutdown. Reset to original setting as indicated on electrical wiring diagram.
- 7-7.9.5** With main burner firing, check high gas pressure switch by turning gas pressure switch setting down until burner is shutdown. Reset to original setting as indicated on electrical wiring diagram.
- 7-7.9.6** Lubricate gas cocks and operate to confirm free movement
- 7-7.9.7** Locate remote emergency valve, lubricate and operate to confirm free movement.
- 7-7.9.8** Safety valves should be replaced when the number of safety valve cycles reaches 90% of lifetime cycle rating. Number of cycles can be estimated by multiplying years of service by 260 work days per year (5 day work week) and the number of times oven is turned on and off per day. Lifetime cycle rating for valves is at least 1 million cycles. Replace valves if estimated number of cycles exceeds 900,000.
- 7-7.9.9** Check that pilot and main burner lights easily and that flame appears blue with yellow tips.
- 7-7.9.10** Check gas pressure against oven nameplate and adjust as necessary.
- 7-7.9.11** Inspect flame rod; clean and reposition as necessary.
- 7-7.9.12** Inspect control valve linkage to motor operator for free and smooth operation.
- 7-7.9.13** Test burner management system (flame safety relay) by closing main burner gas cock and pilot burner gas cock causing flame relay to shut down burner by closing both safety valves and both pilot valves.

## **7-7.10 Steam Heated Ovens**

**7-7.10.1** Heat exchanger (steam coil) shall be inspected and cleaned as necessary to allow free movement of recirculated air through heat exchanger.

## **7-7.11 Safety Switches**

**7-7.11.1** Check each air flow safety switch operation by disconnecting both of the air tubes from each air flow switch to make sure oven heat is shutdown.

**7-7.11.2** Check purge timer setting against Safety Design Form. Check purge time against a clock to check timing operation.

## **7-7.12 Temperature Controls**

**7-7.12.1** Heat oven to operating temperature and check oven temperature at control point against a separate reliable temperature indicator to make sure temperature controller calibration is correct.

**7-7.12.2** Heat oven above setting of excess temperature limit interlock and make sure excess temperature limit interlock shuts down oven heat.

**7-7.12.3** Disconnect one side of thermocouple connection to confirm upscale break protection is operative on both the main controller and the excess temperature limit interlock.

## **7-7.13 Location**

**7-7.13.1** The user is responsible to determine that facility changes in the vicinity of the oven have not created a hazardous condition. Specifically, the oven should be protected from external heat, vibration, mechanical hazards and corrosive environment.

**7-7.13.2** Processes involving flammable liquids or creating explosive vapor or combustible dust clouds must not be located near the oven.

**7-7.13.3** Portable fire extinguishers located in the vicinity of the oven must be inspected periodically.

**7-7.13.4** Fire suppression system installed in the oven should be periodically tested. All sprinkler heads in oven and ductwork should be periodically inspected and cleaned.

## **8 TROUBLE SHOOTING**

### **8-1 NO HEAT**

#### **8-1.1 Air flow switch**

An airflow switch (which can be located at any blower) may be holding the control circuit open. The airflow switch senses a pressure differential across the blower. If there is no pressure differential, the heat control circuit is not closed. If the air flow switch opens, it will also reset the purge timer (if one exists). Operation and adjustment of the airflow switch are described on the manufacturer's literature. While the switch itself may be defective, an open switch may also be indicating other problems such as reverse blower rotation, slipping belts, obstructed ductwork, or a loose pressure connection or electrical connection at the switch itself.

#### **8-1.2 A fuse burned out**

In addition to the fuses in your fused disconnect switch, one or more fuses may be located inside the control panel as shown on the wiring diagram. Depending upon the particular oven involved, it is possible for a fuse to open without affecting the pilot lights (or provide other visible sign) and still affect the heat circuit.

### **8.2 REDUCED OR INCORRECT OVEN TEMPERATURE**

#### **8-2.1 Excessive Exhaust**

Due to unusual stack conditions, the amount of heated air removed from the oven may be excessive and result in a reduced operating temperature. In this case, the oven heater will be running continuously, i.e., 100% output. This can be corrected by closing the exhaust damper until the maximum operating temperature is achieved. **CAUTION:** If the oven is equipped for use with flammable solvents or is gas-heated equipment, the exhaust capacity must not be reduced below the amount indicated on the Safety Design Form. See Section 5 - PROCESSING, for information on balancing fresh air and exhaust settings.

#### **8-2.2 Door Leakage**

Damaged door gaskets or truck track seals (if applicable) combined with excessive exhaust could result in cold air being drawn in around the doorway. Replace or repair gaskets and adjust fresh air inlet. See Section 5 - PROCESSING for adjustment of fresh air inlet.

#### **8-2.3 Reduced Blower Speed**

Loose or worn drive belts could prevent the recirculating blower from attaining its design speed. This results in reduced air flow and inefficient heat transfer from the heat source to the work space.

#### **8-2.4 Incorrect Blower Rotation**

This results in reduced airflow and inefficient heat transfer from the heat source to the work area. Check blower rotation with respect to arrows located on oven or motor mount. Run each blower briefly and watch shaft rotation to ensure correct rotation. See Section 4 - PRIOR TO PLACING OVEN IN SERVICE, to correct blower rotation.

#### **8-2.5 Defective or Improperly Calibrated Temperature Controller**

See the temperature controller manufacturer's instructions for the proper operation and adjustment for the specific controller used.

### **8-2.6 Defective Thermocouples**

Most temperature controllers and excess temperature controllers are provided with thermocouples for sensing. These sensors are subject to drift over time. Compare known reading at sensor inside oven to controller display. If it varies grossly, sensor may have to be replaced. If sensor is damaged or broken open, the controller display may give thermocouple error codes (see controller manual for proper error code meanings).

### **8-2.7 On Electrically Heated Ovens - Improper Line Voltage**

Voltage at the oven should be measured to determine if an excessive line drop is causing reduced power input to the heating elements on an electrically heated oven. This could be caused by too many devices connected to the same circuit or by undersized wiring between the oven and the power source. Measure the voltage with the oven heating elements on and all other equipment on the same circuit operating.

### **8-2.8 On Gas Heated Ovens, Burner or Gas Pressure Adjustment**

Contact your local gas company's service engineers. It is recommended to have them check all installations as they are aware of the many variables, which can affect your operation. Correct gas pressure is essential. Measure gas pressure at the beginning of the oven gas pipe train to ensure pressure agrees with the oven nameplate requirement. If pressure drops as burner approaches high fire, there is insufficient gas supply.

## **8-3 EXCESS TEMPERATURE LIMIT INTERLOCK ACTUATION**

Depending upon the specific device used, it may be tripped by either an excessively high oven temperature or a sensing element failure. Before placing the equipment back into operation, it should be determined what caused the excess temperature limit interlock to actuate and the condition be corrected. See the excess temperature limit interlock manufacturer's literature for the proper operation and adjustment of the control used. **CAUTION:** If the oven is equipped for use with flammable solvents or vapors, the excess temperature limit interlock is factory set at the maximum temperature allowed and should not be set to a higher temperature.

## **8-4 THE MOTOR STARTER OVERLOADS TRIPPED**

All line voltage motors have current sensitive protective features in the motor starter. On magnetic motor starters, the "motor running" pilot light will not remain on if the overloads have tripped. The reset button is located on the motor starter inside the control panel. Measure motor amperage and compare to nameplate. If over amperage, determine cause and correct. If motor is only slightly over amperage, the overload can be increased to compensate. Motor amperage of blowers will drop as the oven heats up and the air thins out reducing the load on the motor.

## **8-5 ON GAS HEATED OVENS, PILOT WILL NOT LIGHT**

A safe-start timer is built into the flame safety relay, which will shut the system down if the pilot is not proven in approximately 10 seconds. If this timer trips, press the reset button on the flame safety relay near the gas burner. When the burner is inaccessible, a reset button will be on the control panel. See TROUBLE SHOOTING GAS HEATED EQUIPMENT procedures which is included in your manual if you have a gas heated oven.



## **8-6 INADEQUATE VENTILATION SYMPTOMS**

Vapor explosions often occur some time after ventilation becomes inadequate. Investigate the following symptoms and take corrective action immediately:

- a. A cold exhaust duct or stack while the oven is operating usually indicates reversal of flow in the stack.
- b. Evidence of negative pressure in the oven room, with respect to adjoining rooms and outdoors when the door to oven room is opened, may indicate inadequate safety ventilation and sometimes reversal of airflow in the exhaust stack.
- c. A record of fires or puffs from work in a particular oven may indicate inadequate safety ventilation, dangerously high vapor concentrations, the probability of an eventual serious oven explosion.
- d. A record of work leaving the oven with paint incompletely dried is an indication of inadequate safety ventilation.
- e. Heavy deposits of condensed paint vapors at the exhaust stack outlet may indicate that interior fouling has dangerously reduced the safety ventilation.
- f. Deposits around oven door cracks may indicate higher pressure inside the oven than in the oven room, and a lack of positive safety ventilation.

## **9 APPENDIX A - SAFETY EQUIPMENT DESCRIPTION & OPERATION**

### **9-1 MANUAL RESET EXCESS TEMPERATURE LIMIT INTERLOCK (All)**

This device will detect and be actuated when the temperature in the oven workspace exceeds a preset level. On actuation, the manual reset excess temperature limit interlock will open the control circuit to the main heat. In electrically heated ovens the circuit is opened to the heating element contactors (or SCR power controller) and separate contactors. On gas heated or steam heated equipment, the control circuit is opened to the control and safety valves.

To restore operation, the operator must manually reset the excess temperature limit interlock. This should be done only after determining the cause of overheating and correcting it. The manual reset excess temperature limit interlock is normally factory set at 15°F. above the maximum temperature of the oven or, when known, 15°F. above your maximum process operating temperature. See the manufacturers operating instructions for adjusting the manual reset excess temperature limit interlock.

### **9-2 SEPARATE CONTACTOR(S) (Electric heat only)**

A separate contactor(s) is connected in series with the main control contactor(s) (or SCR power controller) to open the circuit providing power to the heating elements. These separate contactors are powered through a series of safety interlocks including the manual reset excess temperature limit interlock. When any one of the safety interlocks open, the control circuit to the separate contactors is opened. The separate contactors provide additional protection, which cannot be obtained with the main heating element contactors (or SCR power controller) alone. The redundant separate contactors provide a second cutoff device to the heating elements, which does not cycle to maintain temperature and for this reason is less subject to wear.

### **9-3 SEPARATE BACK-UP STEAM VALVE (Steam heat only)**

A separate steam valve is connected in series with the main control steam valve to close the pipeline providing steam to the steam coil. This separate steam valve is powered through a series of safety interlocks including the manual reset excess temperature limit interlock. When any one of the safety interlocks open, the control circuit to the separate steam valve is opened. The separate steam valve provides additional protection, which cannot be obtained with the main control steam valve alone. The redundant separate steam valve provides a second cutoff device to the steam coil, which does not cycle to maintain temperature and for this reason is less subject to wear.

### **9-4 MAIN SAFETY SHUTOFF VALVES (Gas heat only)**

Two (2) separate gas shutoff valves are connected in series with the gas control valve to close the pipeline providing gas to the main burner system. When all other safety equipment indicates proper operation and the gas burner pilot has been proven ignited, these devices are electrically energized and allow flow of gas to the main burner system. These gas shutoff valves are powered through a series of safety interlocks including the manual reset excess temperature limit interlock. When any one of the safety interlocks open, the control circuit to the gas shutoff valves are opened. The gas shutoff valves provide additional protection, which cannot be obtained with the gas control valve alone. The redundant gas shutoff valves provide gas flow shutoff devices, which do not cycle to maintain temperature and for this reason are less subject to wear.

## **9 APPENDIX A (cont'd)**

### **9-5 PILOT SAFETY SHUTOFF VALVES (Gas heat only)**

On burners with a separate pilot burner, two (2) separate pilot gas shutoff valves are connected in series with the pilot burner to close the pipeline providing gas to the pilot. When all other safety equipment indicates proper operation and the gas burner pilot has been proven ignited, these devices are electrically energized and maintain flow of gas to the pilot burner. These pilot shutoff valves are powered through a series of safety interlocks including the manual reset excess temperature limit interlock. When any one of the safety interlocks open, the control circuit to the pilot shutoff valves are opened.

### **9-6 TEST DEVICE (Gas heat only)**

On gas heated equipment, the test device is used as part of an inspection program to ensure that the main and pilot shutoff valves are sealing properly. (See Appendix D - Main Safety Shutoff Valve Leak Test Procedure and Pilot Safety Shutoff Valve Leak Test Procedure.)

### **9-7 VENT VALVE (Gas heat only, if requested by customer)**

On gas-heated equipment, the vent valve is used to vent the section of gas piping between the two main safety shutoff valves. This valve is installed only at the customer's request. Customer must pipe outlet of vent valve to a safe location outside their building (in accordance with local codes) where any leaking gas will be safely disbursed to the atmosphere.

### **9-8 POWERED FORCED EXHAUSTER (All)**

As a safety device, the powered forced exhauster is used to remove a definite volume of air when flammable solvents, vapors, gases or products of combustion are present in the oven atmosphere. The exhaust rate must be properly sized to give safe operation and is determined from the quantity of material in the atmosphere and the operating temperature of the oven. Reduced exhaust could result in an explosion or fire and bodily injury or property loss.

### **9-9 AIR FLOW SWITCH (All)**

This device senses pressure differential across an exhaust blower, recirculating blower or combustion burner blower to indicate that these blowers are moving air. When there is no pressure differential, the air flow switch opens and turns off the control circuit to the main heat. In electrically heated ovens the circuit is opened to the heating element contactors (or SCR power controller) and separate contactors. On gas fired or steam heated equipment, the control circuit is opened to the control and safety valves. Where failure of the air supply is critical to prevent a dangerous situation, this device is mandatory. The air flow switch picks up typical failures such as when a motor fails to turn the blower or when the blower drive belts are broken.

## 9 APPENDIX A (cont'd)

### 9-10 PURGE TIMER (All)

Where it is necessary to ventilate the oven prior to turning the heat on, a purge timer is installed. This purge period is typically required in gas-heated equipment or when flammable solvents are present in the oven's load. The purge timer ensures that the recirculating blower(s) and powered forced exhausters(s) are operating for a preset period of time prior to turning the heat on. The purge time is typically based on allowing sufficient time for the powered forced exhauster to pull four (4) oven volumes of fresh air through the oven. The time period is factory preset and is calculated based on the exhaust rate and total volume of the oven within the insulated walls. The exhaust rate is based on the quantity of flammable solvents entering the oven and the operating temperature. In the case of gas-heated equipment, the exhaust rate is also based on the combustion venting required for the burner.

### 9-11 HIGH GAS PRESSURE SWITCH (Gas heat only)

This device is used on gas heated equipment to sense an abnormally high gas pressure which would affect the operation and safety of the equipment. If the gas pressure exceeds a preset level, the control circuit is opened to the control and safety valves. Customer must pipe the vent port on this switch to a safe location outside the building (in accordance with local codes) where any leaking gas will be safely disbursed to the atmosphere. Each such vent must be piped separately

### 9-12 LOW GAS PRESSURE SWITCH (Gas heat only)

This device is used on gas-heated equipment to detect an abnormally low gas pressure which would affect the operation and safety of the equipment. If the gas pressure drops below a preset level, the control circuit is opened to the control and safety valves. Customer must pipe the vent port on this switch to a safe location outside the building (in accordance with local codes) where any leaking gas will be safely disbursed to the atmosphere. Each such vent must be piped separately.

### 9-13 FLAME SAFEGUARD (Gas heat only)

On gas-heated equipment, a solid state, electronic flame safeguard monitors each gas burner by use of a flame rod or ultraviolet sensor. This device prevents burner operation unless the pilot burner has been proven and maintained.

### 9-14 HEAT CHAMBER MANUAL RESET EXCESS TEMPERATURE LIMIT INTERLOCK (All)

This device is similar to the manual reset excess temperature limit interlock described previously except that the sensor is located in the heating element chamber or gas burner combustion chamber of the oven

This device will detect and be actuated when the temperature in the oven heat chamber exceeds a preset level. On actuation, the heat chamber manual reset excess temperature limit interlock will open the control circuit to the main heat. In electrically heated ovens the circuit is opened to the heating element contactors (or SCR power controller) and separate contactors. On gas fired (or steam heated) equipment, the control circuit is opened to the control and safety valves.

## 9 APPENDIX A (cont'd)

To restore operation, the operator must manually reset the heat chamber excess temperature limit interlock. This should be done only after determining the cause of overheating and correcting it. The heat chamber manual reset excess temperature limit interlock is set at the maximum temperature appropriate for the heat chamber. Typically the heat chamber will run substantially hotter than the oven workspace. See the manufacturers operating instructions for adjusting the heat chamber manual reset excess temperature limit interlock.

### 9-15 HEAT CHAMBER TEMPERATURE CONTROLLER (All)

Similar to the heat chamber excess temperature limit interlock but this device is not manual reset. This device limits the heat chamber maximum temperature. When temperature of the heat chamber exceeds the setting on the temperature controller, the heat will automatically be cycled off. When the heat chamber cools down, the heat will be automatically cycled back on. While this device may slow down oven heat-up rate, it is designed to protect the heat chamber from excessive temperatures. The heat chamber temperature controller is typically installed on ovens operating over 1100°F to limit the heat chamber temperature to below 1450°F.

## **10 APPENDIX B - REFERENCES**

The following sources of additional information are provided for reference. This is not presented as a complete list of all possible reference sources.

- 10.1** Factory Mutual Engineering Corporation  
1151 Boston-Providence Turnpike  
P.O. Box 9102  
Norwood, MA 02062  
Attn: Publications Order Processing

Specifications 6-9, Industrial Ovens and Dryers

- 10.2** National Fire Protection Association  
One Batterymarch Park  
Quincy, MA 02209-9101

Most current issue of:

NFPA 86 - Ovens and Furnaces  
NFPA 70 - National Electric Code  
NFPA 54 - National Fuel Gas Code  
NFPA 10 - Standard for Portable Fire Extinguishers  
NFPA 11 - Standard for Low-Expansion Foam  
NFPA 12 - Standard on Carbon Dioxide Extinguishing Systems  
NFPA 13 - Standard for the Installation of Sprinkler Systems  
NFPA 14 - Standard for the Installation of Standpipe and Hose Systems  
NFPA 15 - Standard for Water Spray Fixed Systems for Fire Protection  
NFPA 17 - Standard for Dry Chemical Extinguishing Systems  
NFPA 17A-Standard for Wet Chemical Extinguishing Systems  
NFPA 25 - Standard for the Inspection, Testing and Maintenance of Water-Based Fire Protection Systems  
NFPA 30 – Flammable and Combustible Liquids Code  
NFPA 31 - Standard for the Installation of Oil-Burning Equipment  
NFPA 34 - Standard for Dipping and Coating Processes Using Flammable or Combustible Liquids  
NFPA 58 - Liquefied Petroleum Gas Code  
NFPA 79 - Electrical Standard for Industrial Machinery  
NFPA 91 - Standard for Exhaust Systems for Air Conveying of Vapors, Gases, Mists and Noncombustible Solids

- 10.3** ASME Publications  
American Society of Mechanical Engineers  
345 East 47<sup>th</sup> Street  
New York, NY 10017

The most current issue of:

ASME Boiler and Pressure Vessel Code  
ASME B31.1 - Power Piping  
ASME B31.3 - Process Piping

- 10.4** ANSI Publications:  
American National Standards Institute  
11 West 42<sup>nd</sup> Street, 13<sup>th</sup> Floor  
New York, NY 10036

The most current issues of:

ANSI Z117-1 - Safety Requirements for Confined Spaces

## 11 APPENDIX C – MINIMUM PERIODIC INSPECTION REPORT

Model: \_\_\_\_\_ Serial No.: \_\_\_\_\_  
Inspected By \_\_\_\_\_ Date: \_\_\_\_\_

### **BEFORE APPLYING POWER CHECK THAT:**

1. \_\_\_\_ No changes in process have been made including types of materials processed and temperature:  
  
-Oven originally designed for (reference previous Inspection Report): \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
  
-Oven being used for: \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_
2. \_\_\_\_ If flammable solvents are involved in process, quantity entering oven and operating temperature are within oven design parameters -- see Operating Manual for Safety Design Form.  
  
-Oven designed for \_\_\_\_\_ gallons of solvent (per batch or per hour) at a maximum of \_\_\_\_\_°F.  
  
-Oven being used for \_\_\_\_\_ gallons of solvent (per batch or per hour) at an operating temperature of \_\_\_\_\_°F.
3. \_\_\_\_ All electrical connections are tight without stray strands.
4. \_\_\_\_ All contactors, relays, motor starters and other components with contacts have been inspected for wear or sticking.
5. \_\_\_\_ Oven body inspected and painted surfaces touched up to prevent rusting.
6. \_\_\_\_ Oven interior inspected for component assembly and positioning, cleaned, and all foreign matter removed from:  
\_\_\_\_ Floor  
\_\_\_\_ Heat chamber (including heating element or steam coil surfaces)  
\_\_\_\_ Ductwork  
\_\_\_\_ Air inlets  
\_\_\_\_ Exhaust outlets  
\_\_\_\_ Filters  
\_\_\_\_ Control enclosure and components  
\_\_\_\_ Door hinges or support mechanism
7. \_\_\_\_ Remove and clean all drip pans. Inspect and clean all work racks, trays, holders or spacers.
8. \_\_\_\_ Locate temperature control and excess temperature limit interlock thermocouples; inspect for damage. Make sure thermocouples are in free air and not touching anything.
9. \_\_\_\_ Explosion venting panels on roof of oven or heat chamber are free to move and not obstructed; no material is stored on top of oven.
10. \_\_\_\_ Doors are free to move and not obstructed.

11. \_\_\_\_ Exhaust duct work from oven has been inspected and cleaned; all foreign matter removed.
12. \_\_\_\_ Fresh air duct work and/or filters have been inspected and cleaned; all foreign matter removed.
13. \_\_\_\_ Lubricate motors.
14. \_\_\_\_ Lubricate bearings on blower and exhauster shafts, belt conveyor shafts, door lift mechanisms and other bearings.
15. \_\_\_\_ Lubricate explosion relief door latches and check for freedom of movement.
16. \_\_\_\_ Adjust door latches and hinges for good seal around edges of door; gasket needs to only touch sealing surface, it does not need to be crushed. Inspect doors for damage and replace worn gasket if necessary.
17. \_\_\_\_ Check doors for explosion relief; maximum relief pressure of 20 lbs. per square foot of door area.
18. \_\_\_\_ Inspect and tighten set screws between bearings and shafts on blowers, exhauster, combustion blowers, belt conveyor shafts, and other bearings on shafts.
19. \_\_\_\_ Inspect and replace, if necessary, V-belts on blowers, exhausters, combustion blowers and other fans.
20. \_\_\_\_ Inspect blowers, exhauster, combustion blowers and other fans for residue build-up on fan blades and housing. Clean as necessary. Tighten set screws holding fan to shaft.

**APPLY POWER AND CHECK:**

21. \_\_\_\_ Supply voltage agrees with oven nameplate - measure between all three (3) phases and record; \_\_\_\_/\_\_\_\_/\_\_\_\_.
22. \_\_\_\_ Amperage (with everything running) agrees with oven nameplate - measure all incoming lines and record; \_\_\_\_/\_\_\_\_/\_\_\_\_.
23. \_\_\_\_ Check that all blowers, exhausters, combustion blowers and other fans are rotating in the correct direction.
24. \_\_\_\_ Check exhaust rate if it is critical for safe operation such as required for removing flammable solvents or combustion venting. This test should be with all volume controls (dampers) at minimum setting. Reference Safety Design Form for required exhaust rate.

**ELECTRIC OVENS**

25. \_\_\_\_ Check that temperature controller does not cycle separate (back-up) contactors.
26. \_\_\_\_ Shut down oven and make sure main contactors (or SCR power controller) and separate contactors all open.
27. \_\_\_\_ Inspect heating elements for contamination, distortion and adequate support.
28. \_\_\_\_ Check electrical connection at heating element terminals for tightness.



## **FUEL GAS OVENS**

29. \_\_\_\_ Check pilot safety shutoff valves for leakage. (See Appendix D for details.)
30. \_\_\_\_ Check main safety shutoff valves for leakage. (See Appendix D for details.)
31. \_\_\_\_ Check that vent valve (if installed) is closed when main burner is firing.
32. \_\_\_\_ Turning up low gas pressure switch setting shuts all valves and resets purge timer. Return to original setting. Low gas pressure switch set at \_\_\_\_\_.
33. \_\_\_\_ Turning down high gas pressure switch shuts all valves and resets purge timer. Return to original. High setting gas pressure switch set at \_\_\_\_\_.
34. \_\_\_\_ Lubricate gas cocks.
35. \_\_\_\_ Locate remote emergency shut off valve, lubricate and operate to confirm free movement.
36. \_\_\_\_ Number of safety shut off valve cycles should be estimated and safety shut off valves replaced after 90% of lifetime cycles have been reached. Cycle estimate can be made by multiplying number of years of service by 260 days per year (5 day work week) by number of times oven is turned on and off daily.
37. \_\_\_\_ Pilot and main burner light easily.
38. \_\_\_\_ Main flame blue with yellow tips.
39. \_\_\_\_ Gas pressure set at pressure shown on oven nameplate. Setting is \_\_\_\_\_
40. \_\_\_\_ Flame rod clean and positioned correctly.
41. \_\_\_\_ Control valve linkage tight and operates smoothly over full range of travel.
42. \_\_\_\_ Test flame safety relay by closing main burner gas cock and pilot burner gas cock causing flame relay to shut down burner by closing both safety valves and both pilot valves.

## **STEAM OVENS**

43. \_\_\_\_ Heat exchanger (steam coil) inspected and cleaned to allow free air movement through coil.

## **SAFETY SWITCHES**

44. \_\_\_\_ Disconnect both air tubes at each air flow switch to make sure oven heat is shut down on air flow switch deactivation.
45. \_\_\_\_ Check that purge timer is set for purge time shown on Safety Design Form and Caution nameplate installed adjacent to purge timer. Confirm purge time by checking against clock and record: \_\_\_\_\_

## **TEMPERATURE CONTROLS**

- 46. \_\_\_\_ Heat oven to operating temperature and check temperature controller calibration.
- 47. \_\_\_\_ Compare temperature controller indication and excess temperature limit interlock indication to confirm they are similar.
- 48. \_\_\_\_ Disconnect one side of thermocouple connection to confirm upscale break protection is operating on main temperature controller and excess temperature limit interlock.
- 49. \_\_\_\_ To check excess temperature limit interlock function, heat oven above excess temperature limit interlock setpoint. Make sure excess temperature limit interlock shuts down heat by opening main contactor (or SCR power controller) and separate contactors on electric ovens and closes all gas valves on gas oven. On steam oven, separate back-up steam valve will close.
- 50. \_\_\_\_ Excess temperature limit interlock is set no higher than 15°F above maximum operating temperature of oven.


## **LOCATION**

- 51. \_\_\_\_ No changes in the oven area have created a hazardous condition such as external heat, vibration, mechanical hazard or corrosive environment.
- 52. \_\_\_\_ No process change has resulted in flammable liquids or explosive vapors or dust cloud being stored or produced in vicinity of oven.
- 53. \_\_\_\_ Portable fire extinguishers in the area have been inspected.
- 54. \_\_\_\_ Fire suppression systems, such as a sprinkler system, have been inspected.
- 55. \_\_\_\_ Sprinkler heads in oven and duct work have been inspected and cleaned.

## **TRAINING**

- 56. \_\_\_\_ Review job function, oven operation and emergency shutdown with operators and supervisors.

## 12 APPENDIX D - SAFETY SHUT OFF VALVE LEAK TEST PROCEDURE



### **FIRST PILOT SHUT OFF VALVE (1PSOV)**

1. Make sure all gas cocks ahead of equipment are open to allow gas flow to equipment and turn off electrical power to the control panel to assure that there is no power to the pilot shut off solenoid valves so that they are closed (1PSOV & 2PSOV).
2. Make sure the manual test petcock (A) is closed.
3. Remove the leak test tap plug (B) and connect 1/4" tube to the petcock.
4. Close the pilot gas cock located between the pilot shut off solenoid valves and the burner.
5. Immerse the 1/4" tube vertically 1/2 inch into a jar of water.
6. Slowly open the test petcock (A).
7. Gas will bubble through the water and stop. If bubbles continue, the valve is leaking and must be replaced. Do not continue to operate burner until valve is replaced.
8. Close the test petcock (A), remove the 1/4" tube and replace the leak test tap plug (B).

### **FIRST SAFETY SHUT OFF VALVE (1SSOV)**

9. Make sure all gas cocks ahead of equipment are open to allow gas flow to equipment and turn off electrical power to the control panel to assure that there is no power to the safety shut off solenoid valves so that they are closed (1SSOV & 2SSOV).
10. Make sure the manual test petcock (C) is closed.
11. Remove the leak test tap plug (D) and connect 1/4" tube to the petcock.
12. Close the main gas cock located between the safety shut off solenoid valves and the burner.
13. Immerse the 1/4" tube vertically 1/2 inch into a jar of water.
14. Slowly open the test petcock (C).
15. Gas will bubble through the water and stop. If bubbles continue, the valve is leaking and must be replaced. Do not continue to operate burner until valve is replaced.
16. Close the test petcock (C), remove the 1/4" tube and replace the leak test tap plug (D).

## **12 APPENDIX D - SAFETY SHUT OFF VALVE LEAK TEST PROCEDURE** (cont'd)

### **SECOND PILOT SHUT OFF VALVE (2PSOV)**

17. Make sure all gas cocks ahead of equipment are open to allow gas flow to equipment and power is provided to the control panel. Turn on the Exhauster but do not turn HEAT switch to start to assure that there is no power to the pilot shut off solenoid valves so that they are closed (1PSOV & 2PSOV).
18. Make sure the manual test petcock (E) is closed.
19. Remove the leak test tap plug (F) and connect 1/4" tube to the petcock.
20. Close the downstream pilot gas cock located between the pilot shut off solenoid valves and burner.
21. Immerse the 1/4" tube vertically ½ inch into a jar of water.
22. Depress and hold the VALVE TEST button located at the burner junction box to open the first pilot shut off solenoid valve (1PSOV) and allow gas pressure to the second pilot shut off solenoid valve (2PSOV).
23. While holding VALVE TEST button in, slowly open the test petcock (E).
24. Gas will bubble through the water and stop. If bubbles continue, the valve is leaking and must be replaced. Do not continue to operate burner until valve is replaced.
25. Release VALVE TEST button. Close the test petcock (E), remove the 1/4" tube and replace the leak test tap plug (F).
26. Open the pilot gas cock located between the pilot shut off solenoid valves and the burner.

### **SECOND SAFETY SHUT OFF VALVE (2SSOV)**

27. Turn on the Blower (Gas cocks open and exhauster still running from step 17) and turn the HEAT switch to "START". System will purge and ignite pilot causing main safety shut off valve (1SSOV) and secondary safety shut off valve (2SSOV) to open.
28. Make sure the manual test petcock (G) is closed.
29. Remove the leak test tap plug (H) and connect 1/4" tube to the petcock.
30. Close the main gas cock located between the safety shut off solenoid valves and burner.
31. Immerse the 1/4" tube vertically 1/2 inch into a jar of water.
32. Depress and hold VALVE TEST button located at burner junction box to cause secondary safety shut off solenoid valve (2SSOV) to close. (NOTE: If customer requested vent valve is installed, vent valve will also close at this point. Check to make sure vent valve closes and that no gas is passing from vent valve outlet. To do this, the location of the outlet vent pipe must be found where it exits the building.)
33. While holding VALVE TEST button in, slowly open the test petcock (G).
34. Gas will bubble through the water and stop. If bubbles continue, the valve is leaking and must be replaced. Turn HEAT switch to "OFF". Do not continue to operate burner until valve is replaced.

**12 APPENDIX D - SAFETY SHUT OFF VALVE LEAK TEST PROCEDURE** (cont'd)

**SECOND SAFETY SHUT OFF VALVE (2SSOV)** (cont'd)

35. Close the test petcock (G). Release test button. Remove the 1/4" tube and replace the leak test tap plug (H).
  
36. Open the main gas cock located between the safety shut off solenoid valves and burner.

## 13 APPENDIX E - WARRANTY AND LIMITATIONS OF REMEDIES

Any equipment sold by GRIEVE is warranted for one (1) year after the Purchaser receives the equipment to be free from defects of material and workmanship. THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THE DESCRIPTION ON THE FACE HEREOF; WITHOUT LIMITING THE GENERALITY OF THE FOREGOING, GRIEVE EXPRESSLY DISCLAIMS ALL IMPLIED WARRANTIES, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE PURCHASER'S EXCLUSIVE REMEDY FOR ANY BREACH OF THIS WARRANTY SHALL BE FOR THE REPAIR OR REPLACEMENT (AT GRIEVE'S OPTION) OF THE DEFECTIVE EQUIPMENT OR PART.

Parts under warranty are shipped via ground transportation. Express or expedited shipping costs are the sole responsibility of the customer. In order to obtain repair or replacement under this warranty, the user must deliver the defective product or part to GRIEVE's factory on a prepaid basis promptly after discovery of the defect. GRIEVE's warranty ceases to be effective if the equipment is altered or modified, repaired other than by persons authorized by GRIEVE, misused, used by any person in an unsafe or unreasonable manner or used other than in accordance with "GRIEVE's" written instructions. Although GRIEVE makes no additional or extended warranty with respect to thermostats, recorders, control equipment or other accessories, to the extent such items may also be warranted by their respective manufacturers, those warranties are passed on to you by GRIEVE as agent of the respective manufacturer and not as a separate warrantor.

In no event shall GRIEVE be liable for any direct, indirect, special, incidental or consequential damages hereunder, whether such damages are sought based on breach of warranty, breach of contract, negligence, strict liability in tort, or any other theory of legal liability.



*Ovens and Furnaces For Industry Since 1949*

**THE GRIEVE CORPORATION**

500 Hart Road, Round Lake, Illinois 60073-2898 USA

(847) 546-8225 Fax: (847) 546-9210

www.grievcorp.com email: sales@grievcorp.com