

Models 2408 and 2404

Process Controller

User Manual

Part No HA025132_13

Date August 2014



Eurotherm®

by **Schneider** Electric

This page is intentionally blank

MODELS 2408 and 2404 PID CONTROLLERS**User Manual****Contents**

1. CHAPTER 1 installation	5
1.1 General View 2408 Controller.....	5
1.2 General View 2404 Controller.....	5
1.3 Outline dimensions Model 2408	6
1.4 Outline dimensions Model 2404	6
2 CHAPTER 2 Introduction	7
3 CHAPTER 3 Mechanical Installation.....	8
3.1 To install the controller.....	8
3.1.1 Unplugging and plugging-in the controller	8
4 CHAPTER 4 Electrical installation	10
4.1 Rear terminal layouts.....	10
4.1.1 Model 2408 rear terminal layout	10
4.1.2 Model 2404 rear terminal layout	11
4.1.3 Wire Sizes	11
4.1.4 Snubbers	11
4.1.5 Sensor input connections	12
4.1.6 Plug-in module connections.....	12
4.1.7 Four terminal modules.....	13
4.2 Connections for Process Value 2 in module position 3	14
4.2.1 Triple Logic Input and output ratings	14
4.3 Logic Drive Fan Out.....	14
4.4 Communication modules 1 and 2.....	15
4.4.1 Wiring of 2-wire EIA-485 serial communications link	16
4.5 DeviceNet	17
4.5.1 Example of Devicenet Wiring	17
4.6 ProfiBus Wiring.....	18
4.7 Typical wiring diagram	19
4.8 Motorised Valve connections.....	20
5 CHAPTER 5 OPERATION.....	21
5.1 Front Panel Layouts.....	22
5.2 Basic Operation	24
5.3 Operating Modes	24
5.4 Automatic Mode.....	25
5.5 Manual mode.....	26
5.6 Parameters and how to access them	27
5.6.1 List header displays	27
5.7 Parameter names	28
5.8 Navigation Diagram (Part A).....	29
5.8.1 Parameter tables	31
5.9 Alarms	35
5.9.1 Alarm annunciation	35
5.9.2 Alarm acknowledgement and resetting	35
5.9.3 Alarm modes	35
5.9.4 Alarm types.....	35
5.9.5 Diagnostic alarms	35
6 Chapter 6 ACCESS LEVELS.....	37
6.1 THE DIFFERENT ACCESS LEVELS	37
6.2 SELECTING AN ACCESS LEVEL	38
6.3 Edit level	39
6.3.1 Setting operator access to a parameter	39

6.3.2	Hiding or revealing a complete list	39
6.3.3	Promoting a parameter	39
6.3.4	Returning to Operator Level.....	39
7	Chapter 7 TUNING	40
7.1	What Is Tuning?.....	40
7.2	AUTOMATIC TUNING	41
7.2.1	One-shot Tuning	41
7.2.2	How to tune	41
7.3	Typical automatic tuning cycle	41
7.3.1	Calculation of the cutback values	41
7.3.2	Adaptive tune	41
7.4	MANUAL TUNING	42
7.4.1	Setting the cutback values	42
7.4.2	Integral action and manual reset.....	43
7.4.3	Automatic droop compensation (Adc).....	43
7.4.4	Tune Error.....	43
7.5	Motorised Valve Control.....	44
7.5.1	Commissioning the Motorised Valve Controller	44
7.5.2	Adjusting the minimum on-time ' <i>mP_L</i> '	45
7.5.3	Inertia and backlash settings	45
7.5.4	Calibrating the Position Feedback Potentiometer.....	45
7.6	Gain scheduling	46
8	Chapter 8 Programmer Operation.....	47
8.1	What is setpoint programming?.....	48
8.2	Programmer States.....	49
8.3	Running a program from the Run list.....	50
8.4	Running a Program Using the Run/Hold Button	51
8.5	Automatic behaviour	51
8.5.1	Servo.....	51
8.5.2	Holdback	51
8.5.3	Power failure	51
8.6	Configuring the Programmer	53
8.7	Configuring Digital Inputs to Select Program Number	55
8.7.1	Creating a New Program, or Modifying an Existing One	56
9	Chapter 9 CONFIGURATION.....	61
9.1	Selecting Configuration Level	62
9.2	LEAVING CONFIGURATION LEVEL.....	62
9.3	Selecting a Configuration Parameter.....	63
9.3.1	Parameter names	63
9.4	Changing the Passwords.....	63
9.5	Navigation Diagram (Part A).....	64
9.6	Navigation Diagram (PART B).....	65
9.7	Navigation Diagram (Part C).....	66
9.8	Configuration Parameter Tables.....	67
9.9	Configuration Examples.....	81
10	Chapter 10 User calibration	83
10.1	What is the Purpose of User Calibration?	83
10.2	User Calibration Enable	83
10.3	Offset Calibration	84
10.4	Two-point Calibration	86
10.4.1	Calibration Points and Calibration Offsets	88
11	Appendix A UNDERSTANDING THE ORDERING CODE	89
12	APPENDIX B SAFETY and EMC INFORMATION.....	93
13	APPENDIX C Technical Specification.....	96
14	Appendix D LOAD CURRENT MONITORING AND DIAGNOSTICS.....	98
14.1	Example Wiring Diagram (For mode 1 & 2 operation)	99
14.2	Example Wiring Diagram (for mode 5 operation)	100

14.3	Operation	101
14.3.1	To Read Load Current (modes 2 and 5 only)	101
14.3.2	To Display Load Current Continuously in the Lower Readout (modes 2 and 5 only)	101
14.3.3	Display Modes	101
14.3.4	How Heater Alarms are Displayed.....	102
14.3.5	To Set The Alarm Trip Levels.....	103
14.3.6	Short Circuit SSR Alarm and Heater Fail Alarm	103
14.3.7	Relay Outputs	103
14.3.8	To Configure PDS Load Current Diagnostics.....	104
14.3.9	To configure the Logic Module for PDS Modes 1 or 2.....	104
14.3.10	To configure Logic Input B for PDS (Mode 5 only)	105
14.3.11	To Configure Low and High Current Trip Alarms	105
14.3.12	To Attach Soft Alarms To A Relay Output	106
14.3.13	The Scaling Factor.....	107
14.3.14	To adjust the scaling factor.....	107
15	Appendix E: Profibus Communications.....	108
15.1	Introduction	108
15.2	About Profibus-DP	108
15.3	Technical Specification	108
15.4	Electrical Connections	109
15.4.1	Cable Specifications	109
15.4.2	Maximum Line Length per Segment.....	109
15.5	Controller Configuration and Node Address	110
15.5.1	Configuration	110
15.5.2	Assigning a Node Address	110
15.6	Network Configuration	111
15.7	Troubleshooting	112
15.7.1	No Communications:	112
15.7.2	Intermittent failure to communicate.	112
15.7.3	Intermittent flickering of status from <i>rdy</i> to <i>run</i>	112
15.7.4	Diagnostic status changing but no alarms present in the controller.	112

“This product is covered by one or more of the following US Patents:

5,484,206; Additional patents pending.

PDS and INSTANT ACCURACY are trademarks of Eurotherm.”

Issue Status of this Manual

Issue 11 of this handbook applies to software version 4 (see below).

Issue 12 corrects the procedure to access Read only Configuration Chapter 6 and correction to ordering code Digital Inputs 1 & 2 PB changed to PR.

Issue 13 standardises supply voltage ratings.

Enhancements to Software Version 4

The following enhancements have been added to software versions 4.

- Isolated Single Logic Output Module
- Transducer Power Supply Module to provide 5 or 10Vdc to an external transducer. (Not intended for melt pressure control)
- DeviceNet communications
- Linear over range limits are +5% of high instrument range and –5% of low instrument range for all process input ranges (i.e. 0-20mA, 4-20mA, 0-10V)
- Sensor break or input open circuit faults are detected on all analogue inputs (PV1.PV2 and remote input channels)
- PV2 alarm, full scale high and low limits default to maximum and minimum display limits

Deviation alarms are not inverted when direct acting control is selected. Alarm behaviour when using reverse acting control is unchanged

- The PD track valve positioning parameter (Pd_{tr}) has been removed

Controllers Affected:-

Standard controllers – which include programmers with up to 4 programs	Version 4.11 or later
Setpoint programming controllers with up to 20 programs	Version 4.61 or later
Profibus controllers – which include programmers with up to 4 programs	Version 4.32 or later

- The 10Amp output relay in module 4 is not available on controllers supplied after Jan 04

Related Information

- DeviceNet Communications Handbook part no. HA027506 which includes the parameter address map.
- Profibus Communications Handbook part no. HA026290
- EMC (Electromagnetic Compatibility) Installation Guide, part no. HA025464

These are available on www.eurotherm.co.uk.

1. CHAPTER 1 INSTALLATION

1.1 General View 2408 Controller




Figure 1: 2408 1/8 DIN Controller

1.2 General View 2404 Controller




Figure 2: 2404 1/4 DIN controller

1.3 Outline dimensions Model 2408




Figure 3: Outline dimensions of model 2408 controller

1.4 Outline dimensions Model 2404




Figure 4: Outline dimensions of model 2404 controller

The electronic assembly of the controller plugs into a rigid plastic sleeve, which in turn fits into the standard DIN size panel cut-out shown above.

2. CHAPTER 2 INTRODUCTION

Models 2408 and 2404 are high stability, temperature or process controllers with self and adaptive tuning. They have a modular hardware construction which accepts up to three plug-in Input/Output modules and two interface modules to satisfy a wide range of control requirements. Two digital inputs and an optional alarm relay are included as part of the fixed hardware build.

The instruments are available as:

- standard controllers - which include a basic 8-segment programmer
Models 2408/CC and 2404/CC
- setpoint programming controllers:
Models 2408/CP, P4, CM and
2404/CP, P4, CM
- motorised valve controllers - which include a basic 8-segment programmer
Models 2408/VC and 2404/VC
- setpoint programming motorised valve controllers:
Models 2408/VP, V4, VM and
2404/VP, V4, VM

Before proceeding, please read the chapter called, *Safety and EMC Information*.

Controller labels

The labels on the sides of the controller identify the ordering code, the serial number, and the wiring connections.

Appendix A, *Understanding the Ordering Code*, explains the hardware and software configuration of your particular controller.

3. CHAPTER 3 MECHANICAL INSTALLATION

3.1 To install the controller

1. Cut the panel to the relevant hole size shown in Figure 3 and Figure 4
2. Fit the sealing gasket behind the front bezel of the controller.
3. Insert the controller in its sleeve through the cut-out.
4. Spring the upper and lower panel retaining clips into place. Secure the controller in position by holding it level and pushing both retaining clips forward.
5. Peel off the protective cover from the display

Note: If the panel retaining clips subsequently need removing, in order to extract the controller from the control panel, they can be unhooked from the side with either your fingers, or a screwdriver.

3.1.1 Unplugging and plugging-in the controller

If required, the controller can be unplugged from its sleeve by easing the latching ears outwards and pulling it forward out of the sleeve. When plugging the controller back into its sleeve, ensure that the latching ears click into place in order to secure the IP65 sealing.

NEW SLEEVE DESIGN MKIII

From Jan-03 an improved design of 1/8 DIN long sleeve is shipped with all new 2408 controllers and indicators. (The month and year of manufacture are shown in the last two pairs of digits of the instrument serial number).

Details

A new sealing gasket will be fitted onto the instrument bezel ①. This gasket replaces the gasket which was moulded into the front of the sleeve of all previous instruments.

The gasket previously moulded into the sleeve where it fits behind the panel is now supplied as a separate item ②.

Reasons for the Change

This change is to ensure that IP65 sealing is reliably achieved and less physical effort is required to insert the instrument into the new sleeve.

Recommendations


1. An instrument delivered after Jan 03 should be used with the sleeve supplied
2. If the instrument is required to replace one already in use, the existing sleeve should also be replaced
3. A new instrument can be fitted into an existing sleeve by carefully removing gasket ① but IP65 sealing will not be maintained
4. An existing instrument can be fitted into a new sleeve but IP65 sealing will not be maintained

It is, however, possible to achieve IP65 sealing for 3 and 4 above. A gasket kit is available by quoting Part No SUB24/GAS2408.

Then:-

5. To fit a new instrument in an older sleeve carefully remove gasket ①. Replace it with the thinner (1.25mm) gasket from the kit
6. To fit an existing instrument into a new sleeve fit the thicker (1.6mm) gasket from the kit between the instrument and the sleeve

The seal ② supplied as a separate item with a new instrument, should be placed over the sleeve prior to mounting it through the panel cut out as shown below:-



4. CHAPTER 4 ELECTRICAL INSTALLATION

This section consists of five topics:

- Rear terminal layouts
- Fixed connections
- Plug-in module connections
- Typical wiring diagrams
- Motorised valve connections.



Warning: You must ensure that the controller is correctly configured for your application. Incorrect configuration could result in damage to the process being controlled, and/or personal injury. It is your responsibility, as the installer, to ensure that the configuration is correct. The controller may either have been configured when ordered, or may need configuring now. See Chapter 6, Configuration.

4.1 Rear terminal layouts

The rear terminal layouts are shown in Figure 5 and Figure 6. The right-hand column carries the connections to the power supply, digital inputs 1 and 2, alarm relay and sensor input. The second and third columns from the right carry the connections to the plug-in modules. The connections depend upon the type of module installed, if any. To determine which plug-in modules are fitted, refer to the ordering code and wiring data on the controller side labels.

4.1.1 Model 2408 rear terminal layout




Figure 5: Rear terminal layout - Model 2408

* The ground connection is provided as a return for internal EMC filters. It is not required for safety purposes, but must be connected in order to satisfy EMC requirements.

4.1.2 Model 2404 rear terminal layout




Figure 6: Rear terminal layout - Model 2404

4.1.3 Wire Sizes

All electrical connections are made to the screw terminals at the rear of the controller. They accept wire sizes from 0.5 to 1.5 mm² (16 to 22 AWG) and should be tightened to a torque of 0.4Nm (3.5lbin). If you wish to use crimp connectors, the correct size is AMP part number 349262-1. The terminals are protected by a clear plastic hinged cover to prevent hands, or metal, making accidental contact with live wires.

4.1.4 Snubbers

The relay and triac modules have an internal 15nF/100Ω 'snubber' connected across their output, which is used to prolong contact life and to suppress interference when switching inductive loads, such as mechanical contactors and solenoid valves.



Warning: When the relay contact is open or the triac is off, the snubber circuit passes 0.6mA at 110Vac and 1.2mA at 240Vac. You must ensure that this current, passing through the snubber, will not hold on low power electrical loads. It is your responsibility as the installer to ensure that this does not happen. If the snubber circuit is not required, it can be removed from the relay module (but not the triac) by breaking the PCB track that runs crosswise adjacent to the edge connectors of the module. Insert the blade of a screwdriver into one of the two slots that bound it, and twist.

4.1.5 Sensor input connections

The connections for the various types of sensor input are shown below.




Figure 7: Sensor input connections



Warning: Do not connect more than one sensor to any one input

4.1.6 Plug-in module connections

Module 1, 2 and 3

Module positions 1, 2 and 3 are plug-in modules. They can be either two terminal modules of the types shown above, or four terminal modules of the types shown in Figure 8: Two terminal module connections.

The figures below show the connections to each module and the functions that they can perform. Module 1 is normally used for heating and module 2 for cooling although the actual functions will depend upon how the controller has been configured.

PDS modes

PDS stands for 'Pulse Density Signalling' Input/Output. This is a proprietary technique for bi-directional transmission of analogue and digital data over a simple 2-wire connection.

PDS 1 mode uses a logic output module to control a TE10S solid state relay and provides a load failure alarm.

PDS 2 mode uses a logic output module to control a TE10S solid state relay, provide load/SSR failure alarms, and read back the load current for display on the controller.

See Appendix D LOAD CURRENT MONITORING AND DIAGNOSTICS for further information.

Two terminal modules

Note: Module 1 is connected to terminals 1A and 1B

Module 2 is connected to terminals 2A and 2B

Module 3 is connected to terminals 3A and 3B.

Module type	Terminal identity				Possible functions
	A	B	C	D	
Relay: 2-pin (2A, 264 Vac max.)			Unused		Heating, cooling, alarm, program event, valve raise, or valve lower
Logic - non-isolated (18Vdc at 20mA)			Unused		Heating, cooling, PDS mode 1, PDS mode 2, program event
Triac (1A, 30 to 264Vac)			Unused		Heating, cooling, program event, valve raise, or valve lower
DC output: - non-isolated (10Vdc, 20mA max.)			Unused		Heating, or cooling, or retransmission of PV, setpoint, or control output








Figure 8: Two terminal module connections

4.1.7 Four terminal modules

Note: Module 1 is connected to terminals 1A, 1B, 1C and 1D

Module 2 is connected to terminals 2A, 2B, 2C and 2D

Module 3 is connected to terminals 3A, 3B, 3C and 3D

Module type	Terminal identity				Possible functions
	A	B	C	D	
Relay: changeover (2A, 264 Vac max.)					Heating, cooling, alarm, or program event output
DC control: Isolated (10V, 20mA max.)					Heating, or cooling
24Vdc transmitter supply *	+	-			To power process inputs
Potentiometer input 100Ω to 15KΩ *		+0.5Vdc		0V	Motorised Valve Position feedback
DC retransmission					Retrans. of setpoint, or process value
DC remote input or Process Value 2 (Module 3 only)	0-10Vdc	RT source	±100mV 0-20mA	COM	Remote Setpoint Second PV
Dual output modules					
Dual relay (2A, 264 Vac max.)					Heating + cooling Dual alarms Valve raise & lower
Dual Triac (1A, 30 to 264Vac)					Heating + cooling Valve raise & lower
Dual logic + relay (Logic is non-isolated)					Heating + cooling
Dual Logic + triac (Logic is non-isolated)					Heating + cooling
Triple logic input and output modules - see ratings on the next page					
Triple contact input	Input 1	Input 2	Input 3	Common	
Triple logic input	Input 1	Input 2	Input 3	Common	
Triple logic output	Output 1	Output 2	Output 3	Common	Program events

* Can be ordered fitted in module positions 2 & 3 only.


Module type	Terminal identity				Possible functions
	A	B	C	D	
Isolated Logic Output	+			-	This is a fully isolated module which can be fitted in all three module slots. It may be used for heating, cooling or events outputs up to 18Vdc at 20mA.
Transducer Power Supply	+	-			This provides fully isolated 5 or 10Vdc to power external transmitters up to 20mA. It can be fitted in module slots 1 and 2.

Figure 9: Four terminal module connections

4.2 Connections for Process Value 2 in module position 3

The diagrams below show the connections for the various types of input.

The input will have been configured in accordance with the ordering code.



4.2.1 Triple Logic Input and output ratings

1. Triple logic input (current sinking)

- OFF state: -3 to 5Vdc
- ON state: 10.8 to 30Vdc(max) , at 2 to 8mA

2. Triple contact closure or open collector transistor input

Internally generated switching Vdc & mA: 15 to 19Vdc at 10 to 14mA

- OFF state: $>28\text{K}\Omega$ input resistance
- OFF state voltage: $>14\text{Vdc}$
- ON state: $<100\Omega$ resistance
- ON state voltage: $<1.0\text{Vdc}$

3. Triple logic output (current sourcing)

- OFF state output: 0 to 0.7Vdc .
- ON state output: 12 to 13Vdc , at up to 8mA .

4.3 Logic Drive Fan Out

The logic outputs from the 2400 series controllers are capable of driving more than one solid state relay (SSR) in series or parallel. The following table shows the number of SSRs which can be driven depending on type of SSR. S = Series; P = Parallel.

	Drive mA	SVDA	RVDA	TE10S	425S		
		Logic DC	Logic DC	Logic DC	Logic 10V	Logic 24V	Logic 20mA
Logic	$18\text{V@}20\text{mA}$	4S 6P	4S 3P	3S 2P	3S 3P	1S 2P	6S 1P
Triple logic	$12\text{V@}9\text{mA}$	3S 3P	2S 1P	2S 1P	2S 1P	1	4S 1P

	450			TC1027CE	TE200S	TC2000CE	RS3DA
	Standard	TTL	Multi-drive	Logic V	Logic DC	Logic DC	Logic DC
Logic	2S 3P	1S2P	6S 1P	3S 3P	3S 3P	3S 1P	4S 2P
Triple logic	1	1	4S 1P	2S 1P	2S 1P	0	0

Figure 10: Logic drive capabilities

4.4 Communication modules 1 and 2

All 2408 and 2404 controllers can be fitted with up to two plug-in communications modules.

Only one of the two modules can be for serial communications and this will normally be installed in position COMMS 1 (although it is possible to install the serial communications module in position COMMS 2. Serial communications may be configured for either Modbus or EI bisynch protocol.

It is also possible to fit a PDS module in one or other of these positions.


Possible module types are shown in the table below.

Communications module 1	Terminal identity (COMMS 1)					
	HA	HB	HC	HD	HE	HF
2-wire EIA-485 serial communications	–	–	–	Common	A (+)	B (–)
EIA-232 serial communications	–	–	–	Common	Rx	Tx
4-wire EIA-485 serial communications	–	A' (Rx+)	B' (Rx–)	Common	A (Tx+)	B (Tx–)
PDS Setpoint retransmission	–	–	–	–	Signal	Common

Communications module 2	Terminal identity (COMMS 2)		
	JD	JE	JF
PDS Setpoint retransmission	–	Signal	Common
PDS Setpoint input	–	Signal	Common

Figure 11: Communications modules 1 and 2 connections

4.4.1 Wiring of 2-wire EIA-485 serial communications link



Note:

All termination resistors are 220 ohm 1/4W carbon composition.

Local grounds are at equipotential. Where equipotential is not available wire into separate zones using a galvanic isolator.

Figure 12: EIA485 wiring

4.5 DeviceNet

Instruments fitted with software versions 4 onwards can be fitted with DeviceNet communications. The following shows the wiring connections for DeviceNet.

Terminal Reference	CAN Label	Color Chip	Description
HA	V+	Red	DeviceNet network power positive terminal. Connect the red wire of the DeviceNet cable here. If the DeviceNet network does not supply the power, connect to the positive terminal of an external 11-25 Vdc power supply.
HB	CAN_H	White	DeviceNet CAN_H data bus terminal. Connect the white wire of the DeviceNet cable here.
HC	SHIELD	None	Shield/Drain wire connection. Connect the DeviceNet cable shield here. To prevent ground loops, ground the DeviceNet network in only one location.
HD	CAN_L	Blue	DeviceNet CAN_L data bus terminal. Connect the blue wire of the DeviceNet cable here.
HE	V-	Black	DeviceNet network power negative terminal. Connect the black wire of the DeviceNet cable here. If the DeviceNet network does not supply the power, connect to the negative terminal of an external 11-25 Vdc power supply.
HF			Connect to instrument earth


Note:

Power taps are recommended to connect the DC power supply to the DeviceNet trunk line. Power taps include:

- A Schottky Diode to connect the power supply V+ and allows for multiple power supplies to be connected.
- 2 fuses or circuit breakers to protect the bus from excessive current which could damage the cable and connectors.

The earth connection, HF, to be connected to the main supply earth terminal.

4.5.1 Example of Devicenet Wiring



* 121Ω 1% 1/4W terminating resistor must be connected across the blue and white wires at each end of the DeviceNet trunk cable.
Note: this resistor is sometimes included in the master or other devices but should only be switched into circuit on the last device on the trunk cable.

Note:
The DeviceNet network is powered by an external independent 24V supply which is separate from the internal powering of the individual controllers.

The earth connection, HF, to be connected to the main supply earth terminal at one point only.

Figure 13: Wiring connections for 2400 series DeviceNet controllers

4.6 ProfiBus Wiring

Controllers supplied with model numbers 2408*f* and 2404*f* are fitted with ProfiBus communications modules fitted in the H slot. Further details of ProfiBus communications is given in Appendix E and the ProfiBus Communications manual part number HA026290. This manual can be downloaded from www.eurotherm.co.uk.




Figure 14: Profibus wiring example

4.7 Typical wiring diagram

The example shown in Figure 15 is a 2408 heat and cool temperature controller with thermocouple input, logic output driving a solid state relay to provide regulation of power to a heater and triac output driving a cooling solenoid valve.




Figure 15: Typical wiring diagram, model 2408 controller

Safety requirements for permanently connected equipment state:

- A switch or circuit breaker shall be included in the building installation
- It shall be in close proximity to the equipment and within easy reach of the operator
- It shall be marked as the disconnecting device for the equipment.



Note: Note: a single switch or circuit breaker can drive more than one instrument.

For logic output capabilities see section 4.3.

4.8 Motorised Valve connections

Motorised valves will normally be wired either to dual relay, or dual triac, output modules installed in the Module 1 position, or to single channel relay and triac outputs installed in Module positions 1 and 2. In the latter case, the convention is to configure output 1 as the raise output and output 2 as the lower output.

Depending on the configuration, control of the valve is achieved in one of three ways:

1. With no position feedback potentiometer.
2. With a feedback potentiometer used to monitor the valve's position. It does not influence the control.
3. With a feedback potentiometer, where the valve's position is controlled in response to the signal from it.




Figure 16: Motorised valve connections

5. CHAPTER 5 OPERATION

This chapter has nine topics:

- FRONT PANEL LAYOUTS
- BASIC OPERATION
- OPERATING MODES
- AUTOMATIC MODE
- MANUAL MODE
- PARAMETERS AND HOW TO ACCESS THEM
- NAVIGATION DIAGRAM
- PARAMETER TABLES
- ALARMS

5.1 Front Panel Layouts




Figure 17: Model 2408 front panel layout




Figure 18: Model 2404 front panel layout

Button or indicator	Name	Explanation
OP1	Output 1	When lit, it indicates that the output installed in module position 1 is on. This is normally the heating output on a temperature controller.
OP2	Output 2	When lit, it indicates that the output installed in module position 2 is on. This is normally the cooling output on a temperature controller.
SP2	Setpoint 2	When lit, this indicates that setpoint 2, (or a setpoint 3-16) has been selected.
REM	Remote setpoint	When lit, this indicates that a remote setpoint input has been selected. 'REM' will also flash when communications is active.
	Auto/Manual button	When pressed, this toggles between automatic and manual mode: • If the controller is in automatic mode the AUTO light will be lit. • If the controller is in manual mode, the MAN light will be lit. The Auto/Manual button can be disabled in configuration level.
	Run/Hold button	• Press once to start a program (RUN light on.) • Press again to hold a program (HOLD light on) • Press again to cancel hold and continue running (HOLD light off and RUN light ON) • Press and hold in for two seconds to reset a program (RUN and HOLD lights off) The RUN light will flash at the end of a program. The HOLD light will flash during holdback or when a PDS retransmission output is open circuit.
	Page button	Press to select a new list of parameters.
	Scroll button	Press to select a new parameter in a list.
	Down button	Press to decrease a value in the lower readout.
	Up button	Press to increase a value in lower readout.

Figure 19: Controller buttons and indicators

5.2 Basic Operation

Switch on the power to the controller. It runs through a self-test sequence for about three seconds and then shows the measured temperature, or process value, in the upper readout and the target value, called the *setpoint*, in the lower readout. This is called the **Home** display.




Figure 20: Home display

You can adjust the setpoint by pressing the or buttons. Two seconds after releasing either button, the display blinks to show that the controller has accepted the new value.

OP1 will light whenever output 1 is ON. This is normally the heating output when used as a temperature controller.

OP2 will light whenever output 2 is ON. This is normally the cooling output when used as a temperature controller.

Note: You can get back to this display at any time by pressing and together. Alternatively, you will always be returned to this display if no button is pressed for 45 seconds, or whenever the power is turned on.

Alarms

If the controller detects an alarm condition, it flashes an alarm message in the Home display. For a list of all the alarm messages, their meaning and what to do about them, see *Alarms* at the end of this chapter.

5.3 Operating Modes

The controller has two basic modes of operation:

- **Automatic mode** in which the output is automatically adjusted to maintain the temperature or process value at the setpoint.
- **Manual mode** in which you can adjust the output independently of the setpoint.


You toggle between the modes by pressing the AUTO/MAN button. The displays which appear in each of these modes are explained in this chapter.

Two other modes are also available:

- **Remote Setpoint mode**, in which the setpoint is generated from an external source. In this mode, the REM light will be on.
- **Programmer mode** which is explained in Chapter 8, *Programmer Operation*.

5.4 Automatic Mode

You will normally work with the controller in automatic mode. If the MAN light is on, press the AUTO/MAN button to select automatic mode. The AUTO light comes on.



The Home display

Check that the AUTO light is on.

The upper readout shows the measured temperature.

The lower readout shows the setpoint.

To adjust the setpoint up or down, press or .

(Note: If Setpoint Rate Limit has been enabled, then the lower readout will show the active setpoint. If or is pressed, it will change to show and allow adjustment of, the target setpoint.)

Press once.

Display units

A single press of will flash the display units for 0.5 seconds, after which you will be returned to the Home display.

Flashing of the display units may have been disabled in configuration in which case a single press will take you straight to the display shown below.

Press twice

% Output power demand

The % output power demand is displayed in the lower readout. This is a read-only value. You cannot adjust it.

Press and together to return to the Home display.


Press

Pressing from the Output Power display may access further parameters. These may be in this scroll list if the 'Promote' feature has been used (see section 6.3, Edit Level).

When you reach the end of this scroll list, pressing will return you to the Home display.

5.5 Manual mode

If the AUTO light is on, press the AUTO/MAN button to select manual mode. The MAN light comes on



The Home display

Check that the MAN light is on.

The upper readout shows the measured temperature, or process value. The lower readout shows the % output.

To adjust the output, press or .

(Note: If Output Rate Limit has been enabled, then the lower readout will show the working output. If or is pressed, it will change to show and allow adjustment of, the target output.)

Press once.

Display units

A single press of flashes the display units for 0.5 seconds, after which you are returned to the Home display.

Flashing of the display units may have been disabled in configuration, in which case a single press will take you straight to the display shown below.

Press twice.

Setpoint

To adjust the setpoint value, press or .

Press .

Pressing from the Output Power display may access further parameters. These may be in this scroll list if the 'Promote' feature has been used (see section 6.3, *Edit Level*).

When you reach the end of this scroll list, pressing will return you to the **Home** display.

5.6 Parameters and how to access them

Parameters are settings, within the controller, that determine how the controller will operate. For example, alarm setpoints are parameters that set the points at which alarms will occur. For ease of access, the parameters are arranged in lists as shown in the navigation diagram – section 5.8. The lists are:

Home list

Run list

Programming list

Alarm list

Autotune list

PID list

Motor list

Setpoint list

Input list

Output list

Communications list

Information list

Access list.

Each list has a 'List Header' display.

5.6.1 List header displays




Figure 21: Typical list header display

A list header can be recognised by the fact that it always shows 'L, St' in the lower readout. The upper readout is the name of the list. In the above example, 'AL' indicates that it is the Alarm list header. List header displays are read-only.

To step through the list headers, press .

Depending upon how your controller has been configured, a single press may momentarily flash the display units. If this is the case, a double press will be necessary to take you to the first list header. Keep pressing  to step through the list headers, eventually returning you to the Home display.

To step through the parameters within a particular list, press .

When you reach the end of the list, you will return to the list header. From within a list you can return to the current list header at any time can by pressing . To step to the next list header, press  once again.

5.7 Parameter names

In the navigation diagram, each box shows the display for a selected parameter. The Operator parameter tables, later in this chapter, list all the parameter names and their meanings.

The navigation diagram shows all the parameters that can, potentially, be present in the controller. In practice, a limited number of them appear, as a result of the particular configuration.

The shaded boxes in the diagram indicate parameters that are hidden in normal operation. To view all the available parameters, you must select Full access level. For more information about this, see Chapter 6, Access Levels.

5.7.1 Parameter displays




Figure 22: Typical parameter display

Parameter displays show the controller's current settings. The layout of parameter displays is always the same: the upper readout shows the parameter name and the lower readout its value. In the above example, the parameter name is *IFSL* (indicating *Alarm 1, full scale low*), and the parameter value is *10.0*.

5.7.2 To change the value of a parameter

First, select the required parameter.

To change the value, press either  or . During adjustment, single presses change the value by one digit. Keeping the button pressed speeds up the rate of change.

Two seconds after releasing either button, the display blinks to show that the controller has accepted the new value.

5.8 Navigation Diagram

(Part A)

(The parameters that appear depend upon how the controller has been configured).




Figure 23: Navigation diagram (Part A)

Navigation Diagram (Part B)




Figure 23 Navigation diagram (Part B)

5.8.1 Parameter tables

Name	Description
Home list	
Home	Measured value and Setpoint
OP	% Output level
SP	Target setpoint (if in Manual mode)
m-A	Auto-man select
AmPS	Heater current (With PDSIO mode 2)
C _d	Customer defined identification number
+ Extra parameters, if the 'Promote' feature has been used (see section 6.3, <i>Edit Level</i>).	

run	Program run list – Present only in setpoint programming controllers
PrG	Active program number (Only on 4, or 20, program versions)
StAt	Program status (OFF, run, hold, HbAc, End)
PSP	Programmer setpoint
CYC	Number of cycles remaining in the program
SEG	Active segment number
StYP	Active segment type
SEGL	Segment time remaining in the segment units
EGE	Target setpoint
rAtE	Ramp rate (if a rate segment)
PrGL	Program time remaining in hours
FASt	Fast run through program (no / YES)
outn	Event output states (OFF / on) (not 8-segment programmer)
Sync	Segment synchronisation (no / YES) (not 8-segment programmer)
SEGLd	Flash active segment type in the lower readout of the home display (no / YES)

Name	Description
Prog	Program edit list – Present only in setpoint programming controller. For an explanation of these parameters refer to Chapter 8
PrGn	Select program number (Only on 4, or 20, program versions)
Hb	Holdback type for the program as a whole (if configured) (OFF, Lo, Hi, or bAnd)
Hb U	Holdback value (in display units)
rmpU	Ramp units (SEc, mIn, or Hour) [for both rmp _r and rmp _t type segments]
dwLU	Dwell units (SEc, mIn, or Hour)
CYCn	Number of program cycles (1 to 999, or 'cont')
SEGLn	Segment number
TYPE	Segment type: (End) (rmp _r =ramp rate) (rmp _t =ramp time) (dwEl) (STEP) (cALL)
The following parameters depend on the TYPE selected, as shown below.	
	End rmp _r rmp _t dwEl STEP cALL
Hb	Holdback type: OFF, Lo, Hi, or bAnd
EGE	Target setpoint for a 'rmp' or 'STEP' segment
rAtE	Ramp rate for a 'rmp _r ' segment
dur	'dwEl' time / Time to target for a 'rmp _t ' segment
PrGn	cALLed Program number
CYCn	No. of cycles of cALLed program
outn	Event output: OFF/on (not 8-segment programmer)
SynC	Segment synchronisation: no/YES (not 8-seg progr)
Endt	End of prog – dwEl, STEP, STOP

Name	Description
------	-------------

AL	Alarm list
1---	Alarm 1 setpoint value
2---	Alarm 2 setpoint value
3---	Alarm 3 setpoint value
4---	Alarm 4 setpoint value
<i>In place of dashes, the last three characters indicate the alarm type. See alarm types table:</i>	
HY 1	Alarm 1 Hysteresis (display units)
HY 2	Alarm 2 Hysteresis (display units)
HY 3	Alarm 3 Hysteresis (display units)
HY 4	Alarm 4 Hysteresis (display units)
Lb t	Loop Break Time in minutes
d, AG	Enable Diagnostic alarms 'no' / 'YES'
Alarm types table	
-FSL	PV Full scale low alarm
-FSH	PV Full scale high alarm
-dEu	PV Deviation band alarm
-dHi	PV Deviation high alarm
-dLo	PV Deviation low alarm
-LCr	Load Current low alarm
-HCr	Load Current high alarm
-FL2	Input 2 Full Scale low alarm
-FH2	Input 2 Full Scale high alarm
-LOP	Working Output low alarm
-HOP	Working Output high alarm
-LSP	Working Setpoint low alarm
-HSP	Working Setpoint high alarm
4rAL	Rate of change alarm (AL 4 only)

Autun	Autotune list
tunE	One-shot autotune enable
drA	Adaptive tune enable
drAL	Adaptive tune trigger level in display units. Range = 1 to 9999
Rdc	Automatic Droop Compensation (PD control only)

Name	Description
------	-------------

P, d	PID list
GSP	If Gain Scheduling has been enabled (see section 7.6), this parameter sets the PV below which 'P, d, 1' is active and above which 'P, d, 2' is active.
SEt	'P, d, 1' or 'P, d, 2' selected
Pb	Proportional Band (SEt 1) (in display units)
t, 1	Integral Time in secs (SEt 1)
t, d	Derivative Time in secs (SEt 1)
rES	Manual Reset (%) (SEt 1)
Hcb	Cutback High (SEt 1)
Lcb	Cutback Low (SEt 1)
rEL 1	Relative Cool Gain (SEt 1)
Pb2	Proportional Band (SEt 2)
t, 2	Integral Time in secs (SEt 2)
t, d2	Derivative Time in secs (SEt 2)
rES2	Manual Reset (%) (SEt 2)
Hcb2	Cutback High (SEt 2)
Lcb2	Cutback Low (SEt 2)
rEL 2	Relative Cool Gain (SEt 2)
<i>The following three parameters are used for cascade control. If this facility is not being used, then they can be ignored.</i>	
FFPb	SP, or PV, feedforward propband
FFtr	Feedforward trim %
FFdu	PID feedforward limits ± %

mEr	Motor list – see also Figure 29
t, m	Valve travel time in seconds
I n, t	Valve inertia time in secs
bACt	Valve backlash time in secs
mPE	Minimum ON time of output pulse
Ubr	Valve sensor break strategy

Name	Description
SP	Setpoint list
SSEL	Select SP 1 to SP 16 , depending on configuration
L-r	Local (Loc) or remote (rmL) setpoint select
SP 1	Setpoint one value
SP 2	Setpoint two value
rmSP	Remote setpoint value
rmL	Remote setpoint trim
rAL	Ratio setpoint
LocL	Local setpoint trim
SP L	Setpoint 1 low limit
SP H	Setpoint 1 high limit
SP2L	Setpoint 2 low limit
SP2H	Setpoint 2 high limit
SPrr	Setpoint Rate Limit
HbLY	Holdback Type for setpoint rate limit (OFF , Lo , Hi , or band)
Hb	Holdback Value for setpoint rate limit in display units. (HbLY ≠ OFF)

P	Input list
F1L	IP1 filter time constant (0.0 - 999.9 seconds).
F2L	IP2 filter time constant (0.0 - 999.9 seconds).
HiJP LoJP	Transition of control between P1 and P2 . (if configured) The transition region is set by the values of LoJP and HiJP . PV = P1 below LoJP PV = P2 above HiJP
F1 F2	Derived function, (if configured) $PV = (F1 \times P1) + (F2 \times P2)$. F1 and F2 are scalars with the range -9.99 to 10.00
PUP	Selects P1 or P2

The next 3 parameters appear if User Calibration has been enabled. (Refer to Chapter 10.) By default they are hidden when in Operator level. To prevent unauthorised adjustment, we recommend that they are only made available in **FULL** access level.

CAL	'FACT' - reinstates the factory calibration and disables User calibration. Next 2 parameters will not appear. 'USER' - reinstates any previously set User calibration. All parameters below now appear.
CALS	Selected calibration point - 'nonE' , P1L , P1H , P2L , P2H
Adj*	User calibration adjust, if CALS = P1L , P1H , P2L , P2H
DFS1	IP1 calibration offset
DFS2	IP2 calibration offset
mU1	IP1 measured value (at terminals)
mU2	IP2 measured value (at terminals), if DC input in Module 3 position
CJC1	IP1 cold junction temp. reading
CJC2	IP2 cold junction temp. reading
L1	IP1 linearised value
L2	IP2 linearised value
PUSL	Shows the currently selected PV input - P1 or P2

* Do not make adjustments using the **Adj** parameter unless you wish to change the controller calibration.

OP	Output list
Does not appear if Motorised Valve control configured.	
OPLo	Low power limit (%)
OPHi	High power limit (%)
OPrr	Output Rate Limit (% per sec)
FOP	Forced output level (%)
CYCH	Heat cycle time (0.2S to 999.9S)
HYSH	Heat hysteresis (display units)
onEH	Heat output min. on-time (secs) Auto (0.05S), or 0.1 - 999.9S
CYCL	Cool cycle time (0.2S to 999.9S)
HYSL	Cool hysteresis (display units)
onEL	Cool output min. on-time (secs) Auto (0.05S), or 0.1 - 999.9S
HCdb	Heat/cool deadband (display units)
EndP	To set power level in end segment
SbOP	Sensor Break Output Power (%)

cmS	Comms list
Addr	Communications Address

cmS	DeviceNet (additional parameters)
NetSt	Indicates network status
run	Network connected and operational
rdy	Network connected but not operational
OFFL	Network not connected

Info	Information list
diSP	Configure lower readout of Home display to show: UPoS Valve position Std Standard - display setpoint AmPS Load current in amps OP Output StAL Program status PrGL Program time remaining in hours L2 Process value 2 rAL Ratio setpoint PrG Selected program number rSP Remote setpoint
LoGL	PV minimum
LoGH	PV maximum
LoGA	PV mean value
LoGE	Time PV above Threshold level
LoGU	PV Threshold for Timer Log

Name	Description
------	-------------

Info	Information list - <i>continued</i>
rESL	Logging Reset - 'YES/no'
<i>The following set of parameters is for diagnostic purposes.</i>	
wOP	Working output
FFOP	Feedforward component of output
VO	PID output to motorised valve

ACCESS	Access List
codE	Access password
Goto	Goto level - OPER , FULL , Edit or conf
Conf	Configuration password

5.9 Alarms

5.9.1 Alarm annunciation

Alarms are flashed as messages in the Home display. A new alarm is displayed as a double flash followed by a pause, old (acknowledged) alarms as a single flash followed by a pause. If there is more than one alarm condition, the display cycles through all the relevant alarm messages. Figure 24: Process Alarms and Figure 25: Diagnostic Alarms list all of the possible alarm messages and their meanings.

5.9.2 Alarm acknowledgement and resetting

Pressing both  and  at the same time will acknowledge any new alarms and reset any latched alarms.

5.9.3 Alarm modes

Alarms will have been set up to operate in one of several modes, either:

- **Non-latching**, which means that the alarm will reset automatically when the Process Value is no longer in the alarm condition.
- **Latching**, which means that the alarm message will continue to flash even if the alarm condition no longer exists and will only clear when reset.
- **Blocking**, which means that the alarm will only become active after it has first entered a safe state on power-up.

5.9.4 Alarm types

There are **two** types of alarm: **Process alarms** and **Diagnostic alarms**.

Process alarms

These warn that there is a problem with the process which the controller is trying to control.

Alarm Display	What it means	Alarm Display	What it means
<u>F</u> SL*	PV Full Scale Low alarm	<u>F</u> L2*	Input 2 Full Scale Low alarm
<u>F</u> SH*	PV Full Scale High alarm	<u>F</u> H2*	Input 2 Full Scale High alarm
<u>d</u> Ev*	PV Deviation Band alarm	<u>L</u> OP*	Working Output Low alarm
<u>d</u> H*	PV Deviation High alarm	<u>H</u> OP*	Working Output High alarm
<u>d</u> Lo*	PV Deviation Low alarm	<u>L</u> SP*	Working Setpoint Low alarm
<u>L</u> Cr*	Load Current Low alarm	<u>H</u> SP*	Working Setpoint High alarm
<u>H</u> Cr*	Load Current High alarm	<u>4</u> rAL	PV Rate of change alarm <i>Always assigned to Alarm 4</i>

* In place of the dash, the first character will indicate the alarm number.

Figure 24: Process Alarms

5.9.5 Diagnostic alarms

These indicate that a fault exists in either the controller or the connected devices.

Display shows	What it means	What to do about it
EEEr	<i>Electrically Erasable Memory Error:</i> The value of an operator, or configuration, parameter has been corrupted.	This fault will automatically take you into Configuration level. Check all of the configuration parameters before returning to Operator level. Once in Operator level, check all of the operator parameters before resuming normal operation. If the fault persists, or occurs frequently, contact your supplier
S.br	<i>Sensor Break:</i> Input sensor is unreliable or the input signal is out of range.	Check that the sensor is correctly connected.
L.br	<i>Loop Break</i> The feedback loop is open circuit.	Check that the heating and cooling circuits are working properly.
LdF	<i>Load failure</i> Indication that there is a fault in the heating circuit or the solid state relay.	This is an alarm generated by feedback from a TE10S solid state relay (SSR) operating in PDS mode 1 - see Chapter 4, <i>Electrical Installation</i> . It indicates either an open or short circuit SSR, blown fuse, missing supply or open circuit heater.

SSrF	<i>Solid state relay failure</i> Indication that there is a fault in the solid state relay.	This is an alarm generated by feedback from a TE10S solid state relay (SSR) operating in PDSIO mode 2 - see Chapter 4, <i>Electrical Installation</i> . It indicates either an open or short circuit condition in the SSR.
HtrF	<i>Heater failure</i> Indication that there is a fault in heating circuit.	This is an alarm generated by feedback from a TE10S solid state relay (SSR) operating in PDSIO mode 2 - see Chapter 4, <i>Electrical Installation</i> . It indicates either a blown fuse, missing supply, or open circuit heater.
CTOP	<i>Current Transformer Open Circuit</i>	Indicates that the PDS input is open circuit. Mode 5 only
CTSh	<i>Current Transformer Short Circuit</i>	Indicates that the PDS input is short circuit Mode 5 only
HwEr	<i>Hardware error</i> Indication that a module is of the wrong type, missing, or faulty.	Check that the correct modules are fitted.
no i o	<i>No I/O</i> None of the expected I/O modules is fitted.	This error message normally occurs when pre-configuring a controller without installing any of the required I/O modules.
rmtrF	<i>Remote input failure.</i> Either the PDSIO input, or the remote DC input, is open or short circuit	Check for open, or short circuit wiring on the PDSIO, or remote DC, input.
LLLL	<i>Out of range low reading</i>	Check the value of the input.
HHHH	<i>Out of range high reading</i>	Check the value of the input.
Err1	<i>Error 1: ROM self-test fail</i>	Return the controller for repair.
Err2	<i>Error 2: RAM self-test fail</i>	Return the controller for repair.
Err3	<i>Error 3: Watchdog fail</i>	Return the controller for repair.
Err4	<i>Error 4: Keyboard failure</i> Stuck button, or a button was pressed during power up.	Switch the power off and then on, without touching any of the controller buttons.
Err5	<i>Error 5: Faulty internal communications.</i>	Check printed circuit board interconnections. If the fault cannot be cleared, return the controller for repair.
Err6	Digital filter chip faulty or loose board inside controller	Return the controller for repair.
Err7	PV id failure/PSU failure	Return the controller for repair.
Err8	Module 1 id error	Faulty or loose module or may be isolation problem
Err9	Module 2 id error	Faulty or loose module or may be isolation problem
ErrA	Module 3 id error	Faulty or loose module or may be isolation problem
dCF	DC output fail	Return the controller for repair
tunEr	Tune error – shown if any one stage of the auto-tuning process exceeds two hours	Check response time of process: check that the sensor has not failed: check that the loop is not broken. Acknowledge by pressing 'page' key and 'scroll' key together
Pbr	Potentiometer break	Check that the feedback potentiometer is correctly connected or the pot is not open circuit

Figure 25: Diagnostic Alarms

6. CHAPTER 6 ACCESS LEVELS

This chapter describes the different levels of access to the operating parameters within the controller.

There are three topics:

- The different access levels
- Selecting an access level
- Edit level

6.1 THE DIFFERENT ACCESS LEVELS

There are four access levels:

- **Operator level**, which you will normally use to operate the controller.
- **Full level**, which is used to commission the controller.
- **Edit level**, which is used to set up the parameters that you want an operator to be able to see and adjust when in Operator level.
- **Configuration level**, which is used to set up the fundamental characteristics of the controller.


Access level	Display shows	What you can do	Password Protection
Operator	<i>OPER</i>	In this level, operators can view and adjust the value of parameters defined in Edit level (section 6.3).	No
Full	<i>FULL</i>	In this level, all the parameters relevant to a particular configuration are visible. All alterable parameters may be adjusted.	Yes
Edit	<i>Edi t</i>	In this level, you can determine which parameters an operator is able to view and adjust in Operator level. You can hide, or reveal, complete lists, individual parameters within each list and you can make parameters read-only or alterable. (See Edit level section 6.3).	Yes
Configuration	<i>conF</i>	This special level allows access to set up the fundamental characteristics of the controller.	Yes

Figure 26: Access levels

6.2 SELECTING AN ACCESS LEVEL

Access to Full, Edit or Configuration levels is protected by a password to prevent unauthorised access.

If you need to change the password, see Chapter 9, *Configuration*.



Access list header

Press until you reach the access list header 'ACCESS'.

Press .

Password entry

The password is entered from the 'code' display.

Enter the password using or . Once the correct password has been entered, there is a two second delay after which the lower readout will change to show 'PASS' indicating that access is now unlocked.

The pass number is set to '1' when the controller is shipped from the factory.

(A special case exists if the password has been set to '0'. In this case access will be permanently unlocked and the lower readout will always show 'PASS').

Press to proceed to the 'Goto' page.

(If an *incorrect* password has been entered and the controller is still 'locked' then pressing returns you to the 'ACCESS' list header.)

Level selection

The 'Goto' display allows you to select the required access level.

Use and to select from the following display codes:

- OPER: Operator level
- FULL: Full level
- Edit: Edit level
- CONF: Configuration level

Access to Read-only Configuration

From the 'ACCESS' list display, press to 'code'. Then press and together will take you into Read-Only Configuration without entering a password. This will allow you to view all of the configuration parameters, but not adjust them. If no button is pressed for ten seconds, you will be returned to the Home display. Alternatively, pressing and together takes you immediately back to the Home display

Press .

If you selected either 'OPER', 'FULL' or 'Edit' level you will be returned to the 'ACCESS' list header in the level that you chose. If you selected 'CONF', you will get a display showing 'CONF' in the upper readout (see below).

Configuration password

When the 'CONF' display appears, you must enter the Configuration password in order to gain access to this level. Do this by repeating the password entry procedure described in the previous section.

The configuration password is set to '2' when the controller is shipped from the factory. If you need to change the configuration password, see Chapter 9, *Configuration*.

Press .

Configuration level

The first display of configuration is shown. See Chapter 9, *Configuration*, for details of the configuration parameters.

6.3 Edit level

Edit level is used to set which parameters you can view and adjust in Operator level. It also gives access to the 'Promote' feature, which allows you to select and add ('Promote') up to twelve parameters into the Home display list, thereby giving simple access to commonly used parameters.

6.3.1 Setting operator access to a parameter

First you must select **Edi t** level, as shown on the previous page.

Once in **Edi t** level, you select a list, or a parameter within a list, in the same way as you would in Operator, or Full, level – that is to say, you move from list header to list header by pressing , and from parameter to parameter within each list using .


However, in Edit level what is displayed is not the value of a selected parameter, but a code representing that parameter's availability in Operator level.

When you have selected the required parameter, use  and  buttons to set its availability in Operator level.

There are four codes:

- **ALtr** Makes a parameter alterable in Operator level.
- **Pr0** Promotes a parameter into the Home display list.
- **rEAd** Makes a parameter, or list header, read-only (*it can be viewed but not altered*).
- **Hi dE** Hides a parameter, or list header.

For example:



The parameter selected is Alarm 2, Full Scale Low

It will be alterable in Operator level

6.3.2 Hiding or revealing a complete list

To hide a complete list of parameters, all you have to do is hide the list header. If a list header is selected, only two selections are available: **rEAd** and **Hi dE**.

(It is not possible to hide the 'ALCS' list, which always displays the code: 'Li St'.)

6.3.3 Promoting a parameter

Scroll through the lists to the required parameter and choose the **Pr0** code. The parameter is then automatically added (promoted) into the Home display list. (The parameter will also be accessible, as normal, from the standard lists.) A maximum of twelve parameters can be promoted. Promoted parameters are automatically 'alterable'.

Please note, in the '**Pr0G Li St**', the parameters from segment number (**SEG.n**) onwards *cannot* be promoted.

6.4 Returning to Operator Level

To return to operator level from either '**FULL**' or '**Edi t**' level, repeat entry of the password and select '**OPER**' on the '**Go to**' display.

In '**Edi t**' level, the controller will automatically return to operator level if no button is pressed for 45 seconds.

7. CHAPTER 7 TUNING

Before tuning, please read Chapter 5, *Operation*, to learn how to select and change a parameter.

This chapter has five topics:

- WHAT IS TUNING?
- AUTOMATIC TUNING
- MANUAL TUNING
- COMMISSIONING OF MOTORISED VALVE CONTROLLERS
- GAIN SCHEDULING

7.1 What Is Tuning?

In tuning, you match the characteristics of the controller to those of the process being controlled in order to obtain good control. Good control means:

- Stable, 'straight-line' control of the temperature at setpoint without fluctuation
- No overshoot, or undershoot, of the temperature setpoint
- Quick response to deviations from the setpoint caused by external disturbances, thereby rapidly restoring the temperature to the setpoint value.

Tuning involves calculating and setting the value of the parameters listed in the table below. These parameters appear in the '*P, d*' list.

Parameter	Code	Meaning or Function
Proportional band	<i>Pb</i>	The bandwidth, in display units, over which the output power is proportioned between minimum and maximum.
Integral time	<i>t_i</i>	Determines the time taken by the controller to remove steady-state error signals.
Derivative time	<i>t_d</i>	Determines how strongly the controller will react to the rate-of-change of the measured value.
High Cutback	<i>Hcb</i>	The number of display units, above setpoint, at which the controller will increase the output power, in order to prevent undershoot on cool down.
Low cutback	<i>Lcb</i>	The number of display units, below setpoint, at which the controller will cutback the output power, in order to prevent overshoot on heat up.
Relative cool gain	<i>rEL</i>	Only present if cooling has been configured and a module is fitted. Sets the cooling proportional band, which equals the <i>Pb</i> value divided by the <i>rEL</i> value.

Figure 27: Tuning parameters

7.2 AUTOMATIC TUNING

Two automatic tuning methods are provided in the 2408 and 2404:

- **A one-shot tuner**, which automatically sets up the initial values of the parameters listed in Figure 27 on the previous page.
- **Adaptive tuning**, which continuously monitors the error from setpoint and modifies the PID values, if necessary.

7.2.1 One-shot Tuning

The 'one-shot' tuner works by switching the output on and off to induce an oscillation in the measured value. From the amplitude and period of the oscillation, it calculates the tuning parameter values.

If the process cannot tolerate full heating or cooling being applied during tuning, then the level of heating or cooling can be restricted by setting the heating and cooling power limits in the '**oP**' list. However, the measured value *must* oscillate to some degree for the tuner to be able to calculate values.

A One-shot Tune can be performed at any time, but normally it is performed only once during the initial commissioning of the process. However, if the process under control subsequently becomes unstable (because its characteristics have changed), you can re-tune again for the new conditions.


It is best to start tuning with the process at ambient temperature. This allows the tuner to calculate more accurately the low cutback and high cutback values which restrict the amount of overshoot, or undershoot.

7.2.2 How to tune

1. Set the setpoint to the value at which you will normally operate the process.
2. In the '**Autune**' list, select '**tune**' and set it to '**on**'.
3. Press the Page and Scroll buttons together to return to the Home display. The display will flash '**tune**' to indicate that tuning is in progress.
4. The controller induces an oscillation in the temperature by first turning the heating on, and then off. The first cycle is not complete until the measured value has reached the required setpoint.
5. After two cycles of oscillation the tuning is completed and the tuner switches itself off.
6. The controller then calculates the tuning parameters listed in Figure 27 and resumes normal control action.

If you want 'Proportional only', 'PD', or 'PI' control, you should set the '**t_p**' or '**t_d**' parameters to **OFF** before commencing the tuning cycle. The tuner will leave them off and will not calculate a value for them.

7.3 Typical automatic tuning cycle



7.3.1 Calculation of the cutback values

Low cutback and *High cutback* are values that restrict the amount of overshoot, or undershoot, that occurs during large step changes in temperature (for example, under start-up conditions).

If either low cutback, or high cutback, is set to '**Auto**' the values are fixed at three times the proportional band, and are not changed during automatic tuning.

7.3.2 Adaptive tune

Adaptive tuning is a background algorithm, which continuously monitors the error from setpoint and analyses the control response during process disturbances. If the algorithm recognises an oscillatory, or under-damped, response it recalculates the **Pb**, **t_p** and **t_d** values.

Adaptive tune is triggered whenever the error from setpoint exceeds a trigger level. This trigger level is set in the parameter '**drAut**', which is found in the Autotune list. The value is in display units. It is automatically set by the controller, but can also be manually re-adjusted.

Adaptive tune should be used with:

1. Processes whose characteristics change as a result of changes in the load, or setpoint.
2. Processes that cannot tolerate the oscillation induced by a One-shot tune.

Adaptive tune should not be used:

1. Where the process is subjected to regular external disturbances that could mislead the adaptive tuner.
2. On highly interactive multiloop applications. However, moderately interactive loops, such as multi-zone extruders, should not give a problem.

7.4 MANUAL TUNING

If for any reason automatic tuning gives unsatisfactory results, you can tune the controller manually. There are a number of standard methods for manual tuning. The one described here is the Ziegler-Nichols method.

With the process at its normal running temperature:

1. Set the Integral Time ' t_i ' and the Derivative Time ' t_d ' to **OFF**.
2. Set High Cutback and Low Cutback, ' H_{cb} ' and ' L_{cb} ', to **Auto**.
3. Ignore the fact that the temperature may not settle precisely at the setpoint.
4. If the temperature is stable, reduce the proportional band ' P_b ' so that the temperature just starts to oscillate. If the temperature is already oscillating, increase the proportional band until it just stops oscillating. Allow enough time between each adjustment for the loop to stabilise. Make a note of the proportional band value ' B ' and the period of oscillation ' T '.
5. Set the P_b , t_i , t_d parameter values according to the calculations given in the table below.

Type of control	Proportional band ' P_b '	Integral time ' t_i '	Derivative time ' t_d '
Proportional only	$2 \times B$	OFF	OFF
P + I control	$2.2 \times B$	$0.8 \times T$	OFF
P + I + D control	$1.7 \times B$	$0.5 \times T$	$0.12 \times T$

Figure 28: Tuning values

7.4.1 Setting the cutback values


The above procedure sets up the parameters for optimum steady state control. If unacceptable levels of overshoot or undershoot occur during start-up, or for large step changes in temperature, then manually set the cutback parameters ' L_{cb} ' and ' H_{cb} '.

Proceed as follows:


1. Set the low and high cutback values to three proportional bandwidths (that is to say, $L_{cb} = H_{cb} = 3 \times P_b$).
2. Note the level of overshoot, or undershoot, that occurs for large temperature changes (see the diagrams below).

In example (a) increase ' L_{cb} ' by the overshoot value. In example (b) reduce ' L_{cb} ' by the undershoot value.

Example (a)



Example (b)



Where the temperature approaches setpoint from above, you can set ' H_{cb} ' in a similar manner.

7.4.2 Integral action and manual reset

In a full three-term controller (that is, a PID controller), the integral term 'ti' automatically removes steady state errors from the setpoint. If the controller is set up to work in two-term mode (that is, PD mode), the integral term will be set to 'OFF'. Under these conditions the measured value may not settle precisely at setpoint. When the integral term is set to 'OFF' the parameter *manual reset* (code 'rES') appears in the 'P, dL, St' in 'FULL' level. This parameter represents the value of the power output that will be delivered when the error is zero. You must set this value manually in order to remove the steady state error.

7.4.3 Automatic droop compensation (Adc)

The steady state error from the setpoint, which occurs when the integral term is set to 'OFF', is sometimes referred to as 'droop'. 'Adc' automatically calculates the manual reset value in order to remove this droop. To use this facility, you must first allow the temperature to stabilise. Then, in the autotune parameter list, you must set 'Adc' to 'cALC'. The controller will then calculate a new value for manual reset, and switch 'Adc' to 'mAn'.

'Adc' can be repeated as often as you require, but between each adjustment you must allow time for the temperature to stabilise.

7.4.4 Tune Error

If any one stage of the automatic tuning process is not completed within two hours a diagnostic alarm will occur. The display shows **tUEr** - Tune Error.

This alarm could occur if:

1. The process to be tuned has a very slow response time
2. The sensor has failed or is incorrectly aligned
3. The loop is broken or not responding correctly

7.5 Motorised Valve Control

The 2408 and 2404 can be configured for motorised valve control as an alternative to the standard PID control algorithm. This algorithm is designed specifically for positioning motorised valves.

These are ordered pre-configured as Model numbers:

- 2408/VC and 2404/VC motorised valve controllers
- 2408/VP and 2404/VP motorised valve controllers with a single setpoint programmer
- 2408/V4 and 2404/V4 motorised valve controllers storing four setpoint programs.
- 2408/VM and 2404/VM motorised valve controllers storing twenty setpoint programs.

Section 4.8 shows how to connect a motorised valve controller. The control is performed by delivering open, or close, pulses in response to the control demand signal.

The motorised valve algorithm can operate in one of three ways:

1. The so-called *boundless* mode, which does not require a position feedback potentiometer for control purposes; although one can be connected and used purely to display the valve's position.
2. Bounded, (or *position*), control mode, which requires a feedback potentiometer. This is closed-loop control determined by the valve's position.

The desired control mode is selected in the '*ns*' list in configuration level.

The following parameter list will appear in the navigation diagram shown in Chapter 5, if your controller is configured for motorised valve control.

Name	Description	Values		
<i>mlr</i>	Motor list	Min	Max	Default
<i>tm</i>	Valve travel time in seconds. This is the time taken for the valve to travel from its fully closed position to its fully open position.	0.1	2400	300
<i>int</i>	Valve inertia time in seconds. This is the time taken for the valve to stop moving after the output pulse is switched off.	OFF	200	OFF
<i>brct</i>	Valve backlash time in seconds. This is the minimum on-time required to reverse the direction of the valve. i.e. the time to overcome the mechanical backlash.	OFF	200	OFF
<i>mp</i>	Output pulse minimum on-time, in seconds.	Auto	1000	Auto
<i>ubr</i>	Valve sensor break strategy.	reset, up, down		reset

Figure 29: Motorised valve parameter list

7.5.1 Commissioning the Motorised Valve Controller

The commissioning procedure is the same for both bounded and boundless control modes, except in bounded mode you must first calibrate the position feedback potentiometer, as described in the section below.

Proceed as follows:

1. Measure the time taken for the valve to be raised from its fully closed to its fully open position and enter this as the value in seconds into the '*tm*' parameter.
2. Set all the other parameters to the default values shown in Figure 29.

The controller can then be tuned using any of the automatic, or manual, tuning procedures described earlier in this chapter. As before, the tuning process, either automatic or manual, involves setting the values of the parameters in Figure 27. The only difference with boundless control is that the derivative term '*td*', although present, will have no effect.

7.5.2 Adjusting the minimum on-time 'mP_L'

The default value of 0.2 seconds is satisfactory for most processes. If, however, after tuning the process, the valve activity is excessively high, with constant oscillation between raise and lower pulses, the minimum on-time can be increased.

The minimum on-time determines how accurately the valve can be positioned and therefore the control accuracy. The shorter the time, the more precise the control. However, if the time is set too short, process noise will cause an excessively busy valve.

7.5.3 Inertia and backlash settings

The default values are satisfactory for most processes, i.e. 'OFF'.

Inertia is the time taken for the valve to stop after the output pulse is turned off. If this causes a control problem, the inertia time needs to be determined and then entered into the parameter, 'I_nL'. The inertia time is subtracted from the raise and lower output pulse times, so that the valve moves the correct distance for each pulse.

Backlash is the output pulse time required to reverse the direction of the valve, i.e. the time taken to overcome the mechanical backlash of the linkages. If the backlash is sufficient to cause a control problem, then the backlash time needs to be determined and then entered into the parameter, 'bA_CL'.

The above two values are not part of the automatic tuning procedure and must be entered manually.

7.5.4 Calibrating the Position Feedback Potentiometer

Before proceeding with the feedback potentiometer calibration, you should ensure, in configuration level, that module position 2 (2A), or 3 (3A), has its 'd' indicating 'P_oL', (meaning *Potentiometer Input*). Continue to scroll down the module configuration list. 'Func' should be set to 'UP_oS', 'U_AL_L' must be set to '0' and 'U_AL_H' to '100'.

Exit from configuration and you are now ready to calibrate the position feedback potentiometer. Proceed as follows.


1. In Operator level, press the AUTO/MAN button to put the controller in Manual mode.
2. Drive the valve to its fully open position using .
3. Press  until you get to 'P-L, St'.
4. Press  to get to 'PCAL-OFF'.
5. Press  or  to turn 'PCAL' to 'on'.
6. Press  and the upper readout indicates 'P_oL'.
7. Press  or  to get to 'P_oL-3A_H'. (Assuming that the Potentiometer Input Module is in module position 3.)
8. Press  to go to 'CO-no'.
9. Press  or  to see 'CO-YES', which starts the calibration procedure.
10. Calibration is complete when the display returns to 'CO-no'.
11. Press  and  together to return directly to the Operator level.
12. The controller should still be in Manual mode.
13. Drive the valve to its fully closed position using .
14. Press  until you get to 'P-L, St'.
15. Press  to get to 'PCAL-OFF'.
16. Press  or  to turn 'PCAL' to 'on'.
17. Press  and the upper readout indicates 'P_oL'.
18. Press  or  to get to 'P_oL-3A_L'.
19. Press  to go to 'CO-no'.
20. Press  or  to see 'CO-YES', which starts the calibration procedure.
21. Calibration is complete when the display returns to 'CO-no'.
22. Press  and  together to return directly to the Operator level.
23. Press the AUTO/MAN button to place the controller in AUTO and the calibration of the position feedback potentiometer is now complete.

7.6 Gain scheduling

Gain scheduling is the automatic transfer of control between one set of PID values and another. In the case of the 2408 and 2404 controllers, this is done at a presettable process value. It is used for the more difficult to control processes which exhibit large changes in their response time or sensitivity at, for example, high and low temperatures, or when heating or cooling.


The 2408 and 2404 has two sets of PID values. You can select the active set from either a digital input, or from a parameter in the PID list, or you can transfer automatically in gain scheduling mode. The transfer is bumpless and will not disturb the process being controlled.

To use gain scheduling, follow the steps below:



Step1: Enable in configuration level

Gain scheduling must first be enabled in Configuration level. Goto the *Inst Conf* list, select the parameter *Gsch*, and set it to *YES*.



Step 2: Set the transfer point

Once gain scheduling has been enabled, the parameter *GSP* will appear at the top of the *Pid* list in *FULL* access level. This sets the value at which transfer occurs. PID1 will be active when the process value is below this setting and PID2 when the process value is above it. The best point of transfer depends on the characteristics of the process. Set a value between the control regions that exhibit the greatest change.

Step 3: Tuning

You must now set up the two sets of PID values. The values can be manually set, or automatically tuned as described earlier in this chapter. When tuning automatically you must tune twice, once above the switching point *GSP* and again below the switching point. When tuning, if the process value is below the transfer point *GSP* the calculated values will automatically be inserted into PID1 set and if the process value is above *GSP*, the calculated values will automatically be inserted into PID2 set.

8. CHAPTER 8 PROGRAMMER OPERATION

This chapter deals with the setpoint programming option. All 2408 / 2404 instruments have a basic 8-segment programmer built-in as standard. This facility must be enabled by the user, as explained in the section, *Configuring the Programmer*.

Other programmer versions are listed below, and have 16-segments in each program.

16-segment programmer with:

a single program:	Models 2408/CP and 2404/CP.
four stored programs:	Models 2408/P4 and 2404/P4.
twenty stored programs:	Models 2408/CM and 2404/CM.

16-segment Motorised Valve programmer with:

a single program:	a single program: Models 2408/VP and 2404/VP.
four stored programs:	four stored programs: Models 2408/V4 and 2404/V4
twenty stored programs:	twenty stored programs: Models 2408/VM and 2404/VM.

The 8-segment programmer differs from the other programmers in that it will not provide event outputs and program synchronisation. Otherwise they all operate in the same way.

There are eight topics:

- What is setpoint programming?
- Programmer states
- Running a program from the Run list
- Running a program using the Run/Hold button
- Automatic behaviour
- Configuring the programmer
- configuring digital inputs to select program number
- Creating a new program, or MODIFYING an existing program.

To understand how to select and change parameters in this chapter you need to have read Chapter 5, *Operation* and Chapter 6, *Access Levels*.

8.1 What is setpoint programming?

Many applications need to vary temperature, or process value, with time. Such applications need a controller which varies a setpoint as a function of time; all 2408 and 2404 models can do this.

The setpoint is varied by using a *setpoint program*. Within each 2408 and 2404 controller, there is a software module called *the programmer*, which stores one, or more, such programs and drives the setpoint according to the selected program. The program is stored as a series of 'ramp' and 'dwell' segments, as shown below.




Figure 30: Setpoint profile

(If the 8-segment programmer is being used, then the information in the next paragraph does **not** apply.)

In each segment you can define the state of up to eight (8) digital outputs, each of which can be used to trigger external events. These are called *event outputs* and can drive either relay, logic, or triac outputs, depending on the modules installed.

A program is executed either, once, repeated a set number of times, or repeated continuously. If repeated a set number of times, then the number of cycles must be specified as part of the program.

There are five different types of segment:



Ramp		The setpoint ramps linearly , from its current value to a new value, either at a set rate (called <i>ramp-rate programming</i>), or in a set time (called <i>time-to-target programming</i>). You must specify the ramp rate or the ramp time, and the target setpoint, when creating or modifying a program.
Dwell		The setpoint remains constant for a specified period.
Step		The setpoint steps instantaneously from its current value to a new value.
Call		The main program calls another program as a subroutine. The called program then drives the setpoint until it returns control to the main program. This facility is available on those controllers with 4, or 20, stored programs.
End		The program either ends in this segment, or repeats. You specify which is the case when you create, or modify, the program (see the final topic in this chapter). When the program ends, the programmer is put into either, a continuous Dwell state with all outputs staying unchanged, or the Reset state, or to a settable power level.

Figure 31: Segment types


8.2 Programmer States

The programs have five states: *Reset*, *Run*, *Hold*, *Holdback* and *End*.

State	Description	Indication
Reset	In Reset, the programmer is inactive and the controller behaves as a standard controller, with the setpoint determined by the value set in the lower readout.	Both the RUN and HOLD lights are OFF
Run	In Run, the programmer varies the setpoint according to the active program.	RUN light on
Hold	In Hold, the program is frozen at its current point. In this state you can make temporary changes to any program parameter (for example, a target setpoint, a dwell time, or the time remaining in the current segment). Such changes will only remain effective until the program is reset and run again, when they will be overwritten by the stored program values. Note: When a program is running, you <u>cannot</u> alter a CALL ed program until it becomes active within that program.	HOLD light on
Holdback	Holdback indicates that the measured value is lagging the setpoint by more than a preset amount and that the program is in Hold, waiting for the process to catch up. See <i>Holdback</i> in the section on Automatic behaviour later this chapter.	HOLD light flashes
	A master controller can re-transmit a setpoint value to a number of slave units using PDSIO setpoint retransmission. Any of the slave units can generate a holdback signal which will also flash the HOLD light. Holdback will also occur if the PDSIO output is open circuit. This can be disabled in configuration by selecting the <i>Pd5</i> output as <i>SPnH</i> - 'setpoint retransmission without holdback'	HOLD light flashes
End	The program is complete.	RUN light flashes

Figure 32: Program states

8.3 Running a program from the Run list



The Run List

From the Home display, press until you reach the 'run' list header.

Press

Program number

This display only appears on programmers that can store more than one program. Use or to select the required program number, from 1 to 4, or 1 to 20, depending on the particular controller.

Alternatively, the program number can be selected remotely, using digital inputs on the rear terminals. See the section on *Configuring Digital Inputs to Select a Program Number* for information on how this is done.

Press

Status selection

Use or to select:

- **run**: Run program.
- **hoLd**: Hold program.
- **OFF**: Program reset.

After two seconds, the lower readout blinks and the chosen state is now active.

To return to the Home display press and together.

Other parameters

To access the other parameters in the 'run' list, continue to press . These parameters are shown in the 'Program run list' in Chapter 5, Parameter Tables. They show the current status of the active program.

Temporary changes

Temporary changes can be made to the parameters in this 'run' list, (for example a setpoint, ramp rate, or an unelapsed time), by first placing the programmer into 'hoLd'. Such changes remain active only for the duration of the segment; the segment parameters will revert to their original (stored) values whenever the segment is re-executed.

8.4 Running a Program Using the Run/Hold Button

If you are using a 4, or 20, program version of the controller, you must first select the number of the program that you want to run. Do this in the '*run*' list – see the previous topic, *Running a program from the Run list*.

Then:

	RUN / HOLD button	Press once to run a program (RUN light on) Press again to hold a program (HOLD light on) Press again to cancel hold and continue running (HOLD light off, RUN light on) Press and hold in for two seconds to reset a program (RUN and HOLD lights off).
---	------------------------------	---



Note: The RUN/HOLD button can be disabled, either when ordering the controller, or subsequently in configuration. This will force you to operate the programmer from the 'run' list all the time. The main advantage of this method is that it will reduce the chance of accidentally changing the state of a program.

8.5 Automatic behaviour

The preceding topics explain how to operate the programmer manually.

The following topics cover aspects of its automatic behaviour: *Servo*, *Holdback* and *Power Failure*.

8.5.1 Servo

When a program is RUN, the setpoint can start either from the initial controller setpoint, or from the process value. Whichever it is, the starting point is called the 'servo' point and you set it up in configuration. When the program starts, the transition of the setpoint to its starting point is called 'servoing'.

The normal method is to servo to the process value, because this will produce a smooth and bumpless start to the process. However, if you want to guarantee the time period of the first segment, you should set the controller to servo to its setpoint.

8.5.2 Holdback

As the setpoint ramps up, or down (or dwells), the measured value may lag behind, or deviate from, the setpoint by an undesirable amount. 'Holdback' is available to freeze the program at its current state, should this occur. The action of Holdback is the same as a deviation alarm. It can be enabled, or disabled. Holdback has **two** parameters - a *value* and a *type*.

If the error from the setpoint exceeds the set 'holdback' value, then the Holdback feature, if enabled, will automatically freeze the program at its current point and flash the HOLD light. When the error comes within the holdback value, the program will resume normal running.

There are *four* different Holdback types. The choice of type is made by setting a parameter when creating a program, and may be one of the following:–

'**OFF**' – **Disables Holdback** – therefore no action is taken.

'**Lo**' – **Deviation Low Holdback** holds the program back when the process variable deviates *below* the setpoint by more than the holdback value.

'**Hi**' – **Deviation High Holdback** holds the program back when the process variable deviates *above* the setpoint by more than the holdback value.

'**band**' – **Deviation Band Holdback** is a combination of the two. It holds the program back when the process variable deviates *either above, or below*, the setpoint by more than the holdback value.

There is a single Holdback Value which applies to the whole program. However, the Holdback type and whether or not it is enabled, can be applied to the program as a whole, or individually in each segment.

8.5.3 Power failure

If power is lost and then restored, while a program is running, the behaviour of the programmer is determined by the setting of the parameter '**Pwr.F**' *Power fail strategy* in Programmer configuration. This can have one of three settings:– **cont** (Continue), **rmpb** (Ramp from PV), or **rSEt** (Reset).

If **'CONT'** is selected, then when power is restored the program continues from where it was interrupted when power was lost. All parameters, such as the setpoint and time remaining in the active segment, will be restored to their power-down values. For applications that need to bring the measured process value to the setpoint as soon as possible, this is the best strategy.

If **'rmpb'** is selected, then when power is restored the setpoint starts at ('servos to') the current measured value, and then ramps to the target setpoint of the active segment at the last ramp rate used by the program. This strategy provides a smoother recovery. The two diagrams below illustrate the respective responses, Figure 33 if power fails during a dwell segment and Figure 34 if it fails during a ramp segment.




Figure 33: Continue after a power fail




Figure 34: Ramp back after a power fail

If **'rSEt'** is selected, then when power is restored the program terminates.


8.6 Configuring the Programmer

When first installing a programmer you should check that the configuration conforms to your requirement.

Configuration defines:

- the number of stored programs *(multi-programmer only)*
- the holdback strategy
- the power fail strategy
- the servo type
- if event outputs are available *(not 8-segment programmer)*
- if program synchronisation is available. *(not 8-segment programmer)*
- selection of program number using digital inputs *(multi-programmer only)*

To check, or change, the configuration, select Configuration level. See Chapter 9.



Programmer list header

After selecting Configuration mode, press  until the **PRG Conf** header is displayed.

Press 

Number of programs

Use  or  to select:

- **nonE**: Disable built-in 8-segment programmer
- **1**: Enable built-in 8-segment programmer

For 16-segment programmers:

- **nonE**: no programs
- **1**: One stored program
- **4**: Four stored programs
- **20**: Twenty stored programs

Press 

Holdback Strategy

Use  or  to select:

- **SEG**: Holdback type to be set in each segment
- **Prog**: Holdback type to be set for the whole program


Press 

Power fail strategy

Use  or  to select

- **cont**: Continue from last setpoint
- **rmPb**: Ramp from PV to setpoint at last ramp rate
- **rSEt**: Reset the program.

Continued on next page



Press

Servo type

Use or to select:

- **toPU**: Servo to PV
- **toSP**: Servo to SP

Press

Event Outputs (not in 8-segment programmer)

Use or to select:

- **no**: Event outputs disabled
- **YES**: Event outputs enabled

Press

Synchronisation(not in 8-segment programmer)

Use or to select:

- **no**: Synchronisation disabled
- **YES**: Synchronisation enabled


Press to return the list header.

8.7 Configuring Digital Inputs to Select Program Number

The program number can be selected by external BCD inputs from, for example, a thumbwheel switch.

The appropriate number of digital inputs must be installed in the controller and be configured for this function - see Chapter 9, *Configuration*.

To invoke this mode of operation, the parameter '*bcd*' in '*inst-Conf*' must be set to '*Pr00*'.








Press  until you reach '*bcd*'.

Use the  or  buttons, to select '*Pr00*'.

8.7.1 Creating a New Program, or Modifying an Existing One

The only difference between creating a new program, and modifying an existing one, is that a new program starts with all its segments set to *End* in the *TYPE* parameter. The procedure for both consists of setting up the parameters in the *ProG* list of the Operator Navigation Diagram shown in section 5.8. As explained earlier under 'Programmer states', temporary changes can be made to these parameters while in the *HOLD* state but permanent changes (to the stored values) can only be made when the programmer is in the Reset state. So, before modifying a stored program first make sure that it is in Reset and then follow the procedure



Program edit list

From the Home display press  until you reach the ProG LiSt header.

Press 

Program number

This display appears only on the multi-program controllers.

Use  or  to select the number of the program which you wish to modify (from 1 to 4, or 1 to 20).

Press 

Holdback type

[Only appears when Holdback has been selected for the whole program.]

Use  or  to select:

- *OFF*: Holdback disabled
- *Lo*: Deviation Low Holdback
- *Hi*: Deviation High Holdback
- *bAnd*: Deviation Band Holdback

Press 

Holdback value

Note! The value set in this parameter is always for the whole program.

Use  or  to set the value.





Press 

Ramp units

Use  or  to select:

- *SEc*
- *min*
- *Hour*

Continued on next page



Continued on next page

Press

Dwell units

Use or to select:

- SEc
- m n
- Hour

Press

Number of program cycles

Use or to set the number of program cycles required from 1 to 999, or 'cont' for continuous cycling.

Press

Segment number

Use or to select the number, from 1 to 16.

(1 to 8 in 8-segment programmers)

The parameters that follow 'SEG.n' set up the characteristics of the individually-selected segment number. By defining the characteristics of each segment of the program, you define the whole program.

Press


Segment type

Select the segment type using or .

- r m P r: Ramp to a new setpoint at a set rate
- r m P t: Ramp to a new setpoint in a set time
- dwEll: Dwell for a set time
- StEP: Step to a new setpoint
- cALL: Call another program as a subroutine (only available in multi-program controllers)
- End: Make this segment the end of the program.

The parameters that follow 'TYPE' depend on the type of segment selected as shown in the table below. The function of each parameters follows the table.

Parameter	Segment type selected					
	r m P r	r m P t	dwEll	StEP	cALL	End
Hb	✓	✓	✓	✓		
tEt	✓	✓		✓		
rAtE	✓					
dur		✓	✓			
PrGn					✓	
cYc.n					✓	
outn	✓	✓	✓	✓		✓
Sync	✓	✓	✓	✓		
Endt						✓



Press

Holdback type

Only appears when Holdback per segment has been selected.

Use or to select:

- **OFF**: Holdback disabled
- **Lo**: Deviation Low Holdback
- **Hi**: Deviation High Holdback
- **bAnd**: Deviation Band Holdback

Press

Target setpoint

Target setpoint for 'rmP.r', 'rmP.t' or 'StEP' segments.

Set the target setpoint using or .

Press

Ramp rate

Ramp rate for 'rmP.r' segments

Using or , set a value for the ramp rate, ranging from 0.0 to 999.9. The units are the ramp units (**rmP.U**) set earlier in this sequence.

Press

Duration time

Time for a 'dwEll' segment, or time to target for a 'rmP.t' segment.

Set the time using or . You have set the units earlier in this sequence. [**dwL.U** defines the units for 'dwEll' segments: '**rmP.U**' defines the units for 'rmP.t' segments.]


Press

Called program number

Only appears for 'cALL' segments. (multi-program controllers only)

Set a called program number from 1 to 4, or from 1 to 20, using or .

Continued on next page



Press

Number of cycles of the cALLED program

Only appears for 'cALL' segments. (multi-program controllers only)

Sets the number of cycles of the cALLED program from 1 to 999, using or .

Press

Event output 1 (16-segment programmers only)

Appears in all segments, except 'cALL' segments.

Use or to set output 1:

- **OFF**: Off in the current segment
- **on**: On the current segment.

Press

Further event outputs (16-segment programmers only)

Up to eight (8) event outputs may appear in this list where 'n' = event number.

Pressing will step through all the remaining event outputs.

Note: If you are not using all of the event outputs, you can step immediately to the next segment number by pressing .

Press

Synchronisation event output (only appears if configured)

Use or to select:

- **YES**: Synchronisation Enabled
- **no**: Synchronisation Disabled

Note: This event output, if used, occupies the position of 'outB'.


Press

End segment

Use or to select:

- **dwEll**: An indefinite dwell
- **rSEt**: Reset.
- **5 OP**: End Segment Output Power Level

Continued on next page



Press 

Power Value [End Segment]

Use  or  to set the power value in the range $\pm 100.0\%$.

This power level is clipped by the parameters 'OP.Hi' and 'OP.Lo' before being applied to the process.

Note: In programmer/controller software versions 3.56 onwards this parameter has been replaced by a parameter **EndP** which appears at the end of the Output List, see Chapter 5.

Press  to return to the Prog-List header.

9. CHAPTER 9 CONFIGURATION

This chapter consists of six topics:

- SELECTING CONFIGURATION LEVEL
- LEAVING CONFIGURATION LEVEL
- SELECTING A CONFIGURATION PARAMETER
- CHANGING THE PASSWORDS
- NAVIGATION DIAGRAM
- CONFIGURATION PARAMETER TABLES.

In configuration level you set up the fundamental characteristics of the controller.

These are:

- The type of control (e.g. reverse or direct acting)
- The Input type and range
- The Setpoint configuration
- The Alarms configuration
- The Programmer configuration
- The Digital input configuration
- The Alarm Relay configuration
- The Communications configuration
- The Modules 1, 2 & 3 configuration
- Calibration
- The Passwords.



Warning: Configuration is protected by a password and should only be carried out by a qualified person, authorised to do so. Incorrect configuration could result in damage to the process being controlled and/or personal injury. It is the responsibility of the person commissioning the process to ensure that the configuration is correct.






Caution: It is recommended to maintain a record of instrument configurations or use Eurotherm iTools to make clone copies of fully working instruments. Store this securely as a back up record to be used to restore the configuration and other settings should the instrument need to be replaced in the future. iTools and the iTools Help Manual HA028838 is available from www.eurotherm.co.uk.

9.1 Selecting Configuration Level

There are two alternative methods of selecting Configuration level:

- If you have already powered up, then follow the access instructions given in Chapter 6, Access Levels.
- Alternatively, press  and  together when powering up the controller. This will take you directly to the 'CONF' password display.



Password entry

When the 'CONF' display appears, you must enter the Configuration password (which is a number) in order to gain access to Configuration level.

Enter the password using the  or  buttons.

The configuration password is set to '2' when the controller is shipped from the factory.

Press .

Once the correct password has been entered, there is a two second delay, after which the lower readout will change to 'PASS' indicating that access is now unlocked.



Note:

A special case exists if the password has been set to '0'. In this situation, access is permanently unlocked and the lower readout will always show 'PASS'.

Press  to enter configuration.


(If an incorrect password has been entered and the controller is still 'locked' then pressing  at this point will take you to the 'Inst' display with 'no' in the lower readout. Simply press  to return to the 'CONF' display.)

You will obtain the first display of configuration.

9.2 Leaving Configuration Level

To leave the Configuration level and return to Operator level Press  until the 'Inst' display appears.

Alternatively, pressing  and  together will take you directly to the 'Inst' display.



Use  or  to select 'YES'. After a two-second delay, the display will blank and revert to the Home display in Operator level.

9.3 Selecting a Configuration Parameter

The configuration parameters are arranged in lists as shown in the navigation diagram in Figure 35.

To step through the list headers, press the Page  button.

To step through the parameters within a particular list press the Scroll  button.

When you reach the end of the list you will return to the list header.

You can return directly to the list header at any time by pressing the Page  button.

9.3.1 Parameter names

Each box in the navigation diagram shows the display for a particular parameter. The upper readout shows the name of the parameter and the lower readout its value. For a definition of each parameter, see the Configuration Parameter Tables at the end of this chapter. To change the value of a selected parameter, use the  and  buttons.

The navigation diagram shows all the lists headers and parameters that can, potentially, be present in the controller. In practice, those actually present will vary according to the particular configuration choices you make.

9.4 Changing the Passwords

There are TWO passwords. These are stored in the Password configuration list and can be selected and changed in the same manner as any other configuration parameter.

The password names are:

‘*ALLP*’ which protects access to Full level and Edit level

‘*CONF*’ which protects access to Configuration level.

9.5 Navigation Diagram (Part A)





Figure 35: Navigation diagram (Part A)

9.6 Navigation Diagram (PART B)



- Note:**
1. Additional headers, carrying the suffixes **b** and **L**, will appear if dual-, or triple-, channel modules have been installed. The header denotes the labelling of the terminal to which the output function is connected.
 2. Module 4 is the High Current Switch Module. This is only available in the Model 2404 controller on controllers manufactured before Jan-04.
 3. 8-point custom linearisation. Only appears when either '3A' or 'P-Conf' has 'inPt' = 'mV L', or 'mA L', or 'V L'.
 4. The navigation diagram shows typical parameters, but is dependant upon the exact configuration of the instrument. The following sheets show the full list of parameters.

Figure 35: Navigation diagram (Part B)

9.7 Navigation Diagram (Part C)




Figure 35: Navigation diagram (Part C)

9.8 Configuration Parameter Tables

Name	Description	Values	Meaning
Inst	Instrument configuration		
Ctrl	Control type	PID OnOff Unb Unb	PID control On/off control Boundless motorised valve control - <i>no feedback required</i> Bounded motorised valve control - <i>feedback required</i>
Act	Control action	Rev Dir	Reverse acting Direct acting
Cool	Type of cooling	Lin Oil H2O Fan OnOff	Linear Oil (50mS minimum on-time) Water (non-linear) Fan (0.5S minimum on-time) On/off cooling
IntD	Integral & derivative time units	Sec min	Seconds, OFF to 9999 Minutes, OFF to 999.9
DerP	Derivative type	PV Err	Operates on rate of change of PV Operates on rate of change of error
Man	Front panel Auto/Man button	EnAb DiSA	Enabled Disabled
Run	Front panel Run/Hold button	EnAb DiSA	Enabled Disabled
PowerF	Power feedback	on OFF	On Off
Feed	Feed forward type	nonE FEED SPFF PUFF	None Normal feed forward Setpoint feed forward PV feed forward
PDtr	Manual/Auto transfer when using PD control	no YES	Non-bumpless transfer Bumpless transfer - (<i>Pre-loads Manual Reset value</i>)
Sbrt	Sensor break output	SbOP HoLd	Go to pre-set value Freeze output
FOP	Forced manual output	no ErrAc STEP	Bumpless Auto/Manual transfer Returns to the Manual value that was set when last in Manual mode Steps to forced output level. Value set in 'FOP' of 'oP-L, SE' in Operator Level
bcd	BCD input function	nonE Prog SP	Not used Select program number Select setpoint number
Gsch	Gain schedule enable	no YES	Disabled Enabled

Name	Description	Values	Meaning
PU	Process value config		
unit	Instrument units	°C °F K none	Celsius Fahrenheit Kelvin Display units blanked
decP	Decimal places in the displayed value	none one two	None One Two
rngL	Range low		Low range limit. Also setpoint limit for alarms and programmers
rngH	Range high		High range limit. Also setpoint limit for alarms and programmers

Notes: 1. **Pyrometer Emmisivity**

Controllers which are specifically supplied for pyrometer inputs (not Exergen K80), have the curve downloaded in the Custom Input. The parameter, **Emi 5**, Pyrometer Emmisivity, appears in the Input List on page 2-15. This parameter is also now correctly adjusted.



2. **Range**

If a decimal point was configured, negative display and setpoint ranges were limited to -99.9 in previous software versions. The range has been increased to -199.9 by combining the negative sign with the figure one. This allows Setpoints, Process Variables, Alarm Setpoints and Programmers to be set to -199.9.

Name	Description	Values	Meaning
IP	Input configuration		
IPt	Input type	Jtc Ktc Ltc Rtc Btc Ntc Ttc Stc PL 2 Ctc rtd mV volt mA sqrt V sqrt A * see 'CUST' List. mVc Vc mAc	J thermocouple K thermocouple L thermocouple R thermocouple (Pt/Pt13%Rh) B thermocouple (Pt30%Rh/Pt6%Rh) N thermocouple T thermocouple S thermocouple (Pt/Pt10%Rh) PL 2 thermocouple Custom downloaded t/c (default = type C) 100Ω platinum resistance thermometer Linear millivolt Linear voltage Linear milliamps Square root volts Square root milliamps 8-point millivolt custom linearisation* 8-point Voltage custom linearisation* 8-point milliamp custom linearisation*
CJC	Cold Junction Compensation	Auto 0°C 45°C 50°C OFF	Automatic internal compensation 0°C external reference 45°C external reference 50°C external reference No cold junction compensation
IMP	Sensor Break Impedance	OFF Auto Hi Hi, Hi	Disabled (applies to any input) Caution: If sensor break is disabled the controller will not detect open circuit faults Factory set (Default i.e. enabled) Impedance of input > 5KΩ Impedance of input > 15KΩ
Linear Input Scaling – The next 4 parameters only appear if a linear or sqrt input is chosen.			
INPL		Input value low	
INPH		Input value high	
URLL		Displayed reading low	
URLH		Displayed reading high	

Name	Description	Values	Meaning
SP	Setpoint configuration		
nSP	Number of setpoints	2, 4, 16	Select number of setpoints available
rmt	Remote Tracking	OFF tRAc	Disable Local setpoint tracks remote setpoint
mt	Manual Track	OFF tRAc	Disable Local setpoint tracks PV when in manual
Prtr	Programmer Track	OFF tRAc	Disable Local setpoint tracks programmer SP
rmpU	Setpoint rate limit units	PSEc Pm, n PHr	Per second Per minute Per hour
rmt	Remote setpoint configuration	nonE SP Loc t rmt t	Disable Remote setpoint Remote setpoint + local trim Remote trim + local setpoint

AL	Alarm configuration	Values
<i>The controller contains four 'soft' alarms, which are configured in this list. Once configured, they can be attached to a physical output as described in the alarm relay configuration list, 'AR ConF'.</i>		
AL1	Alarm 1 Type	see Table A
Ltch	Latching	no/YES/Eunt/mAn*
bLoc	Blocking	no/YES
AL2	Alarm 2 Type	see Table A
Ltch	Latching	no/YES/Eunt/mAn*
bLoc	Blocking	no/YES
AL3	Alarm 3 Type	see Table A
Ltch	Latching	no/YES/Eunt/mAn*
bLoc	Blocking	no/YES
AL4	Alarm 4 Type	see Table A
Ltch	Latching	no/YES/Eunt/mAn*
bLoc	Blocking (not if 'AL4' = 'rAt')	no/YES
Sbrt	Sensor break trip alarm latching type. Disable = process alarms inhibited when in sensor break Enable = process alarms shown when in sensor break	En Enable dS Disable

Table A - Alarm types	
Value	Alarm type
OFF	No alarm
FSL	PV Full scale low
FSH	PV Full scale high
dEu	PV Deviation band
dHi	PV Deviation high
dLo	PV Deviation low
LCr	Load Current low
HCr	Load Current high
FL2	Input 2 Full Scale low
FH2	Input 2 Full Scale high
LDP	Working Output low
HDP	Working Output high
LSP	Working Setpoint low
HSP	Working Setpoint high
rAt	PV Rate of change AL4 only
Ct.OP	CT open circuit
Ct.Sh	CT short circuit

* Alarm Modes

'no' means that the alarm will be non-latching.

'YES' means that the alarm will be latched, with automatic resetting. Automatic resetting means that if a reset is actioned before the alarm has cleared, then it will automatically reset when it clears.

'Eunt' means that the alarm is used to trip an external event. If this option is selected the front panel alarm message will not appear.

'mAn' means that the alarm will be latched, and can only be reset after it has first cleared (called 'manual reset mode').

<i>The following parameters apply if the standard 8-segment programmer is to be configured.</i>			
PROG	Programmer configuration	Values	Meaning
PtYP	Programmer type	nonE 1	Programmer disabled (<i>factory setting</i>) 8-segment programmer enabled
HbRC	Holdback	SEG PROG	Holdback is individually selectable in each segment. Holdback is applied across the whole Program.
PwrF	Power fail recovery	cont rmpb rSEt	Continue from last setpoint (SP) Ramp from PV to SP at last ramp rate Reset the program
SRuo	Starting setpoint of a program (Servo point)	LoPV LoSP	From the Process Value (PV) From the setpoint

<i>The following parameters apply if a 16-segment programmer is to be configured.</i>			
PROG	Programmer configuration	Values	Meaning
PtYP	Programmer type	nonE 1 4 20	Programmer disabled Single program Four programs Twenty programs
HbRC	Holdback	SEG PROG	Holdback is individually selectable in each segment. Holdback is applied across the whole Program.
PwrF	Power fail recovery	cont rmpb rSEt	Continue from last setpoint (SP) Ramp from PV to SP at last ramp rate Reset the program
SRuo	Starting setpoint of a program (Servo point)	LoPV LoSP	From the Process Value (PV) From the setpoint
out	Programmable event outputs	no YES	Disabled Enabled
SYNC	Synchronisation of programs of several programmers	no YES	Disabled Enabled

Name	Description	Values	Meaning
------	-------------	--------	---------

LA Lb	Digital input 1/2 configuration		Action on contact closure
Id	Identity	LoG	Logic input
Func	Function of input <i>The function is active when the input has a contact closure to the common terminal - LC</i>	nonE mAn rmt SP2 Pi d2 E, H EunE drA AckAL AccS Locb uP dwn ScrL PAGE run HoLd r-H rES Sk, P HbAc bcd.1 bcd.2 bcd.3 bcd.4 bcd.5 bcd.6 rmPE SYnc rrES rESr Stby PUSL AdU AmPS	No function Manual mode select Remote setpoint select Setpoint 2 select PID set 2 select Integral hold One-shot self-tune enable Adaptive tune enable Acknowledge alarms Select Full access level Keylock Simulate pressing of the  button Simulate pressing of the  button Simulate pressing of the  button Simulate pressing of the  button Run program Hold program Run program (closed) / Hold (open) Reset program Skip to End of Current Segment, without changing the setpoint Program holdback enabled Least significant BCD digit 2nd BCD digit 3rd BCD digit 4th BCD digit 5th BCD digit Most significant BCD digit Setpoint Rate Limit Enable Program waits at the end of the current segment Program Run (closed) / Reset (open) Program Reset (closed) / Run (open) Standby - ALL control outputs turned OFF (alarm Outputs are not affected) PV Select: Closed = PV1 / Open = PV2 Advance to End of Segment and to Target Setpoint Current – LB only
	<i>These BCD inputs are used to select either a program number or the setpoint number according to the setting of the parameter 'bcd' in the 'Inst' configuration list</i>		

Name	Description	Values	Meaning
RR	Alarm relay configuration		
id	Identity	REL	Relay output
Func	Function	none	No function
		dig	Digital output
SEnS	Digital output sense	nor	Normal (<i>output energises when TRUE, e.g. program events</i>)
		inv	Inverted (<i>output de-energises when TRUE, e.g. alarms</i>)
The following digital events appear after 'SEnS'. Any one, or more, of the events can be combined on to the output (see Figure 36) by selecting 'YES' in the lower readout.			
1---	Alarm 1 active	YES / no	(---) = alarm type (e.g. FSL). If an alarm has not been configured in 'AL Conf' list, then the display will not show the alarm type:- e.g. Alarm 1 = 'AL 1'.
2---	Alarm 2 active	YES / no	
3---	Alarm 3 active	YES / no	
4---	Alarm 4 active	YES / no	
man	Controller in manual mode	YES / no	
Sbr	Sensor break	YES / no	
SPAn	PV out of range	YES / no	
Lbr	Loop break	YES / no	
LdF	Load failure alarm	YES / no	
tunE	Tuning in progress	YES / no	
dcF	Voltage output open circuit, or mA output open circuit	YES / no	
rmLF	PDS module measurement connection or remote input open circuit	YES / no	
IP1F	Input 1 failure	YES / no	
newAL	New Alarm has occurred	YES / no	
End	End of setpoint rate limit, or end of program	YES / no	
SYnc	Program Synchronisation active	YES / no	
PrGn	Programmer event output active, where 'n' = event number from 1 to 8. (Not available with 8-segment programmer.)	YES / no	




Figure 36: Combining several digital events on to one output

Name	Description	Values	Meaning
HA	Comms 1 module config		
i d	Identity of the module installed	cm5 Pd5 Pd5, dnEt	EIA-232, or 2-wire EIA-485, or 4-wire EIA-485 comms PDS retransmission PDS input DeviceNet

For 'i d' = 'cm5' (Digital communications) use this parameter table:

Func	Function	mod El b,	Modbus protocol Bisynch protocol
bAud	Baud Rate	1200, 2400, 4800, 9600, 1920 (19,200) 125(K), 250(K), 500(K) for DeviceNet	
dELy	Delay - quiet period, required by some comms adaptors	no YES	No delay Delay active - 10mS
<i>The following parameters only appear if the function chosen is Modbus protocol.</i>			
Prty	Comms Parity	nonE EuEn Odd	No parity Even parity Odd parity
rES	Comms Resolution	FuLL I nt	Full resolution Integer resolution

For 'i d' = 'Pd5' (PDS retransmission output) use this parameter table:

Func	Function <i>i.e. Retransmitted output</i>	nonE SP.OP PV.OP OP.OP Er.OP SP.nH	No PDS function PDS setpoint retransmission PDS PV retransmission PDS output power retransmission PDS error signal retransmission PDS setpoint retransmission - no holdback
-------------	--	---	--

Output Scaling

URL L		Retransmitted value low
URL H		Retransmitted Value High

For 'i d' = 'Pd5,' (PDS setpoint input) use this parameter table:

Func	Function	SP, P	PDS setpoint input
URLL	Displayed Value VAL.H VAL.L 0%100%Electrical Input	Setpoint Displayed Value - Low	
URLH		Setpoint Displayed Value - High	



Note: Having configured the module function as remote setpoint you must then specify the type of remote setpoint in the **SP-conf** list

JA	Comms 2 module config		
Same as HA but is only available as PDS.			

Name	Description	Values	Meaning
IA/IC⁽¹⁾	Module 1 configuration		
i d	Identity of module installed (1) If a dual-, or triple-, channel module is installed then the list headers IA and IC also appear	nonE rELY dCOP LOG LOGI SSr dcrE dCOP SGSU	Module not fitted Relay output DC output isolated and non-isolated Logic/PDS output Logic input Triac output DC retransmission (isolated) Isolated DC output Transducer power supply

For **i d** = 'rELY', 'LOG', or 'SSr' use this parameter table:

Func	Function (Only Channels IA and IC can be Heating, or Cooling). If a single logic output module is fitted (code LO) this function will need to be configured. (Only if i d = 'LOG') (Only if i d = 'LOG')	nonE dIG HEAT COOL uP dwn SSr.1 SSr.2	Function disabled Digital output function Heating output Cooling output Open motorised valve Close motorised valve PDS mode 1 heating PDS mode 2 heating
URLL			% PID demand signal giving minimum output – 'Out.L'
URLH			% PID demand signal giving maximum output – 'Out.H'
OutL			Minimum average power
OutH			Maximum average power
SEnS	Sense of output (Only if Func = 'dIG')	nor inu	Normal (output energises when TRUE, e.g. program events) Inverted (output de-energises when TRUE, e.g. alarms)


Note:

- When 'SEnS' appears, then further parameters are available. These are identical to those in the **RA Conf** list.
- If a Transducer Power Supply is fitted, the **SEnS** parameter selects the output voltage.
nor = 5V, **inu** = 10V
- A Transducer Power Supply does not provide any calibration facility and is simply a 5 or 10V power supply.
- To invert a PID output, the **URLH** can be set below the **URLL**



Name	Description	Values	Meaning
------	-------------	--------	---------


For 'd' = 'dC.OP', 'dC.rE', or 'dC.OP' use this parameter table:


Func	Function	nonE	Function disabled
		HEAt	Heating output
		COOL	Cooling output
		PV	Retransmission of PV
		wSP	Retransmission of setpoint
		Err	Retransmission of error signal
		OP	Retransmission of OP power
VAL.L		% PID, or Retrans'n Value, giving minimum output	
VAL.H		% PID, or Retrans'n Value, giving maximum output	
unit		Volts = Volts, mA = milliamps	
Out.L		Minimum electrical output	
Out.H		Maximum electrical output	

For 'd' = 'LOG' (i.e logic input) use the LA Conf list.

Label	Module 2 configuration		
As per module 1 configuration, but excluding the 'SSr.1', 'SSr.2' functions.			
d	Identity of module installed. As per module 2 plus:	TPSU Pot.	Transmitter power supply Potentiometer input

For 'd' = 'Pot.' (i.e. potentiometer input module) use this parameter table:

Func	Function	nonE	Function disabled
		rSP	Remote Setpoint
		Fwd.	Feedforward input
		rOPh	Remote OP power max.
		rOPL	Remote OP power min.
		UPoS	Motorised valve position
VAL.L		Displayed value low equivalent to 0% potentiometer position	
VAL.H		Displayed value high equivalent to 100% potentiometer position	

3A1b/C	Module 3 configuration		
As per module 2 configuration, plus 'd' = 'dC, P'			
For 'd' = 'dC, P' use this parameter table. THIS INCLUDES THE SECOND PV FUNCTIONS			
Func	Function	nonE	Function disabled
		rSP	Remote Setpoint
		Fwd,	Feedforward input
		rOPh	Remote OP power max.
		rOPL	Remote OP power min.
		H _i	PV = The highest of, P, I, or, P2
		L _o	PV = The lowest of, P, I, or, P2
		F _{Ln}	Derived function, where $PV = (F, I \times P, I) + (F, 2 \times P, 2)$. 'F, I' and 'F, 2' are scalars which are found in 'P-L, S _E ' of Operator Level
		SEL	Select, P, I, or, P2 via Comms, front panel buttons, or a digital input
		trAn	Transition of control between, P, I and, P2. The transition region is set by the values of 'L _o P' and 'H _i P', which are found in 'P-L, S _E ' of Operator Level. PV =, P, I below 'L _o P', PV =, P2 above 'H _i P'
, nP _E	Input type	Refer to 'P Conf' for all types, + the following:	
		H _i I _n	High Impedance (range = 0 to 2 volt)
CJC	Cold Junction Compensation	OFF	No cold junction compensation
		Auto	Automatic internal compensation
		0°C	0°C external reference
		45°C	45°C external reference
		50°C	50°C external reference
, mP	Sensor Break Impedance	OFF	Disabled (applies to any input)
		Caution: If sensor break is disabled the controller will not detect open circuit faults	
		Auto	Factory set
		H _i	Impedance of input > 15KΩ
		H _i H _i	Impedance of input > 30KΩ
Linear Input Scaling – The next four parameters only appear if a linear input is chosen.			
, nP _L		Input value low	
, nP _H		Input value high	
U _{RL} L		Displayed value low	
U _{RL} H		Displayed value high	

Name	Description	Values	Meaning
4A	Module 4 configuration		
Note: This option is not available on controllers from 01 Jan-04			
Id	Identity of module installed	HCS	High Current Switch
Func	Function	nonE	Function disabled
		diG	Digital output function
		HEAT	Heating output
		COOL	Cooling output
URLL			% PID demand signal giving minimum output – 'OutL'
URLH			% PID demand signal giving maximum output – 'OutH'
OutL			Minimum electrical output
OutH			Maximum electrical output
SENS	Sense of output (Only if Func = 'diG')	nor	Normal (output energises when TRUE, e.g. program events)
		inu	Inverted (output de-energises when TRUE, e.g. alarms)
When ' SENS ' appears, then further parameters are available. These are identical to those in the ' AA Conf ' list on Page 6-14.			

Custom	8-point Custom Linearisation ⁽¹⁾	
in 1		Custom input 1
URL 1		Linearisation Value representing in 1
in 8		Custom input 8
URL B		Linearisation Value representing in 8

**Note:**

1. Custom Linearisation is only available when '**3A-Conf**' or '**P-Conf**' list has '**inPE**' set to '**mUC**', or '**mAC**', or '**UC**'.
2. The values and inputs must be continuously increasing or decreasing

Name	Description	Values	Meaning
------	-------------	--------	---------

CAL	Calibration			
In this mode you can				
1. Calibrate the instrument using a mV source - rCAL or ref source cal.				
2. Offset the calibration to account for errors in actual sensor measurement and a ref sensor - UCAL or user calibration				
3. Return to factory set calibration - FALT or factory set calibration.				
rCAL	Calibration point	nonE	No calibration	▶ Goto User calibration table-See also section 10
		PU	Calibrate main Process Value input.	▶ Go to input Calibration table
		PU2	Calibrate DC input, or PV 2.	
				▶ Go to DC Output Calibration table
		1AH ₁	Calibrate DC output high - Module 1	
		1AL ₀	Calibrate DC output low - Module 1	
		2AH ₁	Calibrate DC output high - Module 2	
		2AL ₀	Calibrate DC output low - Module 2	
		3AH ₁	Calibrate DC output high - Module 3	
		3AL ₀	Calibrate DC output low - Module 3	

Input Calibration			
For 'CAL' = 'PU', or 'PU2', the following parameters apply.			
PU	PV Calibration Value	Idle	Idle
		mUL	Select 0mV as the calibration point
		mUH	Select 50mV as the calibration point
		U 0	Select 0V as the calibration point
		U 10	Select 10V as the calibration point
		CJC	Select 0°C CJC calibration point
		rtd	Select 400Ω as the calibration point
		HI 0	High impedance: 0V cal'n point
		HI 10	High impedance: 1.0 Volt cal'n point
		FALE	Restore factory calibration
GO	Start calibration Select 'YES' with ▲ or ▼ Wait for calibration to complete.	no	Waiting to calibrate PV point
		YES	Start calibration
		buSY	Busy calibrating
		donE	PV input calibration completed
		FAI L	Calibration failed



Note: When a DC input module is installed for the first time, or there is a requirement to change one, then the microprocessor in the controller needs to read the factory calibration data stored in the module. Select '**FALE**' as the calibration value. Step to '**GO**' and start calibration.

DC Output Calibration			
<i>The following parameters apply to DC output modules ie for $rCAL = 18V$ to $36V$</i>			
$CALH$	Output Calibration High	0	0 = Factory set calibration. Trim value until output = 9V, or 18mA
$CALL$	Output Calibration Low	0	0 = Factory set calibration. Trim value until output = 1V, or 2mA

User calibration		
$UCAL$	User calibration enable	Yes/no
$PL1L$	Low calibration point for Input 1	The factory calibration point at which the low point offset was performed.
$PL1H$	High calibration point for Input 1	The factory calibration point at which the high point offset was performed.
$OF1L$	Offset Low for Input 1	Calculated offset, in display units.
$OF1H$	Offset High for Input 1	Calculated offset, in display units.
$PL2L$	Low calibration point for Input 2	The factory calibration point at which the low point offset was performed.
$PL2H$	High calibration point for Input 2	The factory calibration point at which the high point offset was performed.
$OF2L$	Offset Low for Input 2	Calculated offset, in display units.
$OF2H$	Offset High for Input 2	Calculated offset, in display units.

Name	Description	Values	Meaning
$PASS$	Password configuration		
$ACCP$	Full or Edit level password		
$cnFP$	Configuration level password		





Note: When passwords are changed please make a note of the new numbers

$EXIT$	Exit configuration	no/YES	
--------	--------------------	--------	--

9.9 Configuration Examples








Transducer Power Supply

To configure the choice of output voltage:-

Do This	The Display You Should See	Additional Notes
1. Press  as many times as necessary to select the slot position in which the transducer power supply is fitted		The transducer power supply can be fitted in slot positions 1 and 2. The display will show <i>IA</i> or <i>IB</i> accordingly
2. Press  to read the identity of the module		This is read only where: <i>50.50</i> = Transducer Power Supply
3. Press  (twice) to read 'SEn5' 4. Press  and  to select ' <i>nu</i> ' or ' <i>nr</i> '		<i>nu</i> = 10Vdc <i>nr</i> = 5Vdc The Transducer Power supply uses existing software written for digital modules. A list of parameters follow which are not applicable to this module.

DeviceNet

To configure Function, Baud Rate, Resolution and Node Address:-

Do This	The Display You Should See	Additional Notes
1. Press  as many times as necessary to select 'HA'		This is the position in which the DeviceNet module is fitted
2. Press  to read 'd'		If the module is present 'd' = 'cm5' (digital communications) or 'nonE' if the module is not present
3. Press  to read 'Func'		If the DeviceNet module is fitted 'Func' = 'dnEt' and will be read only
4. Press  to read 'bAud'		Baud rate can be set to 125(K), 250(K) or 500(K)
5. Press  and  to select the baud rate		
6. Press  to read 'rES'		Full - the decimal point position is implied, eg 100.1 is transmitted as 1001. 'nt' - rounded to the nearest integer value
7. Press  and  to select 'Full' or 'nt'		
Node Address is set up in Operator or Full Access level. Select either of these levels, then:-		
8. Press  as many times as necessary to select 'cm5'		
9. Press  to read 'Addr'		Valid addresses are from 0 - 63
10. Press  and  to select the address		
11. Press  to read 'nwSt'		Indicates the network status:- 'run' = network connected and operational 'rdy' = network connected but not operational 'OFFL' = network not connected

10.CHAPTER 10 USER CALIBRATION

This chapter has five topics:

- WHAT IS THE PURPOSE OF USER CALIBRATION?
- USER CALIBRATION ENABLE
- OFFSET CALIBRATION
- TWO POINT CALIBRATION
- CALIBRATION POINTS AND CALIBRATION OFFSETS

To understand how to select and change parameters in this chapter you will need to have read Chapter 5 - *Operation*, Chapter 6- *Access Levels* and Chapter 9 - *Configuration*.

10.1 What is the Purpose of User Calibration?

The basic calibration of the controller is highly stable and set for life. User calibration allows you to offset the 'permanent' factory calibration to either:


1. Calibrate the controller to the your reference standards.
2. Match the calibration of the controller to that of a particular transducer or sensor input.
3. Calibrate the controller to suit the characteristics of a particular installation.
4. Remove long term drift in the factory set calibration.

User calibration works by introducing a single point, or two-point, offset onto the factory set calibration.

10.2 User Calibration Enable

The User calibration facility must first be enabled in configuration level by setting the parameter '*UCAL*' in the input conf list to '*YES*'. This will make the User calibration parameters visible in Operator '*FULL*' level.

Select configuration level as shown in Chapter 9, *Configuration*



The Calibration Configuration List

Press  until you reach the '*CAL-Conf*' list.

Press  until you reach '*UCAL*'.

User Calibration Enable

Use  or  to select:

- *YES*: Calibration enable
- *no*: Calibration disabled


Press  and  together to go to the *Exit* display.

Exit configuration

Use  or  to select '*YES*' to return to Operator level

10.3 Offset Calibration


Offset calibration is used to apply a single fixed offset over the full display range of the controller.



To calibrate, proceed as follows:

1. Connect the input of the controller to the source device to which you wish to calibrate.
2. Set the source to the desired calibration value.
3. The controller will display the current measurement of the value.
4. If the displayed value is correct, then the controller is correctly calibrated and no further action is necessary. If it is incorrect, then follow the steps shown below.

Select '**FULL**' access level, as described in Chapter 6



Input list header

Press  until you reach the input list header.

Press  until you reach the '**CAL**' display.

Calibration type

- **FACT**: Factory Calibration
- **USER**: User Calibration

Use  or  to select '**FACT**'.

Selecting '**FACT**' reinstates the factory calibration and allows the application of a single fixed offset.


Press 

Set Offset 1

Use  or  to set the offset value of Process Value 1 (PV1).

The offset value is in display units.

Continued on next page



Set Offset 2

Use or to set the offset value of Process Value 2 (PV2), if configured.

The offset value is in display units.

Press

The table below shows the parameters which appear after '0F5.2'. These are all read only values and are for information.

Press to step through them.


mU.1	IP1 measured value (at terminals)
mU.2	IP2 measured value (at terminals), if DC input in Module 3 position
CJC.1	IP1 Cold Junction Compensation
CJC.2	IP2 Cold Junction Compensation
L.1	IP1 Linearised Value
L.2	IP2 Linearised Value
PU.5L	Shows the currently selected input

If you do not want to look at these parameters, then press and this returns you to the 'P-L, 5t' header.

To protect the calibration against unauthorised adjustment, return to Operator level and make sure that the calibration parameters are hidden. Parameters are hidden using the 'Ed, t' facility described in Chapter 6, *Access Levels*


10.4 Two-point Calibration

The previous section described how to apply an offset, or trim, calibration, which applies a fixed offset over the full display range of the controller. A two-point calibration is used to calibrate the controller at two points and applies a straight line between them. Any readings above, or below, the two calibration points will be an extension of this straight line. For this reason it is best to calibrate with the two points as far apart as possible.



Proceed as follows:

1. Decide upon the low and high points at which you wish to calibrate.
2. Perform a two-point calibration in the manner described below:



Input list header

Press until you reach the input list header, 'IP L, St'.

Press until you reach the 'CAL' display.

Calibration type

- **FACT**: Factory Calibration
- **USE**: User Calibration

Use or to select 'USE'.

Selecting 'USE' enables two-point calibration.

[If two-point calibration is unsatisfactory, select 'FACT' to return to the factory set calibration.]

Press .


Select Low-point Calibration

This is the Calibration Status display. This display shows that no input is selected for calibration.

- **nonE**: No selection
- **PIL**: Input 1 (PV1) calibration low-point selected
- **PIH**: Input 1 (PV1) calibration high-point selected
- **P2L**: Input 2 (PV2) calibration low-point selected
- **P2H**: Input 2 (PV2) calibration high-point selected

Use / to select the parameter for the Low Calibration point of Input 1, 'PIL'.

Continued on next page



Adjust low-point calibration

This is the display for adjusting the Low Calibration point of Input 1. The lower readout is a live reading of the process value, which changes as the input changes.

Make sure that the calibration source is connected to the terminals of Input 1, switched on and feeding a signal to the controller. It should be set to the desired low-point calibration value. If the lower readout does not show this value, then use / to adjust the reading to the required value.

Press to return to the 'P-L, St' header.

To perform the High-point Calibration, repeat the above procedure, selecting 'P 1H' in the 'CAL.S' display for adjustment.

Press three times.

Calibration type

'USEr' was selected for the Low-point Calibration, and has remained selected.

Press

Select High-point Calibration

This is the Calibration Status display, again.

Use / to select the parameter for the High-point Calibration of Input 1, 'P 1H'.

Press

Adjust High-point Calibration

This is the display for adjusting the High Calibration point of Input 1. The lower readout is a live reading of the process value, which changes as the input changes.

Feed the desired high-point calibration signal to the controller, from the calibration source. If the lower readout does not show this value, then use / to adjust the reading to the required value.

Press to return to the 'P-L, St' header.

To protect the calibration against unauthorised adjustment return to Operator level and make sure that the calibration parameters are hidden. Parameters are hidden using the 'Ed, E' facility described in section 6.3.

To perform a User Calibration on Input 2, proceed as with Input 1 above, except that when 'CAL.S-nonE' appears, press / until 'CAL.S-P 2L' is obtained, then proceed as with Input 1. Repeat the procedure for 'P 2H'.

10.4.1 Calibration Points and Calibration Offsets

If you wish to see the points at which the User calibration was performed and the value of the offsets introduced, then these are shown in Configuration, in 'CAL-CONF'.

The parameters are:

Name	Parameter description	Meaning
PE 1L	Low calibration point for Input 1	The factory calibration point at which the low point offset was performed.
PE 1H	High calibration point for Input 1	The factory calibration point at which the high point offset was performed.
OF 1L	Offset Low for Input 1	Calculated offset, in display units.
OF 1H	Offset High for Input 1	Calculated offset, in display units.
PE 2L	Low calibration point for Input 2	The factory calibration point at which the low point offset was performed.
PE 2H	High calibration point for Input 2	The factory calibration point at which the high point offset was performed.
OF 2L	Offset Low for Input 2	Calculated offset, in display units.
OF 2H	Offset High for Input 2	Calculated offset, in display units.




Note: The value of each of the parameters in the above table may also be altered by using the   buttons..

11. APPENDIX A UNDERSTANDING THE ORDERING CODE

The 2408 and 2404 controllers have a modular hardware construction, which accepts up to three plug-in Input/Output modules and two communications modules to satisfy a wide range of control requirements. Two digital inputs and an optional alarm relay form part of the fixed hardware build.

The ordering code is in two parts. The hardware coding and an optional configuration coding. The hardware coding specifies the basic build of the controller and the plug-in modules that are fitted.



The controller may have been ordered with just the hardware build specified, or with configuration included. This is indicated by the ordering code on the side of the controller.

Hardware coding									
Basic build			Plug-in modules						
Model number	Function	Supply voltage	Module 1	Module 2	Module 3	Alarm Relay	Comms 1	Comms 2	Manual
2408	CC	VH	LH	RC	RR	RA			

Model Number	
2408	1/8 DIN Controller
2404	1/4 DIN Controller
Profibus units	
2408f	1/8 DIN Controller
2404f	1/4 DIN Controller

Function	
Standard PID control	
CC	Controller
CG	1 x 8 seg prog
CP	1 x 16 seg prog
P4	4 x 16 seg prog
CM	20 x 16 seg prog
On/Off control	
NF	Controller only
NG	1 x 8 seg prog
NP	1 x 16 seg prog
N4	4 x 16 seg prog
NM	20 x 16 seg prog
Motorised valve control	
VC	Valve positioner (VP)
VG	1 x 8 seg prog
VP	1 x 16 seg prog
V4	4 x 16 seg prog
VM	20 x 16 seg prog

Supply voltage	
VH	100 to 230Vac
VL	24Vac/dc

Module 3	
XX	Not fitted
Relay: 2-pin	
R2	Fitted unconfigured
Relay: change-over	
R4	Fitted unconfigured
PO	Program event 4 (note 7)
PE	Program END output
<i>Or Alarm 3 select from table A</i>	
Logic (non-isolated)	
L2	Fitted unconfigured
Logic (isolated)	
LO	Single logic output *
Triac	
T2	Fitted unconfigured
Dual relay	
RR	Fitted unconfigured
PP	Program event 4 & 5 (note 7)
Digital I/O (unconfigured)	
TK	Triple contact input
TL	Triple logic input
TP	Triple logic output
Power supply	
MS	24V transmitter
DC remote input	
D5	Fitted unconfigured
W2	4 to 20mA setpoint
W5	0 to 10V setpoint
WP	Second PV input
DC retrans (isolated)	
<i>Select from table B</i>	
Potentiometer input	
VU	Fitted unconfigured
VS	VP feedback
VR	Setpoint input
Transducer PSU	
G3	5Vdc
G5	10Vdc

Module 1	
XX	Not fitted
Relay: 2-pin	
R2	Fitted unconfigured
RH	PID heating
RU	Valve raise output
Relay: change-over	
R4	Fitted unconfigured
YH	PID heating
RP	Valve raise (note 6)
<i>Or Alarm 1: select from table A</i>	
Logic: (Non-isolated)	
L2	Fitted unconfigured
LH	Heating output
M1	PDS heater break detect (note 2 ¹)
M2	PDS current monitoring (note3)
Logic: (isolated)	
LO	Single logic output (fitted unconfigured)
Triac	
T2	Fitted unconfigured
TH	Heating output
TU	Valve raise output
DC control	
Isol	Non-isol
D4	D2 Fitted unconfigured
H6	H1 0-20mA PID heating
H7	H2 4-20mA PID heating
H8	H3 0-5V PID heating
H9	H4 1-5V PID heating
HZ	H5 0-10V PID heating
Digital I/O (unconfigured)	
TK	Triple contact input
TL	Triple logic input
TP	Triple logic output
Dual relay	
RR	Fitted unconfigured
RD	PID heat + PID cool
RM	Valve raise and lower
Dual triac	
TT	Fitted unconfigured
TD	PID heat + PID cool
TM	Valve raise and lower
Logic + relay	
LR	Fitted unconfigured
LD	PID heat + PID cool
QC	Mode 2 + cool
Logic + triac	
LT	Fitted unconfigured
GD	PID heat + PID cool
QD	Mode 2 + cool
Transducer P5	
G3	5Vdc
G5	10Vdc

Module 2	
XX	Not fitted
Relay: 2-pin	
R2	Fitted unconfigured
RC	Cooling output
RW	Valve lower output
Relay: change-over	
R4	Fitted unconfigured
YC	Cooling Output
RL	Valve lower (note 6)
PO	Program event output 1 (note 7)
PE	Program END segment
<i>Or Alarm 2: select from table A</i>	
Dual relay	
RR	Fitted unconfigured
PP	Program events 1 & 2 (note 7)
Logic (non-isolated)	
L2	Fitted unconfigured
LC	PID cooling
Logic (isolated)	
LO	Single logic output (fitted unconfigured)
Triac	
T2	Fitted unconfigured
TC	PID cooling
TW	Valve lower output
DC control	
Isol	Non-isol
D4	D2 Fitted unconfigured
O6	C1 0-20mA PID cooling
C7	C2 4-20mA PID cooling
O8	C3 0-5V PID cooling
C9	C4 1-5V PID cooling
CZ	C5 0-10V PID cooling
Digital I/O (unconfigured)	
TK	Triple contact input
TL	Triple logic input
TP	Triple logic output
Power supply	
MS	24Vdc transmitter
DC retrans (isolated)	
<i>Select from table B</i>	
Potentiometer input	
VU	Fitted unconfigured
VS	Valve position feedback
VR	Setpoint input
Transducer PSU	
G3	5Vdc
G5	10Vdc

Table B : DC retransmission			
D6	Fitted unconfigured		
First character		Second character	
V-	PV retrans	-1	0-20mA
S-	Setpoint retrans	-2	4-20mA
O-	Output retrans	-3	0-5V
Z-	Error retrans	-4	1-5V

Alarm relay	
XX	Not fitted
Alarm 4 relay	
RF	Fitted unconfigured
<i>Table A alarm options plus:</i>	
RA	Rate of change
PDS alarms	
LF	Heater break detect
HF	Current monitor heater brk
SF	Current monitor SSR fail
PO	Program event 7 (note 7)
PE	Program END output

Table A : Alarm relay functions	
FH	High alarm
FL	Low alarm
DB	Deviation band
DL	Low dev. alarm
DH	High dev alarm

Comms 1	
XX	None
2-wire EIA-485	
Y2	Fitted unconfigured
YM	Modbus protocol
YE	EI Bisynch protocol (note 1)
RS-232	
A2	Fitted unconfigured
AM	Modbus protocol
AE	EI Bisynch protocol (note 1)
4-wire RS-485	
F2	Fitted unconfigured
FM	Modbus protocol
FE	EI Bisynch protocol (note 1)
PDS output	
M7	Fitted unconfigured
PT	PV retransmission
TS	Setpoint retrans
OT	Output retrans
Profibus module	
PB	High speed RS485
DeviceNet	
DN	DeviceNet

Comms 2	
XX	Not fitted
PDS input	
M6	Fitted unconfigured
RS	Setpoint input
PDS output	
M7	Fitted unconfigured
PT	PV retransmission
TS	Setpoint retrans
OT	Output retrans

Manual	
XXX	No manual
ENG	English
FRA	French
GER	German
NED	Dutch
SPA	Spanish
SWE	Swedish
ITA	Italian

Configuration										
Sensor input types				Digital inputs		Options				
Sensor input	Range min	Range max	Display Units	Digital input 1	Digital input 2	Control	Power feedback	Cooling	Buttons	Program
K	0	1000	C	AM	S2	XX	XX	XX	MD	XX

Sensor input		Range min & max	
Standard sensor inputs		°C	°F
J	J thermocouple	-210 to 1200	-340 to 2192
K	K thermocouple	-200 to 1372	-325 to 2500
T	T thermocouple	-200 to 400	-325 to 750
L	L thermocouple	-200 to 900	-325 to 650
N	N thermocouple	-250 to 1300	-418 to 2370
R	Type R - Pt13%Ph/Pt	-50 to 1768	-58 to 3200
S	Type S - Pt10%Rh/Pt	-50 to 1768	-58 to 3200
B	Type B - Pt30%Rh/Pt6%Rh	0 to 1820	32 to 3308
P	Platinel II	0 to 1369	32 to 2496
Z	RTD/PT100	-200 to 850	-325 to 1562
Process inputs			
F	+/- 100mV	0 to 9999	
Y	0-20 mA Linear	0 to 9999	
A	4-20 mA Linear	0 to 9999	
W	0-5V DC Linear	0 to 9999	
G	1-5V DC Linear	0 to 9999	
V	0-10V DC Linear	0 to 9999	
Factory downloaded input			
C	*Type C	0 to 2319	32 to 4200
	W5%Re/W26%Re (Hoskins)*		
D	Type D -	0 to 2399	32 to 4350
	W3%Re/W25%Re		
E	E thermocouple	-270 to 1000	-450 to 1830
1	Ni/Ni18%Mo	0 to 1399	32 to 2550
2	Pt20%Rh/Pt40%Rh	0 to 1870	32 to 3398
3	W/W26%Re (Englehard)	0 to 2000	32 to 3632
4	W/W26%Re (Hoskins)	0 to 2010	32 to 3650
5	W5%Re/W26%Re (Englehard)	10 to 2300	50 to 4172
6	W5%Re/W26%Re (Bucose)	0 to 2000	32 to 3632
7	Pt10%Rh/Pt40%Rh	200 to 1800	392 to 3272
8	Exergen K80 I.R. pyrometer	-45 to 650	-50 to 1200
Display Units			
C	Celsius		
F	Fahrenheit		
K	Kelvin		
X	Linear input		

Digital inputs 1 & 2			
XX	Disabled	AT	Adaptive tune enable
AM	Manual select	FA	Select full access level
SR	Remote setpoint select	RB	Simulates UP button
S2	Second setpoint select	LB	Simulates DOWN button
EH	Integral hold	SB	Simulates SCROLL button
AC	Alarm acknowledge	PR	Simulates PAGE button
RP	Setpoint rate limit enable	B1	Least sig. BCD dig.
RN	Run program	B2	2nd BCD digit
HO	Hold program	B3	3rd BCD digit
RE	Reset program	B4	4th BCD digit
RH	Run/hold program	B5	5th BCD digit
KL	Keylock	B6	Most sig. BCD digit
NT	Run/Reset program	SY	Standby - ALL ops OFF
TN	Reset/Run program	SG	Skip segment (without changing SP)
HB	Prog. holdback enable	SC	Program synch.
P2	PID2 select	PV	Select PV2
ST	One-shot tune enable	AG	Advance to end of segment (& step to target setpoint)
		M5	CTX (mode 5) (input 2 only)

Range min and Range max: Thermocouple and RTD sensor inputs will always display over the full operating range shown in Sensor input table. For these inputs, the values entered here are the low and high setpoint limits. For process inputs, the values are the display scaling, corresponding to the minimum and maximum input values.

Options	
Control action	
XX	Reverse acting (standard)
DP	Direct acting PID control
Power feedback	
XX	Enabled on logic, relay & triac heating
PD	Feedback disabled
Cooling options	
XX	Linear cooling
CF	Fan cooling
CW	Water cooling
CL	Oil cooling
CO	On/off cooling
Front panel buttons	
XX	Enabled
MD	Auto/man button disabled
MR	Auto/man & run/hold disabled
RD	Run/hold button disabled
Programmer time units	
XX	Dwell & ramp in minutes
HD	Dwell time in hours
HR	Ramp rate in units/hour

The example given in the coding is for 2408 PID controller, 100 to 230 Vac supply, logic heating, relay cooling, low alarm relay, high alarm relay, RS485 Modbus comms, PDSIO setpoint retransmission, type K thermocouple, 0 to 1000°C, Auto/manual select, second setpoint select, manual button disabled.



- Notes:**
1. Not available with profibus controllers
 2. PDS heater break detect will transmit the power demand to a TE10S solid state relay and read back a heater break alarm
 3. PDS current monitoring will transmit the power demand signal to a TE10S solid state relay and read back load current and open and short circuit alarms
 4. Setpoint limits: include the decimal position required in the displayed value. Up to one for temperature inputs, up to two for process inputs
 5. An external 1% current sense resistor is supplied as standard. If greater accuracy is required, a 0.1% 2.49 Ω can be ordered as part number SUB2K/249R.1
 6. Only available with Profibus controller
 7. Not available with 8 segment programmer



Note: **PDS** is a proprietary technique for bi-directional transmission of analogue and digital data between instruments.

Mode 1: provides logic heating to a TE10S (fitted with option PDS1) solid state relay with feedback of a general load fault alarm.

Mode 2: provides logic heating to a TE10S (fitted with option PDS2) solid state relay with feedback of load current and two alarms: solid state relay failure and heater circuit failure.

12. APPENDIX B SAFETY AND EMC INFORMATION

This controller is manufactured in the UK by Eurotherm Ltd.

Please read this section carefully before installing the controller

This controller is intended for industrial temperature and process control applications when it will meet the requirements of the European Directives on Safety and EMC. Use in other applications, or failure to observe the installation instructions of this handbook may impair the safety or EMC protection provided by the controller. It is the responsibility of the installer to ensure the safety and EMC of any particular installation.

GENERAL

The information contained in this manual is subject to change without notice. While every effort has been made to ensure the accuracy of the information, your supplier shall not be held liable for errors contained herein.

Safety

This controller complies with the European Low Voltage Directive 2006/95/EC, by the application of the safety standard EN 61010.

Electromagnetic compatibility

This controller conforms with the essential protection requirements of the EMC Directive 2004/108/EC, by the application of appropriate product specific international standards.

This instrument satisfies the general requirements of the commercial and industrial environments defined in EN 61326. For more information on product compliance refer to the Technical Construction File.

Unpacking and storage

The packaging should contain an instrument mounted in its sleeve, two mounting brackets for panel installation and an Installation & Operating guide. Certain ranges are supplied with an input adapter.

If on receipt, the packaging or the instrument are damaged, do not install the product but contact your supplier. If the instrument is to be stored before use, protect from humidity and dust in an ambient temperature range of -20°C to +70°C.

SERVICE AND REPAIR

This controller has no user serviceable parts. Contact your nearest Eurotherm agent for repair.

Caution: Charged capacitors

Before removing an instrument from its sleeve, disconnect the supply and wait at least two minutes to allow capacitors to discharge. Failure to observe this precaution will expose capacitors that may be charged with hazardous voltages. In any case, avoid touching the exposed electronics of an instrument when withdrawing it from the sleeve.

Electrostatic discharge precautions

When the controller is removed from its sleeve, some of the exposed electronic components are vulnerable to damage by electrostatic discharge from someone handling the controller. To avoid this, before handling the unplugged controller discharge yourself to ground.

Cleaning

Do not use water or water based products to clean labels or they will become illegible. Isopropyl alcohol may be used to clean labels. A mild soap solution may be used to clean other exterior surfaces of the product.

INSTALLATION SAFETY REQUIREMENTS

Symbols

If any of the symbols shown below are used on the instrument they have the following meaning:

 CE Mark.
  Refer to manual.
  Risk of electric shock.
  Take precautions against static ESD symbol.
  Earth symbol.
  TCA-tick Australia (ACA) and New Zealand (RSM).
  Dispose of properly.

 China RoSH (Wheel) Logo.
  Complies with the RoHS2 (2011/65/EU) directive.
  Earlier RoHS symbol (RoSH1).
  Protected by DOUBLE INSULATION.
 
 cUL Mark.

The functional earth connection is not required for safety purposes but to ground RFI filters.

Personnel

Installation must only be carried out by suitably qualified personnel.

Enclosure of live parts

To prevent hands or metal tools touching parts that may be electrically live, the controller must be installed in an enclosure.

Caution: Live sensors

All isolated inputs and outputs have reinforced insulation to provide protection against electric shock. The non-isolated dc, logic and PDSIO outputs are all electrically connected to the main process variable input, (thermocouple etc.). If the temperature sensor is connected directly to an electrical heating element then these non-isolated inputs and outputs will also be live. The controller is designed to operate under these conditions. However you must ensure that this will not damage other equipment connected to these inputs and outputs and that service personnel do not touch connections to these i/o while they are live. With a live sensor, all cables, connectors and switches for connecting the sensor and non-isolated inputs and outputs must be mains rated.

Wiring

It is important to connect the controller in accordance with the wiring data given in this manual. Take particular care not to connect AC supplies to the low voltage sensor input or DC or logic inputs and output. Only use copper conductors for connections (except thermocouple inputs) and ensure that the wiring installations comply with all local wiring regulations. For example in the UK use the latest version of the IEE wiring regulations, (BS7671). In the USA use NEC Class 1 wiring methods.

Power Isolation

The installation must include a power isolating switch or circuit breaker. This device should be in close proximity to the controller, within easy reach of the operator and marked as the disconnecting device for the instrument.

Earth leakage current

Due to RFI Filtering there is an earth leakage current of less than 0.5mA. This may affect the design of an installation of multiple controllers protected by Residual Current Device, (RCD) or Ground Fault Detector, (GFD) type circuit breakers.

Overcurrent protection

To protect the internal PCB tracking within the controller against excess currents, the AC power supply to the controller and power outputs must be wired through the fuse or circuit breaker specified in the technical specification.

Voltage rating

The maximum continuous voltage applied between any of the following terminals must not exceed 230Vac +15%:

- relay output to logic or dc sensor connections;
- any connection to ground.

The controller should not be wired to a three phase supply with an unearthed star connection. Under fault conditions such a supply could rise above 264Vac with respect to ground and the product would not be safe.

Conductive pollution

Electrically conductive pollution must be excluded from the cabinet in which the controller is mounted. For example, carbon dust is a form of electrically conductive pollution. To secure a suitable atmosphere, fit an air filter to the air intake of the cabinet. Where condensation is likely, for example at low temperatures, include a thermostatically controlled heater in the cabinet.

This product has been designed to conform to BSEN61010 installation category II, pollution degree 2. These are defined as follows:-

Installation Category II

The rated impulse voltage for equipment on nominal 230V supply is 2500V.

Pollution Degree 2

Normally only non conductive pollution occurs. Occasionally, however, a temporary conductivity caused by condensation shall be expected.

Over-temperature protection

When designing any control system it is essential to consider what will happen if any part of the system should fail. In temperature control applications the primary danger is that the heating will remain constantly on. Apart from spoiling the product, this could damage any process machinery being controlled, or even cause a fire.

Reasons why the heating might remain constantly on include:

- the temperature sensor becoming detached from the process;
- thermocouple wiring becoming short circuit;
- the controller failing with its heating output constantly on;
- an external valve or contactor sticking in the heating condition;
- the controller setpoint set too high.

Where damage or injury is possible, we recommend fitting a separate over-temperature protection unit, with an independent temperature sensor, which will isolate the heating circuit.

Please note that the alarm relays within the controller will not give protection under all failure conditions.

Grounding of the temperature sensor shield

In some installations it is common practice to replace the temperature sensor while the controller is still powered up. Under these conditions, as additional protection against electric shock, we recommend that the shield of the temperature sensor is grounded. Do not rely on grounding through the framework of the machine.

INSTALLATION REQUIREMENTS FOR EMC

To ensure compliance with the European EMC directive certain installation precautions are necessary as follows:

- For general guidance refer to Eurotherm EMC Installation Guide, HA025464.
- When using relay or triac outputs it may be necessary to fit a filter suitable for suppressing the emissions. The filter requirements will depend on the type of load.
- If the unit is used in table top equipment which is plugged into a standard power socket, then it is likely that compliance to the commercial and light industrial emissions standard is required. In this case to meet the conducted emissions requirement, a suitable mains filter should be installed.

Routing of wires

To minimise the pick-up of electrical noise, the wiring for low voltage dc and particularly the sensor input should be routed away from high-current power cables. Where it is impractical to do this, use shielded cables with the shield grounded at both ends. In general keep cable lengths to a minimum.

13. APPENDIX C TECHNICAL SPECIFICATION

Main Process Value Input and Second DC Input

Low level range	$\pm 100\text{mV}$
High level range	0 to 10Vdc or 0-20mA with external 2.49Ω current shunt. All configurable between limits
Sample Rate	9Hz (110mS)
Resolution	$<2\mu\text{V}$ for low level range, $<0.2\text{mV}$ for high level range, with default input filter time constant of 1.6 seconds.
Linearity	Better than 0.2°C
Calibration accuracy	The greater of 0.25% of reading or $\pm 1^\circ\text{C}$ or $\pm 1\text{LSD}$
User calibration	Low and high offsets can be applied
Input filter	Off to 999.9 secs Default 1.6 seconds.
Thermocouple types	Refer to the ordering code sensor input table
Cold junction compensation	>30 to 1 rejection of ambient temperature changes in automatic mode. Uses INSTANT ACCURACY™ cold junction sensing technology to eliminate warm up drift and to respond quickly to ambient temperature changes. External references 0, 45, and 50°C
RTD/PT100 input	3-wire, Pt100 DIN43750. Bulb current 0.3mA. Up to 22Ω in each lead without error
Potentiometer input	100 to 15Kohm
Analogue input functions	Process value, remote setpoint, setpoint trim, external power limit, feedforward input,, valve position feedback
Second process value input functions	Select min, select max, derived value, transfer to 2 nd PV

Digital inputs

Isolated except for fixed digital inputs 1 & 2

Contact closure inputs	Open circuit voltage: 24 to 30 Vdc Short circuit current: 24 to 29mA Off state: < 100 ohms input resistance On state: $> 28\text{Kohm}$ input resistance
Logic inputs	Off state: -3 to 5Vdc @ $<-0.4\text{mA}$
(current sinking)	On state: 10.8 to 30Vdc @ 2.5mA
Digital input functions	Refer to the ordering code

Digital Outputs

Relay rating	Min: 12V, 100mAdc. Max: 2A, 264Vac resistive
Single logic output	18Vdc, 20mA. This output is not isolated from the main process value input
Triple logic output	12Vdc, 8mA per channel (isolated)
Digital o/p functions	As per the ordering code
High current output	10Amp, 264Vac resistive. This option is not available on controller from Jan-04
Triac rating	1A, 30 to 264Vac resistive (isolated)

Analogue outputs

Range	Scaleable between 0-20mA and 0-10Vdc (isolated)
Resolution	1 part in 10,000 for analogue retransmission
Analogue output functions	Refer to ordering code

Transmitter supply

Rating 20mA, 24Vdc

Control functions

Control modes On/Off, PID, or motorised valve control, with or without feedback potentiometer

Cooling algorithms Linear, water (non-linear), fan (min on time), oil

Tuning One shot (automatic tune of PID and overshoot inhibition parameters) and continuous adaptive tuning

Number of PID sets Two

Auto/manual control Bumpless transfer or forced manual output available

Setpoint rate limit Display units per second, minutes or hour

Alarms

Number of alarms Four

Alarm types Absolute high or low. Deviation band, deviation high, deviation low. Rate of change

Alarm modes Latching or non-latching. Blocking. Energised or de-energised in alarm

Setpoint programming

Number of programs 1, 4 or 20

Segments per program 16

Event outputs Up to eight

Communications (all modules are isolated)

Profibus High speed, RS485. Up to 1.5Mb/s

Modbus ® RS232,2-wire,RS 485 and 4 wire RS485 modules

Baud rate 1200, 2400, 4800, 9600 and 19,200 baud

PDS

Slave input (isolated) Remote setpoint input with holdback to master

Master output Isolated from main PV. Retransmission of setpoint, process value or output

General

Display Dual, 4 digit x 7 segment LED. Up to two decimal places

Supply 100 to 230Vac $\pm 15\%$, 48 to 62 Hz, 10 W max OR
24Vdc or ac -15%, +20%. 10W max

Operating ambient 0 to 55°C and 5 to 90% RH non-condensing

Storage temperature -10 to +70°C

Panel sealing IP65

Dimensions 2408: 48mm wide x 96mm high x 150mm deep
2404: 96mm wide x 96mm high x 150mm deep

Weight 250g

EMC standards EN61326-1 generic standards for industrial environments

Safety standards Meets EN61010, installation category II (voltage transients must not exceed 2.5kV), pollution degree 2

Atmospheres Not suitable for use above 2000m or in explosive or corrosive atmospheres. Electrically conductive pollution must be excluded from the cabinet in which this controller is mounted

14. APPENDIX D LOAD CURRENT MONITORING AND DIAGNOSTICS

Current flowing in a system of electrical heating elements (the 'Load') can be displayed on the controller by using a TE10 SSR fitted with intelligent current transformer, PDCTX, or an SSR or contactor with an external PDCTX.

Load current monitoring and diagnostics may be used with any time proportioned output, fitted in module position 1A, and uses the logic output wires which drive the SSR to return signals back to the controller. These signals represent the RMS value of the load current during the ON period, or load related alarm conditions. It is not designed for analogue outputs i.e. phase angle control.

It is also designed for single phase operation only.

There are three modes of operation:-

1. Mode 1

Detects if there is a **break in the heater circuit**. This includes heater or SSR open circuit. A single **Load Failure** alarm message is displayed on the lower readout of the controller.

2. Mode 2

Provides the following:-

Display of true RMS load current On the lower readout of the controller	Displays the true RMS current in the ON state to the load.
Low current alarm Analogous to Partial Load Failure (PLF) supplied in some SSRs	Provides advanced warning of failure of one or more heaters in parallel
High current alarm Activated when the heater exceeds a set limit	Typically used where element bunching may occur
SSR short circuit	This will apply full power to the heaters which could result in an over temperature condition. This alarm provides early warning.
Heater failure	Indicates open circuit load conditions

3. Mode 5

Provides the same features as mode 2 with two additional alarms. This mode is for use with contactors or other devices which do not use the PDS logic output from the controller as the drive signal. For example, a time proportioning logic, relay or triac output to operate a contactor. Mode 5, therefore, requires an additional input to the controller to display the load conditions. It uses the LB digital input terminals for this, as shown in Figure 38: Connections for contactor operation (mode 5).

Current Transformer Open Circuit	Alarm is shown if the PDS connection to PDCTX or SSR become disconnected
Current Transformer Short Circuit	Alarm is shown if the PDS connection from PDCTX or SSR are short circuited

14.1 Example Wiring Diagram (For mode 1 & 2 operation)

Hardware Required

1. SSR type TE10/PDS2 OR
2. Intelligent current transformer type PD/CTX + contactor or zero voltage switching SSR
3. 2408 or 2404 controller configured for PDS mode 2 option using logic output. This module must be fitted in module position 1. (order code **M2**).




Figure 37: Connections for Mode 1 & 2




Warning: Take care that the controller is correctly wired for the mode of operation which is configured. Failure to do so may be hazardous in some situations.

14.2 Example Wiring Diagram (for mode 5 operation)

Hardware Required

1. Intelligent current transformer type PD/CTX + contactor
2. 2408 or 2404 controller configured for PDS mode 5 option using logic, relay or triac output. This module must be fitted in module position 1. Digital input LB (order code M5) must be configured to accept PDCTX input as described in the configuration section of this appendix.



The controller will have the order code M5 in the Logic Input position.

Figure 38: Connections for contactor operation (mode 5)



Warning: Take care that the controller is correctly wired for the mode of operation which is configured. Failure to do so may be hazardous in some situations.

14.3 Operation

14.3.1 To Read Load Current (modes 2 and 5 only)

Do This	This Is The Display You Should See	Additional Notes
From the 'i nFa' list Press  until <i>AmPS</i> is shown in the upper display	  Current will be displayed in the lower readout. See also 'Display Modes' below. This display will be shown if: - The controller is unable to resolve the reading - The controller is obtaining a reading - The measurement has timed out i.e. current has not flowed for 15 seconds, in mode 2.	It will revert to the HOME display after 45 seconds or 10 seconds if an alarm is present

14.3.2 To Display Load Current Continuously in the Lower Readout (modes 2 and 5 only)

Do This	This Is The Display You Should See	Additional Notes
From the 'HOME' display, Figure 20. Press  until <i>d, SP</i> is shown in the upper display Press  or  until <i>AmPS</i> is displayed in the lower display		Current will be displayed in the lower readout continuously when the controller reverts to the HOME display, see also 'Display Modes' below.

14.3.3 Display Modes

SSR RMS On State Current

This is the default state when high or low current alarms are configured. The load current displayed is the steady state true rms current measured during the ON period.

The minimum on times are:-


Mode 2 0.1 second

Mode 5 3 seconds

Meter Mode

Meter mode applies to mode 5 only. If low current alarms are **not** configured the current displayed is a filtered instantaneous RMS value. This behaves like a damped analogue meter. It may be used in applications where the current sensor is not linked to control, for example, telemetry, indication.


14.3.4 How Heater Alarms are Displayed

Do This	This Is The Display You Should See	Additional Notes
If an alarm is present it will flash a four character mnemonic in the lower display	Actual Temperature (PV) →  The image shows a digital display labeled 'HOME Display'. It has two small boxes at the top labeled 'OP1' and 'OP2'. The main display shows '20.0' in large digits and 'ILLr' in smaller digits below it. At the bottom, there are four icons: a square, a circle with a right arrow, an up arrow, and a down arrow.	If more than one alarm is active, the display will alternate between the alarm messages and the default parameter in the lower display

The Alarm Messages are:-

Mnemonic	Meaning	Description
The following two messages are alarms which are produced as a result of failure within the process. In place of dashes the alarm number will appear i.e 1, 2, 3, or 4		
-LLr	Alarm number - <u>L</u> ow <u>C</u> urrent	Used for partial load failure detection. To avoid nuisance tripping due to supply voltage variations set to a value at least 15% below the minimum normal operating current
-HLr	Alarm number - <u>H</u> igh <u>C</u> urrent	Used for load overcurrent protection. To avoid nuisance tripping due to supply voltage variations set to a value at least 15% above the maximum normal operating current. Note: This alarm is not intended to provide instantaneous safety protection from short circuit fault conditions
The following message is a diagnostic alarm which appears for mode 1 operation only.		
LdF	<u>L</u> oad <u>F</u> ail	This includes failure of the heater circuit or the SSR
The following four messages are diagnostic alarms produced as a result of failure within the equipment or wiring connections. They appear for modes 2 and 5 operation only. They may be enabled using the <u>d</u> i <u>AL</u> parameter in the <u>AL</u> <u>L</u> i <u>St</u> , see 'SHORT CIRCUIT SSR ALARM AND HEATER FAIL ALARM'		
Htr.F	<u>H</u> ea <u>t</u> er <u>F</u> ail	No current is being drawn while the controller output demand signal is on
SSr.F	<u>S</u> SR <u>F</u> ail	The load is continuously on while the controller output demand signal is off
Ct.OP	<u>C</u> urrent <u>T</u> ransformer <u>O</u> pen <u>C</u> ircuit	Indicates that the PDS input is open circuit. Mode 5 only
Ct.Sh	<u>C</u> urrent <u>T</u> ransformer <u>S</u> hort <u>C</u> ircuit	Indicates that the PDS input is short circuit Mode 5 only

14.3.5 To Set The Alarm Trip Levels

Do This	This Is The Display You Should See	Additional Notes
From the HOME display press  until the AL L, St is displayed		To select the Alarm List header
Press  button until the desired alarm number is displayed Press  or  to adjust the alarm trip level	 	To select the diagnostic alarm parameter found under the Alarm List header The alarm trip level is set to 999

14.3.6 Short Circuit SSR Alarm and Heater Fail Alarm

These alarms exist as **Diagnostic Alarms** in the controller. To make the alarm active it is only necessary to turn on the diagnostic alarm feature in the Alarm List in the Operator Level

Do This	This Is The Display You Should See	Reason
From the HOME display press  button until the AL L, St is displayed		This opens the list which contains the d, AG mnemonic
Press  until d, AG is displayed Press  or  to select YES		This activates the d, AG mnemonic to allow Diagnostic Alarms to be displayed in the lower readout of the HOME display

14.3.7 Relay Outputs

The fixed relay output connected to terminals AA to AC in a 1/8 or 1/4 DIN controller is normally used for alarm purposes. In addition, any plug in module can be used for alarms provided they are not already being used for another purpose, such as control. Any one or more alarms can be attached to an output, which will operate when an alarm occurs. Contacts are rated at 2A 264Vac for operating external beacons or audible devices.



14.3.8 To Configure PDS Load Current Diagnostics

Configuration of PDS load current diagnostics is in four parts:-



1. Configure the Logic Module for PDS Mode 1 or 2 operation. If the control device is a contactor or standard SSR, configure the LA digital input for mode 5 operation.
2. Configure the Low and High Current trip alarms.
3. Attach the alarms to operate an output relay.
4. Set up the Scaling Factor.

First enter Configuration Level. See Chapter 9

14.3.9 To configure the Logic Module for PDS Modes 1 or 2

Do This	This Is The Display You Should See	Additional Notes
Press  until the 1A CONF is displayed		This opens the configuration list associated with module position 1A
Press  to show 1d		This shows the identity of the module The module identity is <u>logic</u> output
Press  to show Func Press  or  to show SSr 1 or SSr 2 as required.		This shows the <u>function</u> of module The module function is set to PDS mode 1
Press  to show VAL L Press  or  to show 0.0		This is the lower PID demand level shown set to 0%
Press  to show VAL H Press  or  to show 100.0		This is the upper PID demand level shown set to 100%
Press  to show OUT L Press  or  to show 0.0		This is the minimum output power shown set to 0
 Warning: Take care that the controller is correctly wired for the mode of operation which is configured. Failure to do so may be hazardous in some situations.		
Press  to show OUT H Press  or  to show 100.0		This is the maximum output power To set the max output power to 100
Press  to show SEnS Press  or  to show nor		This sets the output signal to normal for heating control

14.3.10 To configure Logic Input B for PDS (Mode 5 only)

Do This	This Is The Display You Should See	Additional Notes
Press  button until the Lb Conf is displayed		
Press  to show id		This identifies the LA input as logic and is read only
Press  to show Func Press  or  to select AmPS		To configure the input for the PDCTX.

The system is designed to operate in either mode 2 or mode 5 configuration only. Selecting both simultaneously will disable the output. However, mode 1 and mode 5 can be used together.

14.3.11 To Configure Low and High Current Trip Alarms

Alarm 1 will be configured as Load Current Low (**Lcr**)

Alarm 2 will be configured as Load Current High (**Hcr**)


Do This	This Is The Display You Should See	Additional Notes
Press  button until the AL Conf is displayed		This opens the configuration list which contains the Alarms
Press  to show AL 1 (alarm 1) Press  or  to show Lcr		To select alarm 1 To make alarm 1 = <u>L</u> ow <u>C</u> urrent After 0.5 sec the display will blink to show the alarm type has been accepted
Press  until AL 2 (alarm 2) appears Press  or  to show Hcr		To select alarm 2. To make alarm 2 = <u>H</u> igh <u>C</u> urrent After 0.5 sec the display will blink to show the alarm type has been accepted




Note: The above alarms are known as **SOFT ALARMS** because they are indication only.

14.3.12 To Attach Soft Alarms To A Relay Output

Any one alarm indicated above may be attached to an output (normally a relay). Alternatively any combination of alarms may be attached to operate a relay using the procedure below:-

Do This	This Is The Display You Should See	Additional Notes
Press "PAGE" key  as many times as necessary to AA Conf		To select the output which you want to operate when the alarm condition occurs. You may also choose 1A, 1B, 1C, 2A, 2B, 2C, 3A, 3B, 3C or 4A depending upon the controller and the number and type of modules fitted
Press  until 1--- is displayed Press  or  to select YES or Repeat the above step for every alarm to be attached to the output		1--- denotes alarm 1 followed by three letters which denote the alarm type e.g. LCr YES means that the selected output will activate when an alarm occurs in normal operation no means the output will not activate



14.3.13 The Scaling Factor

The value of the current displayed on the controller is scaled using the scaling factor. This is found in the **Inst Conf** list. It is set, by default, to 100 and assumes a single turn through the current transformer. If two turns are made through the current transformer it will be necessary to adjust the scaling factor to 50 to obtain the same reading.

Under normal conditions you should not need to change the scaling factor.

If, however, you wish to change the sensitivity of the current reading, for example, to read very low currents you may need to change the number of turns through the PDCTX and/or adjust the scaling factor to compensate. See also note 1 below.

14.3.14 To adjust the scaling factor

Do This	This Is The Display You Should See	Additional Notes
Press  button until Inst Conf is displayed		
Press  until LEH is displayed Press  or  to change the scaling factor		



Note: Minimum Resolvable Current

TE10 4A RMS. It is not possible to read currents lower than 4A when using a TE10.
PDCTX 4A RMS for a single turn through the PDCTX

Should you wish to read currents lower than 4A using a PDCTX it is necessary to increase the number of turns through the PDCTX and adjust the scaling factor to compensate.

For example: To read 1.0A wind 4 turns through the PDCTX and adjust the scaling factor to 25 as shown in the table below.

Scalar = 100/N Where N = Turns through PDCTX

N	Scalar	N	Scalar
1	100	5	20
2	50	10	10
4	25		



Note: Maximum Resolvable Current

TE10 Determined by the maximum range of the SSR
PDCTX 100A (or 100 ampere turns)

Finally Exit configuration level. See section 9.2.

15. APPENDIX E: PROFIBUS COMMUNICATIONS

15.1 Introduction

The 2408*f* and 2404*f* are special versions of the 2408 and 2404 controllers designed for Profibus-DP communications. The 'standard' 2408 or 2404 controllers cannot be upgraded to a 2408*f* or 2404*f* as the latter uses a different version of the microprocessor board.

Profibus-DP is available with either the 85 to 264Vac or 20-29Vac/dc supply

Apart from the restrictions listed below, the operation, functions and wiring of the 2404*f* and 2408*f* are identical to that of the standard 2408 and 2404 controllers.

- Modbus communications may be configured to replace Profibus-DP if required.
- This must be installed in module slot H.
- EI Bisynch protocol is not supported, therefore the IPSG instrument programming system cannot be used.
- The 20 programmer option is not available.
- The PDSIO input and output modules can only be installed in module slot J.

15.2 About Profibus-DP

Profibus-DP is an industry standard, open network used to connect simple devices in a machine or manufacturing plant. It is most often used to allow a central Programmable Logic Controller or PC based control system to use external 'slave' devices for I/O or specialised functions. One advantage is that these devices may be distributed around a machine, saving on the cost of point to point wiring. The 'open' nature of the network permits equipment from different manufacturers to be mixed easily so that best of breed equipment may be used. Additionally, the off-loading of specialised tasks such as PID temperature control lessens the processing load on the central PLC so that its other functions may be carried out more efficiently.

Profibus-DP is described in DIN 19245 Part 3, and is part of EN 50170.

The Profibus-DP network uses a high speed version of the RS485 standard, permitting baud rates of up to 12Mbaud. The 2408*f* and the 2404*f* support rates of up to 1.5 Mbaud in order to meet electrical isolation standards. A table of network speed against line length is given in the section on wiring below.

Up to 32 Profibus stations (nodes) may be wired to a single network segment. Use of RS485 repeaters allows a total of up to 127 stations.

Other variants of Profibus that exist are Profibus FMS, which is designed to allow higher level communication such as that between PLCs and SCADA systems, and Profibus PA, which has an optional low speed, intrinsically safe, physical medium and is designed for use in the Process Industry. The 2408*f* and 2404*f* controllers can be used on a combined DP and FMS network, sharing the same physical medium, but may only be used for PA when the intrinsically safe physical medium is not used.


Profibus-DP is a multimaster, master-slave, token passing network. The 2408*f* and the 2404*f* operate as intelligent slave units. More detailed information, including a detailed guide to products available, may be obtained from the various world wide Profibus user organisations. You will find contact information in trade magazines or by reference to <http://www.profibus.com> on the World Wide Web.

15.3 Technical Specification

Physical Medium	2-wire RS485
Network topology	Linear bus with active termination of the bus at both ends Stub lines permitted if < 6.6m in length
Protocol	Profibus-DP, intelligent slave
Baud rate	Up to 1.5Mb/s
Number of stations	32 per network segment. Up to 127 with repeaters

15.4 Electrical Connections

The diagram below is also shown in section 4.6.



15.4.1 Cable Specifications

Either of the two cable types detailed below can be used. Please note that the cable types A and B, specified below, are NOT related to the wire numbers A and B in the above wiring diagram. Type A is recommended as it allows higher speed and longer cable length.

	Type A cable	Type B cable
Characteristic Impedance:	135 to 165Ω at a frequency of 3 to 20 MHz.	135 to 165Ω at a frequency of > 100 kHz
Cable capacitance:	< 30 pF per Metre	typ. < 60 pF per Metre
Core diameter:	max. 0.34 mm ² , corresponds to AWG 22	max. 0.22 mm ² , corresponds to AWG 24
Cable type:	twisted pair cable. 1x2 or 2x2 or 1x4 lines	twisted pair cable. 1x2 or 2x2 or 1x4 lines
Resistance:	< 110 Ohm per km	-
Shielding:	Copper shielding braid or shielding braid and shielding foil	Copper shielding braid or shielding braid and shielding foil

15.4.2 Maximum Line Length per Segment

Baud rate (kbit/sec)	9.6	19.2	93.75	187.5	500	1500
Type A cable	1200m	1200m	1200m	1000m	400m	200m
Type B cable	1200m	1200m	1200m	600m	200m	-

Belden B3079A meets cable A specifications, but there are other choices. For more information refer to the 'Profibus Product Guide' produced by the Profibus User Group.

15.5 Controller Configuration and Node Address

Having connected the controller to the network, it must be configured for Profibus communications and a node address assigned.


15.5.1 Configuration

In the *HA* list set *Func* = *Prof*.



Comms configuration list - *HA*

Refer to the main handbook for instructions on how to select configuration level and access the *HA* list



Identity of module

This should be a read-only parameter displaying *Cms*



Function

Set *Func* = *Prof* to select Profibus protocol



Resolution *Full* = Full, *Int* = Integer

This is the only other parameter that appears in this list when *Prof* is selected as the function.



Note: The baud rate is automatically selected by the master.


15.5.2 Assigning a Node Address

Refer to the main handbook for instructions on how to select and change parameters.



Comms list

From the HOME display, press  until you reach the *Cms* list



Node address

Press  to display the node address. Press  or  to set the desired address. 0 - 126



Comms Status

This is a read-only diagnostic display

rdy Ready to run

run Comms running

15.6 Network Configuration

Having wired and configured the controller, the PLC or PC based supervisory package must be configured to set-up the parameters that it will be able to read and write to. This is known as 'network configuration'

The network is configured by importing 'GSD' files into your Master Profibus network configuration software: Refer to the network configuration software documentation for details. 'GSD' is an acronym of a German phrase meaning 'Device Database'.

GSD files for the 2408*f* and 2404*f* controllers are created using a Windows based configuration tool. This is separately supplied under ordering code PROF-ENG. A Communications Handbook (part number HA026290ENG), supplied with the configurator, gives all the required information

Two standard GSD files, are supplied on the disc:


EURO2400.GSD	standard parameter mapping
EURD2400.GSD	standard parameter mapping with 'demand data', which allows random read/write to any parameter within the controller.

It is possible to edit the above files or create new files using the Windows configurator. Details are given in the communications handbook.

The Master network configuration software uses the GSD files to produce a further file which is downloaded into your master PLC or PC supervisory package. Once the configuration file has been downloaded, you can set the network running. If all is well, the 'REM' beacon on the controller will start to flash, indicating that the data exchange is proceeding. The *STATUS* parameter in the *cms* list will show *run*. You may then write to Profibus outputs, and read from Profibus inputs as required by your control strategy.

In case of problems, a troubleshooting section is provided on the next page.

Windows configurator



What does it do?
It creates a 'GSD' file which defines the inputs and outputs that the PLC or supervisory package will be able to talk to. The GSD file is imported into a Profibus Master configuration tool which in-turn produces a file that is downloaded into the PLC or supervisory package.

How do I use it?
Click on the tabs at the bottom of the device parameter window to select a parameter page. Then use the mouse to drag a required parameters into either the Profibus input or output lists.


How many parameters can I select?
Up to 117 per node, total of inputs and outputs.

What can I run it on?
Windows 3.1, Windows 95, or Windows NT.

15.7 Troubleshooting

15.7.1 No Communications:

- Check the wiring carefully, paying particular attention to the continuity of the A and B connections to the Master. Ensure that the correct terminals have been wired to.
- Access the HA list in configuration level and check that the function (Func) is set to Prof. If not, the controller is not configured for Profibus.
- Check that the Node Address (Addr) in the cMS list is correct for the network configuration in use.
- Ensure that a Profibus Comms Module is installed in slot H of the 2404/8f. It can be identified by of the legend on the plug-in module casing, and its distinctive shape:



- Ensure that the network is correctly configured and the configuration has been transmitted correctly to the Profibus master.
- Verify the GSD file in use is correct by loading it into the master GSD Configuration tool. This will check the format.
- Verify that the maximum line length for the baud rate in use is not exceeded (see 15.4.2. Note that the 2404/8f is restricted to use at a maximum rate of 1.5 Mbaud.
- Ensure that the last device (not necessarily a 2404/8f) in the network segment is correctly terminated (see wiring diagram).
- Ensure that no devices other than those at the end of a segment have termination networks fitted.
- If possible, replace faulty device with a duplicate and retest.

Intermittent failure to communicate.

Intermittent flickering of status from *rdy* to *run*.

Diagnostic status changing but no alarms present in the controller.

- Verify wiring, paying particular attention to screening.
- The I/O data length may be too long. Some Profibus DP Master implementations can accept no more than 32 input and 32 output words per slave device. Verify by reference to documentation of the Master.
- Verify that the maximum line length for the baud rate in use is not exceeded (see cable specifications). Note that the 2404/8f is restricted to use at a maximum rate of 1.5 Mbaud.
- Ensure that the last device (not necessarily a 2404/8) in the network segment is correctly terminated (see wiring diagram).
- Ensure that no devices other than those at the end of a segment have termination networks fitted.
- Verify operation with a duplicate device if possible.

This page is intentionally blank

Eurotherm: International sales and support

www.eurotherm.com

Contact Information

Eurotherm Head Office
Faraday Close,
Durrington,
Worthing, West Sussex,
BN13 3PL

Sales Enquiries

T +44 (01903) 695888
F 0845 130 9936

General Enquiries

T +44 (01903) 268500
F 0845 265982

Worldwide Offices
www.eurotherm.com/global



Scan for local contacts

Represented by:

© Copyright Eurotherm Limited 2014

Eurotherm by Schneider Electric, the Eurotherm logo, Chessell, EurothermSuite, Mini8, Eycon, Eyris, EPower, EPack, nanodac, piccolo, versadac, optivis, Foxboro and Wonderware are trademarks of Schneider Electric, its subsidiaries and affiliates. All other brands may be trademarks of their respective owners. All rights are strictly reserved. No part of this document may be reproduced, modified, or transmitted in any form by any means, nor may it be stored in a retrieval system other than for the purpose to act as an aid in operating the equipment to which the document relates, without the prior written permission of Eurotherm Limited. Eurotherm Limited pursues a policy of continuous development and product improvement. The specifications in this document may therefore be changed without notice. The information in this document is given in good faith, but is intended for guidance only. Eurotherm Limited will accept no responsibility for any losses arising from errors in this document.