

Power Series

User's Manual



Microprocessor-Based SCR Power Controller



TOTAL
CUSTOMER
SATISFACTION
3 Year Warranty



U.S. English

1241 Bundy Boulevard, P.O. Box 5580, Winona, Minnesota USA 55987-5580
Phone: +1 (507) 454-5300, Fax: +1 (507) 452-4507 <http://www.watlow.com>

0600-0039-0000 Rev H
July 2012
Supersedes: 0600-0039-0000 Rev G

Made in the U.S.A.
\$10.00



Safety Alert
CAUTION or
WARNING



Electrical
Shock Hazard

CAUTION or
WARNING

Safety Information in this Manual

Note, caution and warning symbols appear throughout this book to draw your attention to important operational and safety information.

A “NOTE” marks a short message to alert you to an important detail.

A “CAUTION” safety alert appears with information that is important for protecting your equipment and performance.

A “WARNING” safety alert appears with information that is important for protecting you, others and equipment from damage. Pay very close attention to all warnings that apply to your application.

The  symbol (an exclamation point in a triangle) precedes a general CAUTION or WARNING statement.

The  symbol (a lightning bolt in a lightning bolt in a triangle) precedes an electric shock hazard CAUTION or WARNING safety statement.

Technical Assistance

If you encounter a problem with your Watlow controller, see the Troubleshooting Table in the Appendix and review all of your configuration information to verify that your selections are consistent with your application: inputs; outputs; alarms; limits; etc. If the problem persists after checking the above, you can get technical assistance from your local Watlow representative, or by dialing +1 (507) 454-5300, 7:00 a.m. to 7:00 p.m. Central Standard Time.

An applications engineer will discuss your application with you.

Please have the following information available when you call:

- Complete model number
- All configuration information
- User's Manual
- Diagnostic Menu readings

Warranty and return information are on the back cover of this manual.

Your Comments

Your comments or suggestions on this manual are welcome. Please send them to the Technical Literature Team, Watlow Winona, 1241 Bundy Boulevard, P.O. Box 5580, Winona, Minnesota, 55987-5580 U.S.; Telephone: +1 (507) 454-5300; fax: +1 (507) 452-4507. The Power Series User's Manual is copyrighted by Watlow Winona, Inc., © 2007, with all rights reserved. (2211)

Power Series

Table of Contents

Chapter 1: Overview	1.1	Appendix	A.1
Chapter 2: Installation	2.1	Troubleshooting	A.2
Dimensions	2.2	Troubleshooting Alarms and Errors ..	A.4
Mounting the Power Series	2.2	Checking and Replacing Fuses	A.6
Enclosure Guidelines	2.3	Power Series Backup	A.7
Harsh Environments	2.3	Modbus™ Register Numbers	A.8
Removing the Power Series	2.4	Product Specifications	A.9
Maintaining the Power Series	2.4	Ordering Information	A.10
Output Rating Curves	2.5	Index	A.11
Chapter 3: Wiring	3.1	Prompt Index	A.13
Torque Guidelines	3.1	CE Declaration of Conformity	A.14
Input Wiring	3.2	Warranty and Returns Policy ..	back cover
Line Power/Output Wiring	3.4		
Wiring Example	3.6		
Chapter 4: Navigation and Software	4.1		
Keys and Displays	4.1		
Navigation	4.2		
Software Map	4.3		
Chapter 5: Control Methods and Features .5.1			
Zero Cross	5.1		
Phase Angle	5.2		
Other Features	5.6		
Input	5.6		
Alarms	5.7		
Communications	5.8		
Retransmit	5.9		
Fast Start Guide	5.10		
Chapter 6: Parameters	6.1		
Display Loop	6.1		
Setup Page	6.5		
Factory Page	6.14		
Factory Mode	6.20		

Chapter One Overview

Introduction

The Power Series is a state-of-the-art microprocessor-based Silicon Controlled Rectifier (SCR) power controller intended for controlling industrial heaters. This product is based on one package with several configurations that include single phase, three phase, and single phase-multizone capabilities. Each package configuration has a specific current rating depending on the number of phases switched. The switching capabilities include 65 to 250A rms at 50°C from 24 to 600V~ depending on the configuration or model number selected. See page 1.2 for additional information on the Power Series configuration options.

Removable Mounting Plate

Power Series snaps on a pre-mounted, removable plate.

Terminal Cover


Electrically touch-safe package.

Fuse Cover

Slides up and down for fuse maintenance and covers the high voltage components.

Digital Programmer/Display

For controller configuration, setup, and monitoring features.

**Ground Lug**

Built in, designed for easy ground connections.

I/O Port

Input, retransmit output, communications, and alarms.

On-Board Fan

A fan is integrated into the package on forced air cooled models to eliminate separate power connection for fan.

Allen Wrench

Used to torque terminals 1 to 6 and ground lug.

Figure 1.1 — Power Series features.

Single Phase

This configuration can be purchased with any or all the features available on the Power Series. The only limitations are the features selected by the customer upon purchase. It has the highest current rating of all configurations since it is only switching one phase of the ac line. It is intended for resistive heaters, but can also be used on transformer connected loads in the phase angle firing mode.

Three Phase, Two-Leg Configuration

This configuration is intended for zero cross firing into a stable resistive heater, i.e., nichrome element. Typically, a three phase, three-wire delta or ungrounded wye/star connected heater is most often used where only two of the three V~ line phases are switched. The third phase is a direct connection through a bussbar on board the Power Series and is controlled by the previous two phases. For this reason, a two-leg configuration should not be used for three phase grounded wye/star connected heaters. (For heaters that are required to be three phase grounded wye/star connected, see “Three Phase, Three-Leg Configuration” section below.)

Because this configuration does not allow phase angle firing, it should not be used on transformer coupled heaters and less stable resistance heaters such as silicon carbide, molybdenum disilicide, carbon graphite, or tungsten lamp heaters. This may cause premature heater failure or nuisance fuse blowing.

Heater current monitoring and kVA options are available with a three phase, two-leg configuration via the heater diagnostics option. Phase angle firing, including current limiting and heater bakeout, is not available.

Three Phase, Three-Leg Configuration

There are two Power Series configurations that include six SCR control. All features are available in these configurations.

The three-leg version is intended for phase angle firing into a transformer connected load or direct connection to heating that requires soft start and/or current limiting.

The four-wire configuration is intended for zero cross firing into a four-wire wye connected nichrome/resistive heater.

Single Phase, Multizone Configuration

This configuration is available in two and three single phase zones. Back-to-back SCRs are used and all of the features of a single phase unit are available. (Note that there is only one alarm relay and all zones in the controller must use the same control method.) This configuration is intended for applications with multiple command signals from independent control zones. The multizone platform offers reduced panel space compared to using multiple single phase power controllers.

Heater Diagnostics

Heater diagnostics is a key feature of the Power Series SCR power controller. Heater diagnostics may include all or only some of the features that require heater current monitoring, depending on the model selected. Heater current monitoring is only available with heater diagnostics installed on the controller. The features dependent on heater current monitoring are heater bakeout, current limiting, heater current and kVA monitoring, retransmit, and heater monitoring alarms such as open heater, heater out of tolerance, load balance, and shorted SCR detection/error. Heater diagnostics must also be installed if you need phase angle control with current limit.

Chapter Two

Installation



WARNING:

To avoid potential electric shock and other hazards, all mounting and wiring for the Power Series must conform to the National Electric Code (NEC) and other locally applicable codes.

NOTE: Ground must be wired with the same size wire as line and load connections to a ground of sufficient current carrying capacity.

NOTE: Integral semiconductor fuses do not qualify as branch circuit protection.

The following two chapters will explain how to install the Power Series controller. Watlow power controllers are thoroughly tested before leaving the factory, so the Power Series controller is ready to install when you receive it.

Chapters 2 and 3 describe the steps required to install the Power Series controller. Refer to Chapter 2 for mounting information and Chapter 3 for input, power, and load wiring of the Power Series.

Before beginning installation, read through these chapters to gain an understanding of the entire installation. Consider the installation carefully. Plan the power, load, and input signal wiring before mounting the Power Series. Also consider the cabinet space, controller dimensions, wire bending radius, and airflow. Use good wiring practices to minimize electrical noise problems.

Power Series Wire Bending Radius at Base Current and Ambient Temperature Rating and Replacement Semiconductor Fuses

Minimum recommended wire sizes are based on the NEC 30°C ambient with not more than three current carrying conductors in raceway or cable, while also considering the Power Series 50°C enclosure temperature and semiconductor fuse rating. Use copper conductors only.

The terminal lug wire range for all Power Series amperages is 350 MCM to 6 AWG. The recommended terminal torque is 180 in.-lbs. (20 Nm.). Refer to page 3.1 for torque guidelines.

Power Series Current (Amps)	Minimum Recommended Wire Size (90C) (AWG)	Wire Bending Radius		Semiconductor Fuse Rating (Amps)	Watlow Replacement fuse P/N	Bussmann Replacement Fuse P/N
		mm	inches			
65	6 AWG	51	2.0	100	0808-0102-0100	170M1317
80	4	76	3.0	125	0808-0102-0125	170M1318
85	4	76	3.0	125	0808-0102-0125	170M1318
90	4	76	3.0	125	0808-0102-0125	170M1318
100	3	76	3.0	160	0808-0102-0160	170M1319
105	3	76	3.0	160	0808-0102-0160	170M1319
120	2	89	3.5	160	0808-0102-0160	170M1319
125	2	89	3.5	160	0808-0102-0160	170M1319
140	1	114	4.5	200	0808-0102-0200	170M1320
155	1/0	140	5.5	200	0808-0102-0200	170M1320
160	1/0	140	5.5	250	0808-0102-0250	170M1321
165	1/0	140	5.5	250	0808-0102-0250	170M1321
185	2/0	152	6.0	250	0808-0102-0250	170M1321
200	3/0	165	6.5	250	0808-0102-0250	170M1321
250	250 MCM	216	8.5	315	0808-0102-0315	170M1322

Power Series Dimensions




Figure 2.2a — Power Series dimensions.




Figure 2.2aa — F35 model only.

Mounting the Power Series Controller

NOTE: The Power Series controller must be mounted vertically. When multiple units are used in one cabinet, it is best that they are mounted side-by-side when possible. If they are mounted one above the other, adequate spacing and airflow must be provided. See Enclosure Guidelines on page 2.3.

For models N20 through F30:

1. Determine the panel location for mounting the Power Series controller and punch or drill holes for the 4 mounting screws per the drawing below. The mounting plate can be used as a template.
2. Attach the Power Series mounting plate using 4 screws (customer supplied, #10 screw minimum, 1/4 inch screw maximum).
3. Align the heads of the shoulder screws on the back of the Power Series heat sink with the key slots on the mounting plate. Push the unit in, and then down until it snaps into place. Mounting is complete.

For F35 models:

F35 models are a bolt-down package. Drill and tap six holes per the above drawing for 1/4-inch 20 bolts.

Power Series Mounting Plate




Figure 2.2b — Mounting plate dimensions.




Figure 2.2c — Installing the controller.

Enclosure Guidelines

The Power Series must be mounted in a suitable electrical enclosure. It must have adequate wire bending space and cooling. The maximum ambient temperature in the enclosure must not exceed 50°C (122°F) for name plate rating. For other output ratings and enclosure ambient temperatures, see output rating curves on pages 2.5 and 2.6.

To maintain the proper cooling, the enclosure must be large enough to dissipate the heat generated by the Power Series, or there must be some form of active cooling.

1. Air circulation — fans bring air into the bottom of the enclosure and louver plates to allow the air to exit the top of the enclosure. Filters are not recommended as they can become plugged and block air flow. To maintain 80 percent of the CFM of a fan, the outlet must be four times the area of the fan inlet. Ensure that each Power Series is within an unobstructed airstream.
2. Vortex coolers operate on compressed air and provide good cooling on a sealed enclosure, but are noisy and consume a lot of air.
3. Cabinet air conditioners work well on sealed enclosures.
4. Heat pipe coolers work well on sealed enclosures, but do not provide as much cooling as vortex coolers or air conditioners.

To determine how much cooling is required:

1. Determine the amperage load on the Power Series. Multiply the amperage by 1.2 and then by the number of phases controlled. This is the output power dissipated by the SCRs in watts. Add the watts dissipated by the controller's power supply (21W) and multiply the total power in watts by 3.41 to get BTUs per hour. Vortex coolers, heat pipe coolers, and air conditioner cooling are rated in BTUs removed.
2. Add up the watts generated by other electronics in the enclosure and multiply by 3.41 to get BTUs per hour.
3. Add up the total BTUs inside the enclosure and pick a cooling device that will remove that amount of BTUs.
4. For fan cooled enclosures, enclosure and fan manufacturers usually have free software programs and application notes to help size the fans for enclosures. If necessary, contact the Application Engineers at Watlow Controls for assistance.

Harsh Environment

The Power Series meets standards UL508, Pollution degree 3 for safety which states: "Conductive pollution occurs or non-conductive pollution occurs which becomes conductive due to condensation which is to be expected." However, Watlow recommends that the Power Series be used in a clean, dry environment to ensure long-term reliability.



CAUTION:
You may want to use a large screwdriver to press in on the release tab while you are pushing on the controller to avoid potential injury to your hands.

Removing the Power Series Controller

1. To release the Power Series controller from the mounting plate, press in on the release tab at the top of the mounting plate.
2. When the release tab is in, push up on the controller from the bottom to release it from the mounting plate. **Beware of sharp edges on the heat sink when you push upward. This will take some force!**
3. The F35 model does not use the standard mounting plate. See page 2.2 for mounting instructions. To remove: reverse the mounting operation.



Figure 2.4 — The F35 Power Series (right) is cooled with larger fans.

Maintaining the Power Series




- **Cleaning:** The heatsink fins must be kept clean for proper cooling and the printed circuit board should be free of conductive residue condensation.
- **Calibration:** Not normally necessary. See pages 6.15-6.16 for data restore and backup.
- **Retorquing:** See page 3.1 for torque guidelines.
- **Software backup and refresh:** Not necessary; see page A.7, Power Series Backup.

NOTE: All Power Series controllers have been 100 percent tested before shipment. The records of these tests are on file for recall if necessary.

Power Series Output Rating Curves

Fan Cooled




All curves are at 100% on with 90°C rated load wire and line wire connected. Note that each chart is slightly different on the amperage scale. The safe operating region is from 1 amp up to the specific curve for the output amperage code selected. For example: F25 Single-Phase is rated up to 200 amps at 50°C; F30 Single-Phase is rated for 250 amps at 50°C. See page 2.6 for Natural Convection Cooled output rating curves.



Power Series Output Rating Curves

Natural Convection

All curves are at 100% on and with 90°C rated load wire and line wire connected. Note that each chart is slightly different on the amperage scale. The safe operating region is from 1 amp up to the specific curve for the output amperage code selected. For example: N25 Single Phase is rated up to 140 amps at 50°C; N30 Single Phase is rated for 165 amps at 50°C.



Chapter Three

Wiring

Wiring the Power Series Controller

Wiring options depend on the model number. Check the terminal designation stickers on the right side of the controller and compare your model number to those shown here and with the model number breakdown in the Appendix (page A.10) of this manual.

Chapter 3 illustrates how to wire the inputs and outputs for all options. Refer to Figure 3.1 for terminal torque guidelines.

Torque Guidelines

- Properly torque terminals by holding for 30 seconds to allow for wires to settle and minimize loosening due to cold flow.
- Re-torque all terminals after 48 hours.
- Establish a maintenance program to re-torque line and load terminations every 3-6 months.




Figure 3.1 — Torque and wire stripping.

Input Wiring



WARNING:

To avoid damage to property and equipment, and/or injury or loss of life, use National Electric Code (NEC) standard wiring practices to install and operate the Power Series. Failure to do so could result in damage, and/or injury or death.

NOTE:

Input, retransmit and communications external terminals have been designed for protection in case of direct contact in accordance with European Standard EN50178.

NOTE:

Insure ground is wired with the same size wire as line and load connections to a ground of sufficient current carrying capacity. (Refer to Chapter 2, p. 2.1, Power Series Wire Bending Radius at Base Current and Ambient Temperature Rating.)

NOTE:

Torque and wire strip guidelines:

- Control wiring 1 thru 23.
- Strip wire to 0.24 inch (6mm). Torque to 8 in.-lbs. (0.9 Nm).
- Hold torque for 30 seconds to allow for wiring settling and cold flow. Re-torque after 48 hours.
- All line connections should be re-torqued every 3-6 months.

Figure 3.2a – Control Power and Alarm Wiring




Figure 3.2b – Retransmit Wiring




Figure 3.2c – Communications Wiring




Figure 3.3a – Single Zone Input Wiring

NOTE:

Successful installation requires four steps:

- Choose the controller's hardware configuration and model number (Appendix);
- Install the controller (Chapter Two);
- Wire the controller (Chapter Three); and
- Configure the controller (Chapters Four, Five and Six).



WARNING:

To avoid damage to property and equipment, and/or injury or loss of life, use National Electric Code (NEC) standard wiring practices to install and operate the Power Series. Failure to do so could result in damage, and/or injury or death.




Figure 3.3b – 2-Zone Input Wiring





Figure 3.3c – 3-Zone Input Wiring



Line Power/Output Wiring

NOTE:

Successful installation requires four steps:

- Choose the controller's hardware configuration and model number (Appendix);
- Install the controller (Chapter Two);
- Wire the controller (Chapter Three); and
- Configure the controller (Chapters Four, Five and Six).



WARNING:


To avoid damage to property and equipment, and/or injury or loss of life, use National Electric Code (NEC) standard wiring practices to install and operate the Power Series. Failure to do so could result in damage, and/or injury or death.

NOTE:

Torque and wire strip guidelines:


- Connections 1 thru 6, and ground lug
- Strip wire 1-1/8 in. (30mm). Torque to 180 in.-lbs. (20 Nm).
- Hold torque for 30 seconds to allow for wiring settling and cold flow. Re-torque after 48 hours.
- All load connections should be re-torqued every 3-6 months.

Figure 3.4a – Single Phase Output Wiring (Model PC1X-XXXX-XXXX)



CAUTION: Figure 3.4a shows the Watlow-recommended output wiring using the internal bussbar as a return current path and with ref. 2 not connected. Should a user choose a non-recommended wiring scheme, then ref. 2 or the internal bussbar must be connected to the appropriate line or neutral. Failure to follow these guidelines could cause damage to the Power Series.

Figure 3.4b – 3 Phase, 2-Leg, 4 SCR Output Wiring (Model PC2X-XXXX-XXXX)



CAUTION: Figure 3.4b shows the Watlow-recommended output wiring using the internal bussbar as a return current path and with ref. 1 and 3 not connected. Should a user choose a non-recommended wiring scheme, then ref. 1 or ref. 3 or the internal bussbar must be connected to the appropriate line. Failure to follow these guidelines could cause damage to the Power Series.

NOTE: Our illustrations illustrate circuit breakers for branch circuit protection. Fuses can also be used.



WARNING:

To avoid damage to property and equipment, and/or injury or loss of life, use National Electric Code (NEC) standard wiring practices to install and operate the Power Series. Failure to do so could result in damage, and/or injury or death.



WARNING:

Install high or low temperature limit control protection in systems where an over temperature fault condition could present a fire hazard or other hazard. Failure to install temperature limit control protection where a potential hazard exists could result in damage to equipment, property and injury to personnel.

NOTE:

For reference connections 1 to 3, use QC 0.250 in. wide and 0.032 in. thick compatible connection which is fully insulated with nylon and has a metal grip ring.

For 14-16 AWG: Molex/ETC AA-5261; 3M MNG14-250DFIX C-54-503X or equivalent.

Figure 3.5a – 3-Phase, 3-Leg, 6-SCR Output Wiring for 4-Wire Wye Application (Model PC4X-XXXX-XXXX)






Figure 3.5b – 3-Phase, 3-Leg, 6-SCR Inside Delta




Note: 1. Phasing must be as shown.
2. Do not connect Ref. terminals.

Figure 3.5c – 3 Phase, 3-Leg, 6-SCR Output Wiring (Model PC3X-XXXX-XXXX)



CAUTION: Do not connect ref. connections with PC3 models. Failure to follow this guideline could cause damage to the Power Series.

Figure 3.5d – **Multizone Output Wiring



PC8X-XXXX-XXX1

Molex/ETC AA-5261; 3M MNG14-250DFIX C-54-503X or equivalent.

PC8X-XXXX-XXX3


Note: Wiring must be A, B, C rotation if phase control is selected.

PC9X-XXXX-XXX1

PC9X-XXXX-XXX3

Note: Wiring must be A, B, C rotation if phase control is selected.

Figure 3.5e – Fan Wiring for 250A Models



**NOTE: Models PC8 and PC9 control legs are isolated so that they may be wired from phase-to-phase inside delta or phase-to-neutral, independent of how the other legs are wired.

Wiring Example



WARNING:

To avoid damage to property and equipment, and/or injury or loss of life, use National Electric Code (NEC) standard wiring practices to install and operate the Power Series. Failure to do so could result in damage, and/or injury or death.



WARNING:

Install high or low temperature limit control protection in systems where an over temperature fault condition could present a fire hazard or other hazard. Failure to install temperature limit control protection where a potential hazard exists could result in damage to equipment, property and injury to personnel.

NOTE: Our wiring example illustrates circuit breakers for branch circuit protection. Fuses can also be used.




Figure 3.6 - System wiring example.

Recommended fusing options to meet 200KA SCCR. All other untested combinations are defaulted to 5KA per UL508A and NEC guidelines.

Power Series Model	Fuse Rating	Watlow Fuse P/N	Bussmann Fuse P/N
PC1X-N20	160	0808-0102-0160	170M1319
PC1X-N25	200	0808-0102-0200	170M1320
PC1X-N30	250	0808-0102-0250	170M1321
PC1X-F20	160	0808-0102-0160	170M1319
PC1X-F25	250	0808-0102-0250	170M1321
PC1X-F30	315	0808-0102-0315	170M1322
PC2(8)X-N20	125	0808-0102-0125	170M1318
PC2(8)X-N25	160	0808-0102-0160	170M1319
PC2(8)X-N30	160	0808-0102-0160	170M1319
PC2(8)X-F20	160	0808-0102-0160	170M1319
PC2(8)X-F25	250	0808-0102-0250	170M1321
PC2(8)X-F30	250	0808-0102-0250	170M1321
PC3(4,9)X-F35	315	0808-0102-0315	170M1322
PC2(8)X-F35	315	0808-0102-0315	170M1322
PC3(4,9)X-N20	100	0808-0102-0100	170M1317
PC3(4,9)X-N25	125	0808-0102-0125	170M1318
PC3(4,9)X-N30	160	0808-0102-0160	170M1319
PC3(4,9)X-F20	125	0808-0102-0125	170M1318
PC3(4,9)X-F25	200	0808-0102-0200	170M1320
PC3(4,9)X-F30	200	0808-0102-0200	170M1320

Chapter Four

Navigation and Software

Keys and Displays

This chapter explains keys, displays and navigation skills. You'll also find a complete software map.





Figure 4.1 — Power Series keys and displays.

Navigating the Power Series


Choose a page (Setup or Factory) and press its key sequence. The page appears in the lower display.

Setup Page - for setting up the control, alarms, retransmit, and communications.




- **Setup Page:** From Display Loop, press  and  keys together for 2 sec.

Factory Page - for calibration and diagnostic information.



- **Factory Page:** From Setup Page, press  and  and  keys together for 2 sec

Display Loop - for monitoring parameters and adjusting manual/digital input, and for clearing alarms if they are latched.



- **Display Loop:** From Setup or Factory Page, press the  key.

NOTE:

The Load Activity Indicator in the Display Loop indicates different things, dependent on whether heater diagnostics is installed. With heater diagnostics installed, it indicates load current has been detected. Without heater diagnostics installed, it indicates the SCRs are being gated and line voltage is present.


Press  or  to find a specific menu in a page. The menu appears in the upper display and the page remains in the lower display.

Press  to enter the list of parameters in the menu displayed. The menu's parameters appear in the lower display and the values in the upper display. To go backward through the parameter list press .


Press  or  to select a value, either alpha or numeric, within a specific parameter.

Navigation

The Display Loop is used to monitor parameters and adjust manual/digital input, and to clear alarms if they are latched.



Display Loop



NOTES:

What you see in each Page and in each Menu are factory set, depending on the options and settings of your controller. The input signal method indicator will change depending on the input signal method chosen — digital, current, or volts. Current operating parameters may be modified at any time with the use of the keypad or communications port.


NOTE: For an explanation of the parameters in the Display Loop, range information, Modbus address, and conditions for the parameter to appear, see pp. 6.1-6.4, Chapter Six, Parameters.

Setup Page Menus



*NOTE: This prompt will only appear in [Ctr1], and if the controller is 3 phase.

Factory Page Menus



**NOTE: These menus and display prompts are only viewable in the Factory Mode using a password.

NOTE: For an explanation of the parameters in the Setup Page, (range information, Modbus address, and conditions for the parameter to appear), see Chapter Six, Parameters, pp. 6.5-6.14; for information on the Factory Page, see pp. 6.14-6.22.

Chapter Five

Control Methods and Features

Zero Cross

Zero cross (also known as burst firing) provides even output power with the lowest level of noise generation (RFI). Zero cross is the preferred method for controlling a resistive load.


The controller determines when the ac sine wave crosses the 0-volts point, then switches the load, minimizing RFI.

Zero cross control is available for all Power Series configurations.

Soft start and current limiting are not available with zero cross control.

Setup Page:

- Enter the Setup Page by holding **■ ◀** for 3 seconds.
- When the display reads **AL90**, press **▶** until **OFF** is displayed. Press **▲▼** to select **SEt** **AL90** is displayed. Press **▲▼** to select **FtB** fixed time base, zero cross or **UrTb** variable time base, zero cross.



SCR Switch On/Off Points

Figure 5.1a — Zero cross switching.

Fixed Time Base - Zero Cross

In the fixed time base control method, the selected percentage power level output is generated over a fixed time period (i.e. a fixed number of cycles), regardless of power level selected. Resolution of operator selectable power may be more precise than the fixed time base allows. Selected power output level is rounded to the closest possible power output value in full cycles as necessary.

Line voltage compensation is not used in the fixed time base control method.

Setup Page:

- Enter the Setup Page by holding **■ ◀** for 2 seconds.
- When the display reads **AL90**, press **▶** until **OFF** is displayed. Press **▲▼** to select **SEt** **AL90** is displayed. Press **▲▼** to select **FtB** fixed time base, zero cross.
- Press **▶** until **1SEC** is displayed. Press **▲▼** to select **FtB** **1SEC** or **45EC**.




Figure 5.1b — 40% power, fixed time base, 60 Hz, 1 sec time base.

Variable Time Base - Zero Cross

In the variable time base control method, an optimal ratio of cycles on to cycles off is used to generate the desired power output. The number of cycles needed to completely generate a desired power level is variable in single cycle increments. Line voltage compensation algorithms are used to adjust the percentage power output while operating in this mode. Variable time base operation gives the best response time and resolution and provides for the longest heater life.

In single cycle variable time base below 50 percent power, the unit is never on for more than one consecutive full cycle. Above 50 percent power, the unit is not off for more than one consecutive full cycle while maintaining the proper output.

Line voltage compensation is active if selected; however, it can be disabled.

Setup Page:

- Enter the Setup Page by holding **■ ◀** for 2 seconds.
- When the display reads **RL9a**, press **▶** until **OFF** is displayed. Press **▲ ▼** to select **Urb** variable time base, zero cross.



Figure 5.2a — 50% variable time base
1 cycle on, 1 cycle off.



Figure 5.2b — 40% single cycle variable time base
1 cycle on, 1 cycle off, 1 cycle on, 2 cycles off.

DC Contactor - Zero Cross

DC contactor control mode is a specialized version of zero cross control in which the analog control input is always used and percentage power output is fixed at 100 percent or 0 percent.

The off/on thresholds are 2.0V/3.5V for voltage input; 5.0mA/8.0mA for current input. This means the unit is off for an input voltage (current) of 2.0V(5.0mA) or lower, and 100% on for an input voltage (current) of 3.5V(8.0mA) or higher. Maximum input voltage is 10.0V.

In contactor mode use a four second cycle time to improve heater diagnostics operation.

Line voltage compensation is not used under dc contactor control, the output is either 100 percent on or 100 percent off.

Setup Page:

- Enter the Setup Page by holding **■ ◀** for 2 seconds.
- When the display reads **RL9a**, press **▶** until **OFF** is displayed. Press **▲ ▼** to select **cont** dc contactor.

NOTE: Heater Tolerance, Heater Open and Load Balance alarms do not work in DC Contactor control mode.

Phase Angle

The phase angle control method gates a limited portion of the line voltage cycle to the load based on percentage power selected. Soft start is always included when phase angle is selected.

Phase angle control may not be selected in a 3 phase, 2-leg system.

Line voltage compensation will be used to adjust the percentage power output while operating in this mode if selected.

Current limiting is a valid option with phase angle if the unit is equipped with heater diagnostics.

Setup Page:

- Enter the Setup Page by holding **■ ◀** for 2 seconds.
- When the display reads **RL9a**, press **▶** until **OFF** is displayed. Press **▲ ▼** to select **PH2E** phase angle.




Figure 5.2c — Phase angle firing.

NOTE: The maximum output power is 99%. This is considered full on for the Power Series.

Soft Start

Soft start is a variation of phase angle control executed on **startup** in which there is a gradual increase in power until the final selected power output is reached. If soft start is selected, the system will execute the soft start sequence each time a zone starts active control. This happens at power-on and on recovery from an alarm such as “Line Loss.” The soft start time is the time it takes to achieve 100 percent power after a zone restart. The actual time may be greater than the set time because of the resolution, but the actual time will never be less than the set time. $\text{Rate} = 100.0 \div \text{time}$. The actual power achieved is set by the temperature control input (see Figure 5.3a and 5.4a).

NOTE: Soft start is intended to be used **only** for slowly increasing power on the initial power request.

Soft start is available in single phase and 3 phase, 3-leg models only.

Soft start is always used in systems with phase angle control mode selected unless **Soft** is set to **0**.

Setup Page:

Adjustable Soft Start - On Power Up

- Enter the Setup Page by holding **■ ◀** for 2 seconds.
- When the display reads **RL90**, press **♥** until **Ctrl** is displayed. Press **▶** until **40** is displayed.

Use the **▲♥** keys to set the desired soft start time in seconds.

NOTE: Repeat this procedure for each zone that you wish to configure.




Figure 5.3a — Soft start.

Maximum Rate of Change

The maximum rate of change is used during **normal operation** of a phase angle controlled system (after a soft start sequence ends) to cause large changes in requested power to be implemented gradually. *The maximum rate of change of the power is defined as the percentage of power change allowed every 0.1 second.* This prevents a sudden increase or decrease in current from one phase angle level to another level from one cycle to the next into a nonlinear load that could be damaged or blow a fuse.

Setup Page:

Adjustable Maximum Rate of Change On Signal Change

- Enter the Setup Page holding **■ ◀** for 2 seconds.
- When the display reads **RL90**, press **♥** until **Ctrl** is displayed. Press **▶** until **10.0** is displayed.

Use the **▲♥** keys to set the desired % output change per 0.1 seconds to reach the desired output power level when in phase angle control.

Example:

Time needed for 100% change in power at selected **Rate** :

- 10.0% increase = 1 sec. from 0 to 100% power
- 10.0% increase = 0.8 sec. from 10 to 90% power
- 10.0% increase = 0.4 sec. from 10 to 50% power

NOTE: The default for Maximum Rate of Change is set to 10%/0.1 second.

NOTE: Repeat this procedure for each zone that you wish to configure.




Figure 5.3b — Maximum rate of change set to 10%.

Heater Bakeout

If a system is shut down for long periods, some heaters can absorb moisture. With a standard power controller, turning the power full “on” when moisture is present, can cause the fuses or the heater to blow. However, with the Power Series you can now “bake out” the moisture in a wet heater before applying full power and destroying the heater. During heater bakeout, the Power Series slowly increases voltage to the heater while monitoring the output current. If the heater achieves full output before the bakeout time expires, then the heater is dry and can be put into service. At all times, the output will not exceed the temperature controller set point.

If the output current reaches a user-specified trip point during the bakeout (as it would if arcing occurred in the heater), then the Power Series shuts off the output and activates an over-current trip error, **HbOC**. The operator should then lengthen the bakeout time and restart or just restart, depending on how long the initial bakeout ran. To start heater bakeout you must cycle the controller power. After a successful heater bakeout, the Power Series automatically switches to the operator pre-selected control mode (phase angle or zero cross).

NOTE: Heater bakeout is intended for magnesium oxide filled nichrome elements. A nichrome element heater can have a tolerance up to $\pm 10\%$. This tolerance could add to the maximum heater current during normal operation. For example, a 50-amp heater could draw 55 amps and still be a good and dry heater.

Heater bakeout may be selected in single phase (phase to neutral) and 3 phase, 6 SCR systems with any pre-selected control mode. You must also have

the heater diagnostics option installed on your Power Series.

Heater bakeout operates with an over-current trip. The operator must set the maximum current allowed during heater bakeout using the **HbOC** prompt. This will set the maximum allowable load during heater bakeout.

Setup Page:

- Enter the Setup Page by holding **■ ◀** for 2 seconds.
- When the display reads **AL 9a**, press **▼** until **OPt 1** is displayed. Press **▶** until **OFF** is displayed. Use the **▲▼** keys to turn heater bakeout on.
- Press **▶** until **77.0** appears in the lower display. Use the **▲▼** keys to set the desired heater bakeout time in minutes.
- Press **▶** until **HbC** appears in the lower display. Use the **▲▼** keys to set the desired maximum load current during the heater bakeout process.

NOTE: Repeat this procedure for each zone that you wish to configure.




Figure 5.4a— Heater bakeout.

Heater Tolerance Detection

Heater tolerance detection allows you to detect a failed heater or a heater that is beginning to fail. An alarm is triggered if the load current drops below or rises above specific levels.

For example, if you have five heaters that draw 20 amps each, for a total load current of 100 amps at 100 percent power, you could program the heater tolerance alarm to trigger if the load current drops below 80 amps at 100 percent power. This would indicate that one of the heaters has failed (open.) To monitor for a heater that is beginning to fail or age, you could watch for too little or too much current. For example, in Figure 5.4b the alarm is programmed to trigger if the load current drops below 90 amps, or rises above 110 amps at 100 percent power.

The Power Series automatically adjusts the set points, depending upon the percent power, as shown in the illustration below.




Figure 5.4b— Heater Tolerance Detection.

Current Limiting

The current limit uses the RMS current entered by the user. When a zone goes from 0.0% to a requested power greater than 0.0%, the software increments the output power by 0.1% increments per AC cycle until a current limit is detected. The software will continue to increment and decrement by 0.1% per AC cycle based on the current limit until the goal power is met.

During normal operation (after the initial goal power is met), a detected current limit will cause decrements at 0.1% power per AC cycle until the current limit is no longer active. The software will continue to increment and decrement by 0.1% per AC cycle based on the current limit, until the goal power is again met.

Current limiting is available on units equipped with heater diagnostics, (P __ 1 - ____ - ____).

Current limiting is not available with 3 phase, 2-leg systems.

Current limiting is available under phase angle control operation.

Setup Page:

- Enter the Setup Page by holding **■ ◀** for 2 seconds.
- When the display reads **AL90**, press **♥** until **OPt 1** is displayed. Press **▶** until **OFF** is displayed.

Use the **▲ ♥** keys to turn current limit on.

- Press **▶** until **CL R** appears in the lower display. Use the **▲ ♥** keys to set the desired current limit set point.

NOTE: Repeat this procedure for each zone that you wish to configure.




Figure 5.5 — Current limiting.

Inductive Load Adjustment

The effect of inductive loads on current readings with phase angle control can be factored in by requesting an Inductive Load Factor Adjustment. This feature is used to improve current measurement when phase angle firing into a transformer or other inductive loads.

The adjustment should be done with active phase angle control with a requested power of 5% to 50% in the zone of interest using a true RMS current meter.

NOTE: If an inductive load factor has been requested and the load is no longer inductive, the current reading will not be accurate. Use the **CLr** parameter in the **IndF** prompt to remove the inductive factor.

Setup Page:

- Enter the Setup Page by holding **■ ◀** for 2 seconds.
- When the display reads **AL90**, press **♥** until **OPt 1** is displayed. Press **▶** until **IndF** is displayed.

Using the **▲ ♥** keys, select **rE9** in the upper display.

- Press **▶** until **ICur** appears in the lower display. The upper display shows the current calculated by the system with no inductive factor. Read the actual current measured by a true RMS meter; use the **▲ ♥** keys until that value is displayed.
- Press **◀** until **IndF** appears in the lower display. Using the **▲ ♥** keys, select **ACE** in the upper display. After 5 seconds, the prompt will read **idLE** if the adjustment was successful, or **Err** if there was an error.
- To return to using no Inductive Load Factor, select **CLr**.

NOTE: Using the inductive load factor parameter the Power Series displayed current can only be increased to match the current reading of a true RMS meter. The Power Series displayed current reading cannot be decreased below what it initially calculated and displayed. The maximum inductive load factor increase allowed is 50% of the non-inductive current measured initially by the Power Series. If you exceed the allowable adjustment then the Power Series will display **Err** in the upper display and **IndF** in the lower display. In the event of an error push the up or down key to **rE9** and start the process over.

Other Features

Baseline Voltage and Voltage Compensation

The baseline voltage is used by the controller to adjust the output so that the system power remains constant. This adjustment is called voltage compensation. The requested power is assumed to occur at the baseline voltage. If there are any deviations of the line voltage from the baseline voltage, the applied output power will be adjusted.

For example, the starting line voltage of the system is 121 volts and the baseline voltage is set to 121 volts. The requested power is set to 50.0 percent. After the system has been controlling, the line voltage drops to 110 volts. During the time that the line voltage is at 110 volts, the applied output power will be adjusted to $(121^2/110^2) \times .50 = 60.5$ percent so that the system power remains constant.

The baseline voltage is also used for adjusting operating parameters in the software. It is important to adjust the baseline voltage to the normal operating voltage of the unit to enable it to operate at maximum accuracy.

Menu Lock

Menu locks allow a user to restrict access to parameters. If a lock is set on a menu, the parameters become read only. The system will not allow parameter to be changed, either from the keypad or through communications.

Factory Page:

- Enter the Factory Page by holding **■ ◀ ▶** for 2 seconds.
- When the display reads **dRtR**, press **♥** until **Loc** is displayed. Press **▶** until **UnL** is displayed.

Use Global Lockout **9LOC** to write protect all prompts by choosing locked **LOC**. If set to unlocked **UnL**, individual menu locks can be set by selecting each parameter in the Global/Menu Lockouts Menu and individually setting each to locked **LOC** or unlocked **UnL**.

Input

Signal Selection

You need to configure the Power Series for current, voltage or digital.

Setup Page:

- Enter the Setup Page by holding **■ ◀** for 2 seconds.
- When the display reads **RL90**, press **♥** until **Ctrl** is displayed. Press **▶** until **nnR** is displayed.

Use the **▲♥** keys to select either current **nnR**, volt **UoLE**, or digital **d.9**.

NOTE: Repeat this procedure for each zone that you wish to configure.

Analog is typically 0-5V $\pm$ (dc), 1-5V $\pm$ (dc), 0-10V $\pm$ (dc), 4-20mA.

Digital is used for keypad manual control or communications to control the Power Series.

Digital input is entered from the keypad in the Display Loop on the **In 1**, **In 2** or **In 3** prompt.

Current inputs are hardware limited to 0 to 20mA, but may be scaled using the **nnR $\pm$** prompts. Note that the power will be fully off at the current specified by prompt **nnR $\pm$** +.2mA, and fully on at the current specified by prompt **nnR $\pm$** -.2mA.

Voltage inputs are hardware limited to 0 to 10V, but may be scaled using the **UoL $\pm$** prompts. Note that the power will be fully off at the current specified by prompt **UoL $\pm$** +.1V, and fully on at the current specified by prompt **UoL $\pm$** -.1V.

Alarms

An alarm takes some action, usually notifying an operator, when a control parameter leaves a defined range. A user can configure how and when an alarm is triggered and whether it turns off automatically when the alarm condition is over. A description of the alarms and errors, why they occur, and how to troubleshoot them can be found on pages A.4 - A.7.

Setup Page:

- Enter the Setup Page holding **■ ◀** for 2 seconds.

- When the display reads **AL9o**, press **♥** until **ALr** is displayed.
SEE **SEE**

Global Alarm Configuration

The Global Alarm Configuration **9LbL** is used when all of the alarms in the system are to be configured in the same mode. If individual alarms need to be set to different configurations, the Global Alarm Configuration should be set to **OFF**.

Alarm Standard

If an alarm is configured as “standard” **SEd**, the alarm indicators only occur while the alarm is active. The alarm indicators are the relay, which state is set in Active Relay State **AL9c** as either energized on alarm or de-energized on alarm, and the display, which has an indicator LED in the upper display and the descriptive prompt for the active alarm. When the alarm becomes inactive (and no other alarms are active) the alarm indicators are turned off.

Alarm Latched & Unlatching an Alarm Indicator

If an alarm is configured as “latched” **LAL**, the alarm indicators remain active until the user deactivates them. For a latched alarm, the descriptive prompt on the display in the Display Loop will read **LAL**, and the user can switch to **UnLA**, if the alarm is cleared, to turn off the alarm indicators. Once alarm indicators have been turned off, the operator does not have to reconfigure an alarm as latched.

Alarm Silencing

If an alarm is configured as “silenced” **SIL**, the relay does not activate on the active alarm, although the display indicators are still visible. When the alarm becomes inactive (and no other alarms are active) the display alarm indicators are turned off.

Alarm Latched and Silenced

If an alarm is configured as “latched and silenced” **LASI**, only the display alarm indicators are active until the user deactivates them. The alarm displays must be switched off once the alarm has been cleared. See unlatching an alarm indicator above.

Active Relay State

For maximum flexibility, the Power Series controller can generate alarms from the energized or de-energized state of the relay. Creating an alarm from the de-energized state of the relay is the most reliable method of alarm generation since a power loss or any other control malfunction would cause an alarm.

Communications

Overview

A Power Series controller can also be programmed and monitored by connecting it with a personal computer or programmable logic controller (PLC) via serial communications. To use this communications option, a Power Series must be equipped with an EIA/TIA 232/485 (P_ _ _ - _ _ _ _ - 1 _ _ _) communications board.

To view or change controller settings with a personal computer, you need to run software that uses the Modbus™ RTU protocol to read or write to registers

in the controller. See Chapter Six, Parameters, for the Modbus registers. These registers contain the parameter values that determine how the controller will function and the values that reflect the current input and output values of the system.

Parameters relating to communications appear in the Comms Menu (Setup Page). Match the Baud Rate **bRud** to that of the computer and select an Address **Rddr** (1 to 247, default is 1).

The Power Series supports a maximum read of up to 32 registers. See appendix A.8 for Modbus registers.

Retransmit

Retransmitting Output Load Current or Load Power

The retransmit feature allows an output to retransmit an analog signal that can serve as an input variable for another device such as a chart recorder to document system performance over time.

To use the retransmit feature a Power Series must be equipped with heater diagnostics and a universal retransmit board (P__1 - ____ - _1__).

Setup Page:

- Enter the Setup Page by holding **■ ◀** for 2 seconds.
- When the display reads **RL90**, press **♥** until **REtr** is displayed. Press **▶**:

Select **CF9** to choose the type of output retransmitted, mA **nnA** or volts **UOLt**.

Select **TYPE** to choose the type of information that will be retransmitted.

nOnE retransmit not active.

Cur retransmits the load current of selected phase **PhAS** or zone **Zone** if it is a multizone unit.

HUA retransmits the load power of selected zone **Zone** in all models.

Select phase **PhAS** or zone **Zone** to choose the phase/zone that will represent your retransmit signal. A three phase unit can only be single zone.

To scale the retransmit output signal, set the low value load current or kVA to be retransmitted with **Cur_** or **HUA_** and set the high value load current or kVA to be retransmitted with **Cur^** or **HUA^**. For example, if you want 4-20mA to represent a 50A to 250A current, set **Cur_** to 50 and **Cur^** to 250. As the load current varies between 50 and 250A, the retransmit output will vary between 4mA and 20mA.

Current outputs are hardware limited to 0 to 20mA, but may be scaled using the **rt.C_** and **rt.C^** prompts.

Voltage outputs are hardware limited to 0 to 10V, but may be scaled using the **rt.U_** and **rt.U^** prompts.




Figure 5.9a — Retransmitting a remote set point.




Figure 5.9b — Example circuit.

Fast Start Guide

Get Your Power Series Controlling Heat

Single Phase Control

Apply power to the line and the electronics power supply. The displays will read

LoAd

- Enter the Setup Page holding **■** **◀** for 2 seconds.
- When the display reads **RL9o** ▶ to **OFF**,
SEt **RL9o**

then cycle thru the list of choices using the **▲** **▼** keys. Choose one*.

cont dc contactor
OFF non-operational
FtB fixed time base, zero cross
UrTb variable time base, zero cross
PH2t phase angle

Press **◀**.

- At **RL9o**, press **▼** to **Ctr1**.
SEt **SEt**
- **Press ▶ until **nnR** (default) is displayed.
In

Using the **▲** **▼** keys, select input type: **OFF** off, **nnR** current, **UoLt** voltage, or **d.9** keyboard or comms.

- **Press ▶ until **nnR** or **UoL** is displayed.
Ctr1 **Ctr1**

Using the **▲** **▼** keys, set the low end of the input scale to the desired input.

- **Press ▶ until **nnR** or **UoL** is displayed.
Ctr1 **Ctr1**

Using the **▲** **▼** keys, set the high end of the input scale to the desired input.

- **Press ▶ until **IdLE** is displayed.
LrAU

Using the **▲** **▼** keys, select **rE9**, and the Power Series will set the baseline voltage. Line voltage compensation, under voltage alarm, and some internal operating parameters are based on this.

***NOTE: One type of power control algorithm must be selected for all zones.**

****NOTE: Repeat this procedure for each zone in multizone configurations.**

Three Phase Control

Apply power to the line and the electronics power supply. The displays will read

LoAd

- Enter the Setup Page holding **■** **◀** for 2 seconds.
- When the display reads **RL9o** ▶ to **SEt**,
SEt **RL9o**

then cycle thru the list of choices using the **▲** key. Choose one.

cont dc contactor
OFF non-operational
FtB fixed time base, zero cross
UrTb variable time base, zero cross
PH2t phase angle

Press **◀**.

- At **RL9o**, press **▼** to **Ctr1**.
SEt **SEt**
- **Press ▶ until **nnR** (default) is displayed.
In

Using the **▲** key, select input type: **OFF** off, **nnR** current, **UoLt** voltage, or **d.9** keyboard or comms.

- Press ▶ until **nnR** or **UoL** is displayed.
Ctr1 **Ctr1**

Using the **▲** or **▼** key, set the low end of the input scale to the desired input.

- Press ▶ until **nnR** or **UoL** is displayed.
Ctr1 **Ctr1**

Using the **▲** or **▼** key, set the high end of the input scale to the desired input.

- Press ▶ until **IdLE** is displayed.
LrAU

Using the **▲** **▼** keys, select **rE9**, and the Power Series will set the baseline voltage. Line voltage compensation, under voltage alarm, and some internal operating parameters are based on this.

- Press ▶ until **TYPE** is displayed.
TYPE

Select the load type for Zone 1. (Choice is dependent on unit hardware.)

2L d 3 ph, 2-leg delta
2Lod 3 ph, 2-leg open delta
2LwY 3 ph, 2-leg ungrounded wye
nonE unconfigured
3L d 3 ph, 3-leg, 6 SCR inside delta
3L d 3 ph, 3-leg, 6 SCR delta
3L9Y 3 ph, 3-leg, 6 SCR grounded wye

- Press **■** to start the Power Series.

6

Chapter Six Parameters

Display Loop

The resting-state display shows one of the following sets of data, depending on controller setup. The first prompt appears in the top display, the second in the bottom display.

Display	Parameter	Range (Modbus Value)	Default	Modbus Register read/write	Conditions for Parameters to Appear
---------	-----------	-------------------------	---------	----------------------------------	--

System Information

☐ (alpha)	Active Alarms (if any) Displays present alarm conditions.	☐ ALr Active (1) ☐ LAE Latched Active (2) ☐ LRI Latched Inactive (3) ☐ ULR Unlatched (4)		181 to 190 r/w	Active: Any active unmasked alarm. Individual Modbus registers may have ☐ ULR Unlatched (4) written to them to clear a latched alarm. NOTE: a latched alarm must be ☐ LRI Latched Inactive (3) before it can be unlatched.
☐ (alpha)	Display Loop Errors (if any) Displays present error conditions.	☐ Inactive (0) ☐ Err Active (1) (See Appendix A.7 for values)	n/a	195 r	Active: Any active error. See Appendix, pp. A.4-7.
☐ LoAd	Load Activity Indicator Displays ☐ - if load has power applied.	☐ - or ☐ - per display	☐ - - -		Active: Always. Appears in display loop. (In single phase, single zone, only the center LED operates; in single phase, 2-zone, or 3-phase, 2-leg, only the outside LEDs operate; in 3-phase, 3-leg, and multizone, each zone operates a separate LED.)
☐ FRE9	Line Frequency (Hz) Displays the AC line.	☐ 47 to ☐ 63 [47 to 63]	n/a	198 r	Active: Always. Appears in Display Loop.

Single Zone / Single Phase

☐ in	Analog (mA or V) or Numeric (%) Input Signal Displays mA/V analog input; selects numeric % power.	☐ 00 to ☐ 2000 [mA] (0 to 2000) ☐ 00 to ☐ 1000 [V] (0 to 1000) ☐ 00 to ☐ 1000 [%] (0 to 1000) 0.1 increments	☐ 00	150 r [mA] 151 r [V] 5102 r/w [dig]	Active: Always. Appears in Display Loop.
------------------------------------	---	--	------------------------------------	---	---

Display	Parameter	Range (Modbus Value)	Default	Modbus Address read/write	Conditions for Parameters to Appear
OUT	Output Power (%) Displays present output power.	00 to 1000 (0 to 1000)	00	159 r	Active: Always. Appears in Display Loop.
HbE	Heater Bakeout Timeout Displays the time left on a heater bakeout.	9999 to 0 [minutes] (9999 to 0)	n/a	157 r [1]	Active if heater diagnostics option is installed and heater bakeout is running in the zone.
Vol	Line Potential (Volts) rms Displays measured line voltage.	0 to 9999 (0 to 9999)	n/a	162 r	Active: Always. Appears in Display Loop.
Cur	Load Current (Amps) rms Displays measured load current. Peak current converted to rms, then multiplied by % power = average rms current measured by the on-board CT.	0 to 9999 (0 to 9999)	n/a	164 r	Active if heater diagnostics option is installed.
HUA	Load Power (kVA) Displays (est.) calculated load power.	0 to 9999 (0 to 9999)	n/a	156 r	Active if heater diagnostics option is installed.

Two Zone, Single Phase

1 , 2 Zone	Display Zone Selection Select Zone 1 or 2 for display.	1 to 2	1	n/a	Active with multizone configuration.
In 1 , In 2 Analog (mA or V) or Numeric (%) Input Signal	Displays mA/V analog input; selects numeric % power.	00 to 1000 [V] (0 to 1000) 00 to 2000 [mA] (0 to 2000) 00 to 1000 [%] (0 to 1000) 0.1 increments	00	mA, r [1][2] 150,160 V, r [1][2] 151,161 dig, r/w [1][2] 5102, 5202	Active with multizone configuration.
OUT 1 , OUT 2 Output Power (%)	Displays present output power.	00 to 1000 (0 to 1000)	00	159 r [1] 169 r [2]	Active with multizone configuration.
HbE 1 , HbE 2 Heater Bakeout Timeout	Displays the time left on a heater bakeout.	9999 to 0 [minutes] (9999 to 0)	n/a	157 r [1] 167 r [2]	Active if heater diagnostics option is installed and heater bakeout is running in the zone.

Display	Parameter	Range (Modbus Value)	Default	Modbus Address read/write	Conditions for Parameters to Appear
UoL 1 , UoL 2	Line Potential (Volts) rms Read measured line voltage.	0 to 9999 (0 to 9999)	n/a	152 r [1] 172 r [2]	Active with multizone configuration.
Lor 1 , Lor 2	Load Current (Amps) rms Read measured line current.	00 to 9999 (0 to 9999)	n/a	154 r [1] 174 r [2]	Active with multizone configuration and heater diag- nostics option is installed.
HUA 1 , HUA 2	Load Power (kVA) Read calculated (est.) load power.	0 to 9999 (0 to 9999)	n/a	156 r [1] 166 r [2]	Active with multizone configuration and heater diag- nostics option is installed.

Three Zone, Single Phase

1 , 2 , 3	Display Zone Selection Select Zone 1, 2 or 3 for display.	1 to 3	1	n/a	Active with multizone configuration.
In 1 , In 2 , In 3	Analog (mA or V) or Numeric (%) Input Signal Displays mA/V analog input; selects numeric % power.	00 to 2000 [mA] (0 to 2000) 00 to 1000 [V] (0 to 1000) 00 to 1000 [%] (0 to 1000) 0.1 increments	00	mA, r[1][2][3] 150, 160, 170 V, r[1][2][3] 151, 161, 171 dig, r/w [1][2][3] 5102, 5202, 5302	Active with multizone configuration.
Out 1 , Out 2 , Out 3	Output Power (%) Displays present out- put power.	00 to 1000 [%] (0 to 1000)	00	159 r [1] 169 r [2] 179 r [3]	Active with multizone configuration.
HbE 1 , HbE 2 , HbE 3	Heater Bakeout Timeout Displays the time left on a heater bakeout cycle.	9999 to 0 [minutes] (9999 to 0)	n/a	157 r [1] 167 r [2] 177 r [3]	Active if heater diagnostics option is installed and heater bakeout is running in the zone.
UoL 1 , UoL 2 , UoL 3	Line Potential (Volts) rms Read measured line voltage.	0 to 9999 [V] (0 to 9999)	n/a	152 r [1] 162 r [2] 172 r [3]	Active with multizone configuration.

NOTES:

What you see in each Page and in each Menu are factory set, depending on the options and settings in your controller. Current operating parameters may be modified at any time with the use of a keypad or serial input.

The Input Signal Method Indicator will change depending on the Input Signal Method chosen — process, current, or volts.

NOTE: For more information about how parameter settings affect the controller's operation, see Chapter Five, Control Methods and Features.

Display	Parameter	Range (Modbus Value)	Default	Modbus Address read/write	Conditions for Parameters to Appear
[Cur 1], [Cur 2], [Cur 3] Load Current (Amps) rms Read measured line current.		[00] to [9999] [A] (0 to 9999)	n/a	154 r [1] 164 r [2] 174 r [3]	Active with multizone configuration and heater diag- nostics option is installed.
[HUR 1], [HUR 2], [HUR 3] Load Power (kVA) Read calculated (est.) load power.		[0] to [9999] [kVA] (0 to 9999)	n/a	156 r [1] 166 r [2] 176 r [3]	Active with multizone configuration and heater diag- nostics option is installed.

Multi-Phase

[In] Analog (mA or V) or Numeric (%) Input Signal Displays mA/V analog input; selects numeric % power.	[00] to [2000] [mA] (0 to 2000) [00] to [1000] [V] (0 to 1000) [00] to [1000] [%] (0 to 1000) 0.1 increments	[00]	151 r [V] 150 r [mA] 5102 r/w [dig]	Active: Always. Appears in Display Loop.
[Out] Output Power (%) Displays present out- put power.	[00] to [1000] [%] (0 to 1000)	[00]	159 r	Active: Always. Appears in Display Loop.
[1], [2], [3] [PhAS] Display Phase Selection 1 to 3 Select phase for display.	[1] to [3]	n/a		Active with multiphase configuration.
[Vol 1], [Vol 2], [Vol 3] Line Potential (Volts) rms Read measured line voltage.	[00] to [9999] [V] (0 to 9999)	n/a	152 r [1] 162 r [2] 172 r [3]	Active with multiphase configuration.
[Cur 1], [Cur 2], [Cur 3] Load Current (Amps) rms Read measured load current.	[00] to [9999] [A] (0 to 9999)	n/a	154 r [1] 164 r [2] 174 r [3]	Active with multiphase configuration and heater diag- nostics option is installed.

NOTE: In 3 phase, 2-leg systems, **[Cur 2]** is the current displayed; it is the average of phase 1 and phase 3 (**[Cur 1]** and **[Cur 3]**).

[HUR] Load Power (kVA) Read calculated (est.) load power.	[0] to [9999] [kVA] (0 to 9999)	n/a	156 r	Active with multiphase configuration and heater diag- nostics option is installed.
---	---	-----	-------	--

Setup Page

To enter the Setup Page, press the Home and Left keys (■ ◀) together while in the Display Loop.

Each of the following menus in the Factory Page are selected by pressing the Increment/Decrement keys (▲ ▼). Each press of the button will scroll you up or down through these main menu options.

To select a parameter within a menu, use the Left/Right arrow keys (◀ ▶). The parameter appears in the bottom display.

To select a value for each parameter (either alpha or numeric), use the Increment/Decrement keys (▲ ▼). The value appears in the upper display.

Pressing the Home key (■) in this menu will return you to the Display Loop.

The Setup Page contains ten menus:

Display	Parameter	Range (Modbus Value)	Default	Modbus Register read/write	Conditions for Parameters to Appear
■ SET	Setup Page Select Go to a setup menu.	AL90 Control Algorithm CTZ1 Control Zone 1 OPT1 *Options Zone 1 CTZ2 Control Zone 2 OPT2 *Options Zone 2 CTZ3 Control Zone 3 OPT3 *Options Zone 3 ALr Alarms Configuration COM7 *Comms Configurations RETr *Retransmit Configuration	AL90		*NOTE: These menus are dependent on the hardware options that are installed in your controller. Please see the individual menus for the options that must be installed for each of these menus to appear.

AL90 Setup Control Algorithm

■ **SET** Setup Page

This menu is used to set the control algorithm for the system.

NOTE: Changing the algorithm will restart the system.

AL90	Power Control Algorithm Select Select power control algorithm.	cont dc contactor (0) OFF non-operational (1) Ftb fixed time base, zero cross (2) UrTb variable time base, zero cross (3) PH2E phase angle (4)	OFF non-operational (1)	55 r/w	Active: Always. cont is not available if any input on controller is digital. PH2E phase angle is not available with 3 phase, 2-leg controllers. NOTE: Changing this parameter will restart the system.
■ Ftb	Fixed Time Base (Sec) Set the fixed time base in seconds for selected zone.	1SEC 1 second (0) 4SEC 4 second (1)	1SEC 1 second (0)	56 r/w	Active if AL90 is set to Ftb .

NOTE: For more information about how parameter settings affect the controller's operation, see Chapter Five, Control Methods and Features.

Display	Parameter	Range (Modbus Value)	Default	Modbus Address read/write	Conditions for Parameters to Appear
☐ UC	Line Voltage Compensation Automatically adjusts output duty cycle to compensate for line voltage fluctuations.	☐ ON on (0) ☐ OFF off (1)	☐ ON on (0)	80 r/w	Active: Always.

[Err1] [Err2] [Err3] Setup Control Zone 1, 2, and 3 Menus
[SEt] [SEt] [SEt] Setup Page

This menu is used to set up the control for the chosen zone.

Zone 1 is used if Input/Output Configuration is single phase, single zone, or three phase.

Zone 1 and 2 are used if Input/Output Configuration is single phase, two zones.

All zones are used if Input/Output Configuration is single phase, three zones.

☐ IN	Input Signal Method Select (dig, mA, Volt) Select the input signal method for chosen zone.	☐ OFF off (0) ☐ nnR current (1) ☐ UoLE voltage (2) ☐ d.9 keyboard or comms (3)	☐ nnR current (1)	5101 r/w [1] 5201 r/w [2] 5301 r/w [3]	Active: Always. ☐ d.9 is not available if ☐ SEt RL9o in the Setup Page is set to ☐ cont .
☐ dFLt	Default Numeric Input Signal (%) Selects the power-on level for chosen zone.	☐ 00 0 percent to ☐ 1000 100 percent (0 to 1000)	☐ 00 (0)	5103 r/w [1] 5203 r/w [2] 5303 r/w [3]	Active if input signal method is set to ☐ d.9 .
☐ nnR₋	Analog Input Low Current (mA) Sets current value which will correspond to 0% power if input is current type.	☐ 000 to ☐ nnR₋ [- 5mA] (0 to Analog Input High Current[-5mA])	☐ 000 (0)	5011 r/w [1] 5021 r/w [2] 5031 r/w [3]	Active if ☐ IN is set to ☐ nnR current.
☐ nnR₊	Analog Input High Current (mA) Sets current value which will correspond to 100% power if input is current type.	☐ nnR₊ [+ 5mA] to ☐ 9999 (Analog Input Low Current [+5mA] to 9999)	☐ 2000 (2000)	5012 r/w [1] 5022 r/w [2] 5032 r/w [3]	Active if ☐ IN is set to ☐ nnR current.
☐ UoL₋	Analog Input Low Voltage (Volts) Sets voltage value which will correspond to 0% power if input is voltage type.	☐ 000 to ☐ UoL₋ [- 2.5V] (0 to Analog Input High Voltage [-2.5V])	☐ 000 (0)	5013 r/w [1] 5023 r/w [2] 5033 r/w [3]	Active if ☐ IN is set to ☐ UoLE voltage.

Display	Parameter	Range (Modbus Value)	Default	Modbus Register read/write	Conditions for Parameters to Appear
UoL	Analog Input High Voltage (Volts) Sets voltage value which will correspond to 100% power if input is voltage type.	UoL [+ 2.5V] to 9999 (Analog Input Low Voltage [+2.5V] to 9999)	1000 (1000)	5014 r/w [1] 5024 r/w [2] 5034 r/w [3]	Active if In is set to UoLE voltage.
Lrn.R	Learn Input Learn Request (Hi, Lo) Allows software to learn the high and low limits of the analog input signal.	Err invalid input signal (-1) idle idle (0) LO low limit learn request (1) HI high limit learn request (2)	idle idle (0)	5019 r/w [1] 5029 r/w [2] 5039 r/w [3]	Active if In is set to nonR current or UoLE voltage. Go to Lrn.R , set analog input to low limit and set the controller to LO low limit. Wait 5 sec. for automatic input of low data for controller. The display will go back to idle when done. Go to Lrn.R , set the analog input to high limit and set the controller to HI high limit. Wait 5 sec. for automatic input of high data for controller. The display will go back to idle when done.
bL U	Baseline Voltage Read/Adjust Shows the value for baseline voltage and allows manual adjustment of this value.	Minimum to maximum line voltage (minimum to maximum line voltage)	Line Voltage rating	5594 r/w [1] 5595 r/w [2] 5596 r/w [3]	Active: Always.
Lrn.U	Baseline Voltage Learn Request Allows software to learn the baseline voltage on line connected to the zone chosen.	Err invalid input signal (-1) idle idle (0) req learn request (1)	idle idle (0)	5591 r/w [1] 5592 r/w [2] 5593 r/w [3]	Active: Always. Go to Lrn.U , set the controller to req . Wait 5 sec. for automatic input of data for controller. The display will go back to idle when done.
TYPE	Load Type Select (Control Zone 1 only, 3 phase only.) Select the load type for Zone 1.	2L d 3 ph, 2-leg delta (0) 2L od 3 ph, 2-leg open delta (1) 2L uy 3 ph, 2-leg ungrounded wye (2) nonE unconfigured (3) 3L id 3 ph, 3-leg, 6 SCR inside delta (4) 3L d 3 ph, 3-leg, 6 SCR delta or ungrounded wye (5) 3L yy 3 ph, 3-leg, 6 SCR grounded wye (7)	nonE unconfigured (3)	58 r/w	Active if controller is a 3 phase system which only has one zone. NOTE: The parameters available are dependent on the controller's input/output configuration. The system does not operate unless this prompt is set to something other than nonE. NOTE: Changing this parameter will restart the system.

NOTE: For more information about how parameter settings affect the controller's operation, see Chapter Five, Control Methods and Features.

Display	Parameter	Range (Modbus Value)	Default	Modbus Address read/write	Conditions for Parameters to Appear
RALE	Maximum Rate of Change (%/100msec) Set maximum rate of power change of the power level for selected zone when input signal changes.	0.1 to 100.0 0.0 to 100.0% [.1% increments] (1 to 1000)	10.0 (100)	5104 r/w [1] 5204 r/w [2] 5304 r/w [3]	Active unless Input/Output configuration is 3 phase, 2-leg. Active if AL9o is set to Ph2L .
SOFT	Soft Start Time (Sec) Selects the time in seconds for the power level of the chosen zone to change from 0% to 100% when the power cycles.	0.0 to 120.0 0.0 to 120 seconds (.1 second increments) (0 to 1200)	4.0 (40)	5105 r/w [1] 5205 r/w [2] 5305 r/w [3]	Active unless Input/Output configuration is 3 phase, 2-leg. Active if AL9o is set to Ph2L .
rdLY	Reactance Delay for Transformer Loads Prevents half cycle errors and restarts on inductive loads. Increase value until half cycle errors no longer appear.	0.0 to 500.0 (0 to 500)	0.0 (0)	5108 r/w	Active if AL9o is set to Ph2L and TYPE is set to 3Ld or 3Lld .

OPt1 OPt2 OPt3 Setup Options Zones 1, 2, and 3 Menus
SEt SEt SEt Setup Page

This menu is used to set up the options for the chosen zone. This set of menus is available only if Heater Diagnostics is installed.

Zone 1 is used if Input/Output Configuration is single phase, single zone, or three phase.

Zone 1 and Zone 2 are used if Input/Output configuration is single phase, two zones.

All zones are used if Input/Output Configuration is single phase, three zones.

Hbo	Heater Bakeout Select (On/Off) Select heater bakeout option for chosen zone.	OFF off (0) On selected (1)	OFF off (0)	5110 r/w [1] 5210 r/w [2] 5310 r/w [3]	Active if heater diagnostics is installed. Active unless controller is 3 phase, 2 leg configuration.
PTin	Heater Bakeout Select Time Selects the heater bakeout time in minutes for chosen zone.	0 to 9999 0 to 9999 minutes [1 minute increments] (0 to 9999)	1440 minutes (1440)	5111 r/w [1] 5211 r/w [2] 5311 r/w [3]	Active if heater diagnostics is installed. Active unless controller is 3 phase, 2 leg configuration. Active if Hbo is set to On .
HbC	Heater Bakeout Over Current Trip Sets the maximum heater current during heater bakeout. Output will shut down at this value.	0 to Cur 0 to Load Current Amps [1 Amp increment; maximum will be determined by Load Rating] (0 to Load Current Amps)	10.0% of load current	5116 r/w [1] 5216 r/w [2] 5316 r/w [3]	Active if heater diagnostics is installed. Active unless controller is 3 phase, 2 leg configuration. Active if Hbo is set to On .

Display	Parameter	Range (Modbus Value)	Default	Modbus Address read/write	Conditions for Parameters to Appear
CL	Current Limit Select (On/Off) Selects current limit method for selected zone. Used in phase angle control only.	OFF off (0) On on (1)	OFF off (0)	5112 r/w [1] 5212 r/w [2] 5312 r/w [3]	Active if heater diagnostics is installed. Active unless controller is 3 phase, 2 leg configuration. Active if ALGo is set to Ph2L . NOTE: Changing this parameter will restart the system.
CL A	Current Limit Set Point (A) Selects the current limit set point for current limiting in chosen zone.	0 to CLur 0 to Load Current Amps [1 Amp increment; maximum will be determined by Load Rating] (0 to Load Current Amps)	10.0% of load current	5113 r/w [1] 5213 r/w [2] 5313 r/w [3]	Active if heater diagnostics is installed. Active unless controller is 3 phase, 2 leg configuration. Active if ALGo is set to Ph2L and CL is set to On . NOTE: Changing this parameter will restart the system.
LoL	Low Tolerance Set Point (A) Set heater tolerance low current set point for the selected zone. Value is current level for 100% requested power and is adjusted actual percentage of requested power.	0 to LoL 0 amps to High Tolerance Set Point [1 amp increments] (0 to Heater High Tolerance Set Point)	0 (0)	5114 r/w [1] 5214 r/w [2] 5314 r/w [3]	Active if heater diagnostics is installed. This set point will only be used if the requested power is above 20%.
LoL	High Tolerance Set Point (A) Set heater tolerance high current set point for the selected zone. Value is current level for 100% full on.	LoL to maximum system current [1 amp increments] (Heater Low Tolerance Set Point to max Load Current rating of the Power Series)	maximum system current	5115 r/w [1] 5215 r/w [2] 5315 r/w [3]	Active if heater diagnostics is installed. This set point will only be used if the requested power is above 20%.
IndF	Inductive Load Factor Request Requests an inductive load factor adjustment.	Err invalid request (-1) Idle idle (0) req request inductive load factor adjustment (1) Act active load factor adjustment (2) CLR clears factor (3)	Idle idle (0)	5106 r/w [1] 5206 r/w [2] 5306 r/w [3]	Active if heater diagnostics is installed. Active unless Input/Output configuration is 3 phase, 2-leg. Active if ALGo is set to Ph2L . NOTE: Selecting Act or CLR will restart the system.
ICur	Inductive Current Sets the actual measured current for an inductive load.	0 to load current rating	Active load current	5107 r/w [1] 5207 r/w [2] 5307 r/w [3]	Active if heater diagnostics is installed. Active unless Input/Output configuration is 3 phase, 2-leg. Active if ALGo is set to Ph2L and IndF is set to req .

NOTE: For more information about how parameter settings affect the controller's operation, see Chapter Five, Control Methods and Features.

Display	Parameter	Range (Modbus Value)	Default	Modbus Address read/write	Conditions for Parameters to Appear
RLC Setup Alarms Configuration Menu SEt Setup Page <i>This menu is used to set up the alarm configuration. For a definition of the alarm types — standard, latched, silenced, latched and silenced, see page 5.7.</i>					
RLC Active Relay State Select the relay state on an alarm condition.	RLC energized on alarm (0) RLD de-energized on alarm (1)	RLD de-energized on alarm (1)	850 r/w	Active: Always.	
9LbL Global Alarm Configuration Selects global alarm configuration. Configures all alarms to the same type or if set to OFF allows individual alarm configuration.	SEd all alarms active (0) LRE latched (1) SIL silenced (2) LRSI latched and silenced (3) OFF off (4)	SEd all alarms active (0)	851 r/w	Active: Always.	
OPEn Heater Open Alarm Config. Select heater open alarm configuration.	SEd active (0) LRE latched (1) SIL silenced (2) LRSI latched and silenced (3)	SEd active (0)	860 r/w	Active if heater diagnostics is installed. Active if 9LbL is set to OFF .	
tOL Heater Tolerance Alarm Config. Selects heater tolerance alarm configuration.	SEd active (0) LRE latched (1) SIL silenced (2) LRSI latched and silenced (3)	SEd active (0)	861 r/w	Active if heater diagnostics is installed. Active if 9LbL is set to OFF .	
Ot Heat Sink Over Temperature Alarm Config. Select over temperature alarm configuration.	SEd active (0) LRE latched (1) SIL silenced (2) LRSI latched and silenced (3)	SEd active (0)	862 r/w	Active if 9LbL is set to OFF .	
RLT Heat Sink Over Temperature Alarm Temperature Select heat sink overtemp alarm configuration.	0 to SDT	Value equal to SDT or less. User adjustable. See Factory Menu for actual safety shutdown temp.	990 r/w	Active: Always. Output will de-energize at this heatsink shut down temperature (degrees C). The default maximum temperature is model number dependent.	
LinE Line Loss Alarm Configuration Selects the line loss alarm configuration.	SEd active (0) LRE latched (1) SIL silenced (2) LRSI latched and silenced (3)	SEd active (0)	863 r/w	Active if 9LbL is set to OFF .	

Display	Parameter	Range (Modbus Value)	Default	Modbus Address read/write	Conditions for Parameters to Appear
P.bAL	Phase Balance Alarm Config. Select phase balance configuration.	☐ SEd active (0) ☐ LRE latched (1) ☐ SIL silenced (2) ☐ LRSI latched and silenced (3)	☐ SEd active (0)	864 r/w	Active if controller is 3 phase, 3-leg configuration. Active if 9LbL is set to ☐ OFF .
LbAL	Load Balance Alarm Config. Selects the load balance alarm configuration.	☐ SEd active (0) ☐ LRE latched (1) ☐ SIL silenced (2) ☐ LRSI latched and silenced (3)	☐ SEd active (0)	865 r/w	Active if heater diagnostics is installed. Active if 9LbL is set to ☐ OFF . Active if controller is 3 phase.
Ld.F	Load Balance Percentage Selects the minimum percentage difference between loads current in phases.	0 to 100 (0 to 100)	100 (100)	991 r/w	Active if heater diagnostics is installed. Active if controller is 3 phase.
FrEQ	Frequency Out of Tolerance Alarm Configuration Select frequency tolerance alarm configuration.	☐ SEd active (0) ☐ LRE latched (1) ☐ SIL silenced (2) ☐ LRSI latched and silenced (3)	☐ SEd active (0)	866 r/w	Active if 9LbL is set to ☐ OFF .
☐ UC	Voltage Compensation Alarm Config. Selects the line compensation alarm configuration.	☐ SEd active (0) ☐ LRE latched (1) ☐ SIL silenced (2) ☐ LRSI latched and silenced (3)	☐ SEd active (0)	867 r/w	Active if 9LbL is set to ☐ OFF .
☐ OU	Over Voltage Alarm Config. Selects the line over-voltage alarm configuration.	☐ SEd active (0) ☐ LRE latched (1) ☐ SIL silenced (2) ☐ LRSI latched and silenced (3)	☐ SEd active (0)	868 r/w	Active if 9LbL is set to ☐ OFF .
☐ L.Wd	Comms Watchdog Alarm Config. Selects the communications watchdog alarm configuration.	☐ SEd active (0) ☐ LRE latched (1) ☐ SIL silenced (2) ☐ LRSI latched and silenced (3)	☐ SEd active (0)	869 r/w	Active if communications is installed. Active if 9LbL is set to ☐ OFF .

NOTE: For more information about how parameter settings affect the controller's operation, see Chapter Five, Control Methods and Features.

Display	Parameter	Range (Modbus Value)	Default	Modbus Register read/write	Conditions for Parameters to Appear
---------	-----------	-------------------------	---------	----------------------------------	--

[COP] Setup Comms Configuration Menu

[SEt] Setup Page

This menu is used to set up the communications parameters. This menu is not available unless Serial Communications is installed.

[Addr]	Unit Address Select Select device address for communications.	1 to 247	1		Active if serial communications option is installed.
[baud]	Unit Baud Rate Select Select baud rate for communications.	1200 1200 baud 2400 2400 baud 4800 4800 baud 9600 9600 baud 192 19.2K baud	9600 9600 baud		Active if serial communications option is installed.
[LJd]	Watchdog Select (On/Off) Turns on a watchdog for communications.	OFF off (0) On on (1)	OFF off (0)	85 r/w	Active if serial communications option is installed.
[SEC]	Watchdog Timeout (Sec) Selects a timeout in seconds for the communications watchdog.	0 to 9999 (0 to 9999)	9999 (9999)	86 r/w	Active if serial communications option is installed and [LJd] Watchdog is set to On .
[PLJr]	Watchdog Failure Output Power Select Selects the default power level for a watchdog timeout.	00 0 percent to 1000 100 percent (0 to 1000)	00 0 percent (0)	87 r/w	Active if serial communications option is installed and [LJd] Watchdog is set to On .

[REt] Setup Retransmit Configuration Menu

[SEt] Setup Page

This menu is used to set up the retransmit parameters. The menu is not available unless Retransmit and Heater Diagnostics are installed.

[CF9]	Retransmit Config. Select Select type of retransmit output.	00A mA (0) U0LE volts (1)	00A mA (0)	870 r/w	Active if retransmit and heater diagnostics options are installed.
[TYPE]	Retransmit Type Select Select type of retransmit information; amps or kVA.	OFF none (0) CUR current (1) HVA kVA (2)	CUR current (1)	871 r/w	Active if retransmit and heater diagnostics options are installed.

Display	Parameter	Range (Modbus Value)	Default	Modbus Register read/write	Conditions for Parameters to Appear
PHAS	Retransmit Phase Select Select the phase with information to be retransmitted.	1 phase 1 (1) 2 phase 2 (2) 3 phase 3 (3)	1 phase 1 (1)	872 r/w	Active if retransmit and heater diagnostics options are installed. Active if controller is three phase. Active if RETR ► TYPE is set to CUR or HUR .
ZONE	Retransmit Zone Select Select the zone with information to be retransmitted.	1 zone1 (1) 2 zone2 (2) 3 zone3 (3)	1 zone1 (1)	873 r/w	Active if retransmit and heater diagnostics options are installed. Active if controller is multi zone. Active if RETR ► TYPE is set to CUR or HUR .
CUR_{min}	Minimum Amps Retransmit Select minimum load current to be retransmitted.	0 to CUR<sub>max</sub> (0 to Maximum Amps Retransmit)	00 (0)	876 r/w	Active if retransmit and heater diagnostics options are installed. Active if RETR ► TYPE is set to CUR .
CUR_{max}	Maximum Amps Retransmit Select maximum load current to be retransmitted.	CUR<sub>min</sub> to load current (Minimum Amps Retransmit to load current)	load current	877 r/w	Active if retransmit and heater diagnostics options are installed. Active if RETR ► TYPE is set to CUR .
HUR_{min}	Minimum kVA Retransmit Select minimum load power to be retransmitted.	0 to HUR<sub>max</sub> (0 to Maximum kVA Retransmit)	0 (0)	878 r/w	Active if retransmit and heater diagnostics options are installed. Active if RETR ► TYPE is set to HUR .
HUR_{max}	Maximum kVA Retransmit Select maximum load power to be retransmitted.	HUR<sub>min</sub> to 9999 (Minimum kVA Retransmit to 9999)	9999 (9999)	879 r/w	Active if retransmit and heater diagnostics options are installed. Active if RETR ► TYPE is set to HUR .
RECUR_{min}	Retransmit Output Low Current (mA) Select output current that will correspond to CUR<sub>min</sub> or HUR<sub>min</sub> .	000 to RECUR<sub>max "/> (0 to Retransmit Output High Current)	0 (0)	882 r/w	Active if retransmit and heater diagnostics options are installed. Active if CFG is set to 000 .
RECUR_{max}	Retransmit Output High Current (mA) Select output current that will correspond to CUR<sub>max</sub> or HUR<sub>max</sub> .	RECUR<sub>min "/> to 2000 (Retransmit Output Low Current to 2000)	2000 (2000)	883 r/w	Active if retransmit and heater diagnostics options are installed. Active if CFG is set to 000 .

NOTE: For more information about how parameter settings affect the controller's operation, see Chapter Five, Control Methods and Features.

Display	Parameter	Range	Default	Modbus Address read/write	Conditions for Parameters to Appear
rt.U	Retransmit Output Low Voltage (Volts) Select voltage that will correspond to Cur or HUA .	0.00 to rt.U (0 to Retransmit Output High Voltage)	0 (0)	880 r/w	Active if retransmit and heater diagnostics options are installed. Active if CF9 is set to UoLt .
rt.U	Retransmit Output High Voltage (Volts) Select voltage that will correspond to Cur or HUA .	rt.U to 10.00 (Retransmit Output Low Voltage to 1000)	10.00 (1000)	881 r/w	Active if retransmit and heater diagnostics options are installed. Active if CF9 is set to UoLt .

Factory Page

To enter the Factory Page, press the Home, Left and Right keys (  ) together while in the Setup Page. Each of the following menus in the Factory Page are selected by pressing the Increment/Decrement keys ( ). Each press of the button will scroll you up or down through these main menu options.

To select a parameter within a menu, use the Left/Right arrow keys ( ). The parameter appears in the bottom display.

To select a value for each parameter (either alpha or numeric), use the Increment/Decrement keys ( ). The value appears in the upper display.

Pressing the Home key () in this menu will return you to the Display Loop.

The Factory Page contains nine menus.

The Factory Mode parameters of the Factory Page are used for calibration of the Power Series. Since the Power Series is precalibrated at the factory; field calibration may only be necessary in the event that field service work is performed. Field calibration procedures are available at Watlow's website, <http://www.watlow.com/>.

***NOTE: To enter the Factory Mode requires a password. Call Watlow at +1 (507) 454-5300, and ask an applications engineer for this password. Once the password is entered, the controller is in Factory Mode. The controller's power must be cycled to exit the Factory Mode.**

FcEtY Factory Page	dAtA System Data Manipulation
Go to a factory menu.	Loc Global/Menu Lockouts
	InFa Unit Information
Factory Mode ->	d,Ag Diagnostics
Requires factory password to access calibration parameters.	PLU Factory Password
	Lin1 Calibrate Analog Input Signal Zone 1*
	Lin2 Calibrate Analog Input Signal Zone 2*
	Lin3 Calibrate Analog Input Signal Zone 3*
	Retr Calibrate Retransmit*

Display	Parameter	Range (Modbus Value)	Default	Modbus Address read/write	Conditions for Parameters to Appear
dRtR <i>System Data Manipulation Menu</i>					
FctY <i>Factory Page</i>					
<i>This menu is used to maintain the standard and backup system data.</i>					
bAuP	Backup Data Set* Stores appropriate user configurable parameters into backup memory. See page A.7 for Power Series Backup information.	.dLE no backup requested (0) ALL all parameters listed in system, zone 1, 2 and 3 (1) 555 system related parameters, includes locks, alarms, retransmit, comms, algorithm, load type, voltage compensation (2) 2n 1 zone 1 related parameters, includes all parameters in menus Ctr 1 and OPt 1 (3) 2n 2 zone 2 related parameters, includes all parameters in menus Ctr 2 and OPt 2 (4) 2n 3 zone 3 related parameters, includes all parameters in menus Ctr 3 and OPt 3 (5)	.dLE no backup requested (0)	951 r/w	Active: Always.
dFLE	Default Data Set* Sets the appropriate parameters to the factory default values. See page A.7 for Power Series Backup information.	.dLE (0) ALL (1) 555 (2) 2n 1 (3) 2n 2 (4) 2n 3 (5) NOTE: See "Backup Data Set" above for description of the Modbus values 0 - 5.	.dLE disable restore (0)	952 r/w	Active: Always.
rESE	Restore Data Set* Restores the appropriate user configurable parameters from backup memory. See page A.7 for Power Series Backup information.	.dLE (0) ALL (1) 555 (2) 2n 1 (3) 2n 2 (4) 2n 3 (5) NOTE: See "Backup Data Set" above for description of the Modbus values 0 - 5.	.dLE disable restore (0)	950 r/w	Active: Always.

***NOTE:** These prompts (Backup, Default, and Restore Data Set) allow the user to manipulate the EEPROM contents. See Appendix, p. A.7, for more information.

Display	Parameter	Range (Modbus Value)	Default	Modbus Address read/write	Conditions for Parameters to Appear
000	Enable NVOL Storage Enable/disable non-volatile memory.	00 enable (0) 0FF disable (1)	00 (0)	959 r/w	Active: Always.

LOC Global/Menu Lockouts Menu

Fcty Factory Page

This menu is used to set the lockout parameters. Locked means that the parameters in the menu cannot be changed.

9LOC	Global Lockout Sets the state of global lockout which allows all prompts to be write protected. If set to unlocked, individual menu locks can be set.	UnL Unlocked (0) LOC Locked (1)	UnL (0)	1350 r/w	Active: Always.
CEr	Control Setup Menus Lockout Sets lock on all control setup menus.	UnL Unlocked (0) LOC Locked (1)	UnL (0)	1351 r/w	Active if 9LOC is set to UnL .
OPt	Options Setup Menus Lockout Sets lock on all options setup menus.	UnL Unlocked (0) LOC Locked (1)	UnL (0)	1352 r/w	Active if 9LOC is set to UnL . Active if heater diagnostics option is installed.
ALr	Alarms Setup Menu Lockout Sets lock on alarm configuration menu.	UnL Unlocked (0) LOC Locked (1)	UnL (0)	1353 r/w	Active if 9LOC is set to UnL .
COM	Comms Setup Menu Lockout Sets lock on communications menu.	UnL Unlocked (0) LOC Locked (1)	UnL (0)	1354 r/w	Active if 9LOC is set to UnL . Active if serial communications option is installed.
REtr	Retransmit Setup Menu Lockout Sets lock on retransmit menu.	UnL Unlocked (0) LOC Locked (1)	UnL (0)	1355 r/w	Active if 9LOC is set to UnL . Active if retransmit and heater diagnostics options are installed.
Lin	Analog Input Factory Menus Lockout Sets lock on input calibration menu.	UnL Unlocked (0) LOC Locked (1)	UnL (0)	1356 r/w	Active if 9LOC is set to UnL .
Retr	Retransmit Cal Factory Menu Lockout Sets lock on retransmit calibration menu.	UnL Unlocked (0) LOC Locked (1)	UnL (0)	1357 r/w	Active if 9LOC is set to UnL . Active if retransmit and heater diagnostics options are installed.

Display	Parameter	Range (Modbus Value)	Default	Modbus Address read/write	Conditions for Parameters to Appear
dAtA	System Data Factory Menu Lockout Sets lock on system data menu.	☐ UnL Unlocked (0) ☐ L0C Locked (1)	☐ UnL (0)	1358 r/w	Active if ☐ 9L0C is set to ☐ UnL .
dIAG	Diagnostics Facto- ry Menu Lockout Sets lock on diagnos- tics menu.	☐ UnL Unlocked (0) ☐ L0C Locked (1)	☐ UnL (0)	1359 r/w	Active if ☐ 9L0C is set to ☐ UnL .

Info Unit Information Menu

Fcty Factory Page

This menu is used to read unit information that is stored during manufacture.

SnH	Unit Serial Num- ber High Digits Reads the high digits of the serial number of the unit.	0 to 9999 (0 to 9999)	n/a	1 r	Active: Always.
SnL	Unit Serial Num- ber Low Digits Reads the low digits of the serial number of the unit.	0 to 9999 (0 to 9999)	n/a	2 r	Active: Always.
dAtE	Manufactured Date (yymm) Reads month and year of manufacture.	00 to 99 year (00 to 99) 00 to 99 month (00 to 52)	n/a	5 r	Active: Always.
HUEr	Hardware Version Reads hardware ver- sion of the unit.	00 to 9999 (0 to 9999)	n/a	7 r	Active: Always.
SUEr	Software Version Reads software ver- sion of the unit.	00 to 9999 (0 to 9999)	n/a	4 r	Active: Always.
SbLd	Software Build Number Reads software build level of the unit.	00 to 9999 (0 to 9999)	n/a	30 r	Active: Always.
rAtU	Unit Voltage Rating (Volts) Reads load voltage of the unit.	0 to 680 (0 to 680)	n/a	51 r	Active: Always.

NOTE: For more information about how parameter settings affect the controller's operation, see Chapter Five, Control Methods and Features.

Display	Parameter	Range (Modbus Value)	Default	Modbus Address read/write	Conditions for Parameters to Appear
RAEA	Unit Current Rating (Amps) Reads load current of the unit.	0 to 245 (0 to 245)	n/a	50 r	Active: Always.
ZONC	Number Zones Configured Reads the number of zones that are configured.	1 single zone (1) 2 two zone (2) 3 three zone (3)	n/a	52 r	Active: Always.
OPt	Configuration Installed Options Reads the configuration of the hardware options.	none none (0) c comms (1) r retransmit (2) rc comms/retransmit (3) h heater diagnostics (4) hc heater diagnostics/comms (5) hr heater diagnostics/retransmit (6) hrc heater diagnostics/comms/retransmit 2 (7)	n/a	54 r	Active: Always.
T	Heat Sink Temp (°C) Reads the current heat sink temp.	0 to 9999 (0 to 9999)	n/a	1590 r	Active: Always.
ALC	Heat Sink Alarm Temp Set the set point for the heat sink over temp alarm.	0 to 5dC	n/a	990 r/w	Active: Always. Same as alarm temp in Setup Menu.
5dC	Factory Safety Shutdown Temp Indicates set point for factory safety shutdown.	Factory set.	n/a	57 r	Active: Always.
HIT	Record High Heat Sink Temp Indicates record high heat sink temp.	0 to 9999 (0 to 9999)	n/a	1591 r	Active: Always.
HR5	Accum Hours (10K - 100M) Indicates accumulated system operating time (hours x 10000).	0 to 9999 (0 to 9999)	n/a	1960 r	Active: Always. Masked if hours <10000
HR5	Accum Hours (0 - 9999) Accumulated system operating time (hours).	0 to 9999 (0 to 9999)	n/a	1961 r	Active: Always.

[illegible]

Display	Parameter	Range (Modbus Value)	Default	Modbus Address read/write	Conditions for Parameters to Appear
dISP	Display Test Requests a display test.	idle (0) enable display test (1)	idle (0)	1513 r/w	Active: Always.
in	Select Discrete Input Requests a display of the state of the chosen input.	none (0) POS1 (1) POS2 (2) POS3 (3) OCR1 (4) OCR2 (5) OCR3 (6)	none (0)	1580 r/w	Active: Always. Factory mode only for write.
URL	Read Selected Input Value	lo (0) hi (1) undeterminate (2)	---	1581 r	Active if in is not set to none .
retr	Retransmit Set Test Word Sets retransmit test count.	0 to 4095 (0 to 4095)	0 (0)	1555 r/w	Active if retransmit option is installed. Factory mode only for write.

Factory Mode

The Factory Mode parameters of the Factory Page are used for calibration of the Power Series. Since the Power Series is precalibrated at the factory, field calibration may only be necessary in the event that field service work is performed. Field calibration procedures are available at Watlow's website, <http://www.watlow.com/>.

NOTE: To enter the Factory Mode requires a password. Call Watlow at +1 (507) 454-5300, and ask an applications engineer for this password. Once the password is entered, the controller is in Factory Mode. The controller's power must be cycled to exit the Factory Mode.

PLJ **Factory Password**
Fcty **Factory Page**

This menu is used to set the password for the Power Series' Factory Mode.

PLJ	Factory Password Entry Enter factory password.	0 to 9999 (0 to 9999)	1234	1799 r/w	Active: Always.
Fcty	Factory Mode Request Requests factory mode based on value set in Factory Password prompt.	OFF idle (0) retr request factory mode (1) Act factory mode active (2)	OFF idle (0)	1700 r/w	Active if factory password is valid.

Display	Parameter	Range (Modbus Value)	Default	Modbus Address read/write	Conditions for Parameters to Appear
---------	-----------	-------------------------	---------	---------------------------------	--

Calibrate Analog Input Signal Zones 1, 2, and 3 Menus
 Factory Page

This menu is used to set up the analog inputs.

Input 1 is used if Input/Output Configuration is single phase, single zone or three phase.

Input 1 and Input 2 are used if Input/Output Configuration is single phase, two zones.

All zones are used if Input/Output Configuration is single phase, three zones.

NOTE: Care should be taken to allow a buffer between each of the settings and their respective hardware limits to prevent unexpected operation because of noise or signal variations.

nnR_ Low mA Cal Point Sets the low current value for the corresponding analog input calibration.	0000 to nnR_ [or 9999 whichever is smaller] (0 to High mA Cal Point [or 9999])	4000 (4000)	5411 r/w [1] 5421 r/w [2] 5431 r/w [3]	Active if in factory mode.
nnR_ High mA Cal Point Sets the high current value for the corresponding analog input calibration.	nnR_ to 2000 (Low mA Cal Point to 20000)*	1600 (16000)	5412 r/w [1] 5422 r/w [2] 5432 r/w [3]	Active if in factory mode.

***NOTE:** The display prompts are set to two decimal places because of the resolution of the display. The comms registers are set and stored with three decimal places of resolution.

UoL_ Low V Cal Point Sets the low voltage value for the corresponding analog input calibration.	0000 to UoL_ (0 to High V Cal Point)	1000 (1000)	5413 r/w [1] 5423 r/w [2] 5433 r/w [3]	Active if in factory mode.
UoL_ High V Cal Point Sets the high voltage value for the corresponding analog input calibration.	UoL_ to 9999 (Low V Cal Point to 9999)	9000 (9000)	5414 r/w [1] 5424 r/w [2] 5434 r/w [3]	Active if in factory mode.
CALR Calibrate Analog Input Request Request analog input signal calibration.	Err invalid calibration (-1) idle calibration inactive (0) rEg enables calibration request (1)	idle calibration inactive (0)	5415 r/w [1] 5425 r/w [2] 5435 r/w [3]	Active if in factory mode.

✓ **NOTE:** The values entered in the preceding prompts are used with the corresponding analog to digital counts. The parameter will be displayed if the calibrations fails; otherwise the parameter will return to .

NOTE: For more information about how parameter settings affect the controller's operation, see Chapter Five, Features.

Display	Parameter	Range (Modbus Value)	Default	Modbus Address read/write	Conditions for Parameters to Appear
Calibrate Retransmit Menu Factory Page					
<i>This menu is used to calibrate the retransmit output. This menu is available if Retransmit is installed.</i>					
nnR	Retransmit Cal mA Low Selects the low current value for retransmit cal.	0000 to nnR [or 9999 whichever is smaller] (0 to Retransmit Cal mA High [or 9999])	4000 (4000)	5710 r/w	Active if in factory mode. Active if retransmit option is installed.
nnR	Retransmit Cal mA High Set the high current value for retransmit cal.	nnR to 2000 (Retransmit Cal mA Low to 20000)*	1600 (16000)	5711 r/w	Active if in factory mode. Active if retransmit option is installed.
UoL	Retransmit Cal Volts Low Set the low voltage value for retransmit cal.	0 to UoL (0 to Retransmit Cal Volts High)	1000 (1000)	5720 r/w	Active if in factory mode. Active if retransmit option is installed.
UoL	Retransmit Cal Volts High Set the high voltage value for retransmit cal.	UoL to 9999 (Retransmit Cal Volts Low to 9999)	9000 (9000)	5721 r/w	Active if in factory mode. Active if retransmit option is installed.
CAL	Cal Retransmit Request Request a retransmit calibration.	Err invalid calibration (-1) dLE calibration inactive (0) rE9 enables calibration request (1)	dLE calibration inactive (0)	5700 r/w	Active if in factory mode. Active if retransmit option is installed.

***NOTE:** The display prompts are set to two decimal places because of the resolution of the display. The comms registers are set and stored with three decimal places of resolution.

NOTE: For more information about how parameter settings affect the controller's operation, see Chapter Five, Features.

A

Appendix

Troubleshooting	A.2
Troubleshooting Alarms and Errors	A.4
Checking and Replacing Fuses	A.6
Power Series Backup	A.7
Modbus Registration Numbers	A.8
Product Specification	A.9
Ordering Information	A.10
Index	A.11
Prompt Index	A.13
CE Declaration of Conformity	A.14
Warranty Information	back cover

Troubleshooting

All Units

Indication	Probable Cause	Corrective Action
No LED Display	• Controller power not present. • Display not seated properly. • Bent or broken pins. • Faulty (malfunctioning) unit.	• Insure that the unit is plugged in and the power is on. • Check the display to make sure it is flush with plastic. • Pull off the display and check the connection pins; repair or replace if necessary. • Return the unit to the factory for repair.
Display Locked	• System error. • System error (no problem found). • System error not displayed. • Alarm. • Alarm (no problem found).	• Record error and address the cause of the error. • Record error and cycle controller power. If the problem persists, contact factory for assistance. • Cycle controller power. If the problem persists, contact factory for assistance or return the unit to the factory for repair. • Record alarm and address the cause of the alarm. • Record alarm and cycle controller power. If the problem persists, contact the factory for assistance.
No Heat	• Heater or load wire is not connected. • Blown fuse. • SEt > ALGo is set to OFF. • Incorrect input wiring. • Line not connected or off, or the voltage is too low. Controller will indicate ALr (Line Loss Alarm) Line. • Internal malfunction (core PCB, open SCR, gate drive inoperative, core to power supply and LM connection, power supply and line monitor PCB not seated properly on SCR).	• Check the load or load wire; connect if necessary. • Check the fuses and replace any if necessary. • See page 6.5 to set power control algorithm. • Check the input wiring and ensure that it is connected properly. (See pages 3.2-3.3 for wiring.) Input can be monitored with Ln parameter in the Display Loop. With keyboard control, test by increasing output by % and checking for heat. Be careful to not over heat anything. • Insure that line power is connected and is on at the appropriate voltage. • Return the unit to the factory for repair.
Partial Heat	• Line input voltage low.	• Insure that line power is connected and is on at the appropriate voltage. • Return the unit to the factory for repair.
Full or Partial Uncontrollable Heat	• Shorted SCR. • Input out of calibration. • Internal malfunction.	• If the controller has heater diagnostics installed, a shorted SCR will cause an error and shut down the remaining good SCRs. Return the unit to the factory for repair. • If the controller does not have heater diagnostics installed, if output power (%) Out reads 00 and there is power to the heater, the SCR is shorted; return the unit to the factory for repair. • With input signal set for 0% power, check output power display; if it is not 00, check calibration. With input signal set for 100% power, check output power display; if it is not 1000, check calibration. • Return the unit to the factory for repair.

All Units (continued)

Indication	Probable Cause	Corrective Action
Frequent Nuisance Fuse Blowing	- Improper fuse current rating. - Fuses improperly torqued. - Inadequate ventilation or cooling in the cabinet. - Intermittent short in heater.	- Refer to page 2.1; insure the fuses have the correct current rating. - Refer to page A.6 for guidelines on proper torquing of fuses. - Refer to page 2.3 for enclosure guidelines and how to determine how much cooling is required. - Replace heater.

Single Phase Units

Indication	Probable Cause	Corrective Action
No Heat	Power not routed through the internal bussbar. Controller will indicate ALr (Line Loss Alarm) LINE.	If power is not routed through or connected to the internal bussbar, Ref. 2 must be connected to another line or to neutral. (See page 3.4 for wiring.)

Multizone Units

Indication	Probable Cause	Corrective Action
No Heat	Reference not connected.	Reference connections to other lines or neutral must be made appropriately for each zone. (See page 3.5 for wiring.)
No current monitor on the display.	Two phases are 180° out of phase of each other.	When using the multizone feature, the 2 or 3 zones should be wired so that no two phases are 180° out of phase. See wiring diagram page 3.5, Figure 3.5C.

3 Phase, 2-Leg Units

Indication	Probable Cause	Corrective Action
No Heat	- Power not routed through the internal bussbar. Controller will indicate ALr (Line Loss Alarm) LINE. - Load Type Select ETYPE for 3 phase is set to unconfigured none.	- If power is not routed through or connected to the internal bussbar, Ref. 1 or 3 (not both) must be connected to middle line. (See page 3.4 for wiring.) - In the Setup Page, Setup Control Zone 1 menu, select the load type for Zone 1.

3 Phase, 3-Leg Units

Indication	Probable Cause	Corrective Action
No Heat	- Reference is not connected for 3 phase, 3-leg grounded wye unit. - Load Type Select ETYPE for 3 phase is set to unconfigured none.	- For 3 phase, 3 grounded wye models only, reference connections must be connected to neutral. (See page 3.5 for wiring.) - In the Setup Page, Setup Control Zone 1 menu, select the load type for Zone 1.
Phase angle control ramps output power up, develops a hCYL error and shuts down	Inductive load causing half cycle line loss errors hCYL. Reactance delay rdLY is set too low.	Increase rdLY value until the half cycle line loss errors no longer occur.

Troubleshooting Alarms and Errors

Alarm / Error	Condition For Alarm or Error To Occur
ALR Alarms	Any alarms that are active will be represented in binary. As an example, if a Comms Watchdog and a Phase Balance Alarm exists, Modbus register 180 will contain 0x0210. Comms Watchdog = 0000001000000000 Phase Balance = 0000000000010000 Heater Open = 0x0001 Heater Tolerance = 0x0002 Over Temperature = 0x0004 Line Loss = 0x0008 Phase Balance = 0x0010 Load Balance = 0x0020 Frequency = 0x0040 Voltage Compensation = 0x0080 Over Voltage = 0x0100 Comms Watchdog = 0x0200
ALR OPEn Heater Open Alarm	Alarm will occur when ≤ 2 amps is detected (as measured by the Power Series) for $> 20\%$ requested power.
ALR LoL Heater Tolerance Alarm	Alarm will occur when the load current detected is less than the value set in the Setup Page $>$ Options Menu $>$ LoL or is greater than the value set in LoL . This will accomplish both the overcurrent condition alarm and the heater failure low current alarm. This will only occur if requested power is greater than 20 percent.
ALR OT Heat Sink Over Temperature Alarm	Alarm will occur when the heat sink temperature is greater than the value set in the Setup Page $>$ ALR $>$ ALTC .
ALR LineE Line Loss Alarm	Alarm will occur when the zero cross signal does not occur. Caused by loss of line polarity, zero cross or voltage level signal. Also caused by zero cross timing out of tolerance. This alarm will also occur when line voltage is $<$ one-half baseline voltage.
ALR PbBL Phase Balance Alarm	Alarm will occur when measured voltage of one phase of a 3 phase, 3-leg system is $> 20\%$ different from any other.
ALR LbBL Load Balance Alarm	Alarm will occur when the load current is determined to be out of balance. User specified in the Setup Page $>$ ALR $>$ LdBF . Default to 100%.
ALR Freq Frequency Out of Tolerance Alarm	Alarm will occur if frequency is not within 47 to 63 Hz.
ALR UC Line Compensation Alarm	Alarm will occur if the voltage compensation routines cannot compensate for input line voltage changes; occurs for requested power from 5% to 95%, URTB , Ph2E control if UC = ON .
ALR OV Line Over Voltage Alarm	Alarm will occur if the line voltage is greater than the maximum rated voltage of the device. Caused by line voltage being over line voltage rating $+10\%$.
ALR LoG Communications Watchdog Alarm	Alarm will occur if no communications is detected for time specified in OUT Watchdog timeout. Not available unless Serial Communications is installed.

	Shut-down	Auto Recovery	Modbus Number	Corrective Action
	See individual alarms below.	See individual alarms below.	180 r	See individual alarms below for recommendations.
	No		181 r/w (0-4)*	Check wiring connections from load terminal to heater and heater return. Replace heater if necessary.
	No		182 r/w (2) (0-4)*	Check wiring connections from load terminal to heater and heater return. Verify adequate wire size. Replace heater if necessary.
	No		183 r/w (4) (0-4)*	Provide more cabinet ventilation or cooling. Check the fan; if faulty, return to the factory for repair. Check to see that the heat sink is clean. If necessary increase heat sink over temperature value if it is below factory safety shutdown temperature. Return to factory for SCR voltage drop and thermistor evaluation.
	Yes	Yes	184 r/w (8) (0-4)*	Check the line for high noise level and check wiring connections. Possible line sense circuitry error, return to factory for repair. Check Fct9 -> d,89 for L,18 I , L,28 I , or L,38 I , to determine the type and location of the line loss. UUoL can be caused by line voltage < one-half baseline voltage. A,Er can be caused by noisy line supplies. n,Er can be caused by a missing line. PQL can be caused by a line half cycle or a missing line. FrE9 can be caused by noisy line supplies. HC9C only active with heater diagnostics installed and indicates a half cycle loss detected in the load; can be caused by SCR non-conduction.
	Yes if Ph2E	Yes	185 r/w (0-4)*	Insure that the line voltage is the same for each phase. If line voltages are the same, check line voltages calibrations.
	Yes if Ld,IF	Yes	186 r/w (0-4)*	Address load balance on heaters. If loads are balanced, check calibration of current.
	No		187 r/w (0-4)*	Check the power supply line frequency. Power Series will not operate reliably outside 47 to 63 Hz. specification.
	No		188 r/w (0-4)*	Check for major line voltage fluctuations. If line voltage does not fluctuate, check line voltage calibration.
	No		189 r/w (0-4)*	Lower line voltage or damage to the unit may occur. If line voltage is appropriate, check line voltage calibration.
	Yes	No	190 r/w (0-4)*	Insure that the source of communications to the unit is communicating without long interruptions. Verify the integrity of the communications signals from the controlling device. Return to the factory for repair.

*Inactive - 0, Active - 1, Latched Active - 2, Latched Inactive - 3, Unlatched - 4

Alarm / Error	Condition For Alarm or Error To Occur
Err System Errors HbOL	Any system-level errors that are active will be represented in binary. As an example, if the power source is losing half cycles and an over temperature condition exists, Modbus register 195 will contain 0x00C0. Over temperature Error = 0000000001000000 Half Cycle Loss = 0000000010000000 Heater Bakeout Overcurrent = 0x0001 SCR Short = 0x0002 System Configuration = 0x0004 AD Reference Fail = 0x0008 Checksum Error = 0x0010 Ram Error = 0x0020 Over Temperature Error = 0x0040 Half Cycle Loss = 0x0080 Phase Rotation = 0x0100
Err Heater Bakeout Overcurrent Error HbOL	Error will occur when the maximum heater current during heater bakeout has been exceeded.
Err Shorted SCR Error ShrE	The shorted SCR error is detected by measuring current when the SCR is de-energized and comparing this reading to the current measured when the SCR is energized. A shorted SCR error is activated if the de-energized current reading is at least 10A and 25% or more of the energized current reading.
Err System Configuration Error ShrE	Invalid hardware configuration error.
Err Analog to Digital Failure Error Ad	Analog to digital failure error.
Err Checksum Error ChE	Invalid checksum in non-volatile memory error.
Err Ram Error rAMP	Error will occur when RAM failure is detected.
Err Over Temperature Error OE	Error will occur when heat sink temperature is greater than factory shutdown temperature SDT .
Err Half Cycle Line Loss Error HCL	Error will occur if a load half cycle loss is detected during five consecutive zone restart attempts.
Err Phase Rotation Error P.rOE	Incorrect phasing. Error will occur on a three-phase system with a 3Ld load or on a multizone (PC8 and PC9) operating on a three-phase power supply under phase angle control if the phasing is incorrect. Must be A,B,C phase rotation (CW).

Checking and Replacing Fuses

Ensure that all high voltage power is off. Slide the fuse cover down. Using an ohmmeter, measure the dc resistance of the fuse to determine if it is open. (Typical dc resistance is less than 1 ohm.)

If fuse is open, replace it by removing the old fuse using a 1/2 inch socket and a #3 Phillips screwdriver. Be careful not to drop washers off the bolt or screw ends. If they have dropped into the case, shake them out gently.

The bolt will have 2 washers. The bottom machine screw will have 2 or 3 washers, depending on the size of the SCR in the unit. **It is important that the washers are replaced in the exact order in which they were removed.** Take care installing the fuse so that its orientation matches the image that is printed on the PC board.

With the new Cooper Bussman fuse in the unit, torque the bolt to 44 inch-pounds and the screw as follows: For models PXX-F20X-XXXX and PXX-N20X-XXXX torque to 26 in.-lbs. (2.93 Nm.). For models PXX-F25X-XXXX, PXX-N25X-XXXX, PXX-F30X-XXXX, PXX-F35X-XXXX, and PXX-N30X-XXXX, torque to 44 in.-lbs. (4.95 Nm.). Close fuse cover. If unit was taken off the wall, observe all terminal torque specs when reconnecting wires. Unit should now be ready to resume operation. Reapply power to the controller and line/load terminals.




Figure A.6 — Fuse location.

Note: The fuse must be a Cooper Bussman to retain SCCR rating.

	Shut-down	Auto Recovery	Modbus Number	Corrective Action
	Yes	No	195 r	See individual errors below for recommendations.
	Yes	No	195 r, (1)	It's likely the heater is too wet for heater bakeout time selected. Increase heater bakeout time, cycle power to restart heater bakeout process.
	Yes	No	195 r, (2)	Check output with test instrument while Power (%) 0.0 is at 0.0 . If there is an output, return to the factory for a new SCR. If there is no output, check current calibration.
	Yes	No	195 r, (4)	Cycle control power. If problem persists, return to factory for repair.
	Yes	No	195 r, (8)	Cycle control power. If problem persists, return to factory for repair.
	Yes	No	195 r, (16)	Cycle control power. If problem persists, return to factory for repair.
	Yes	No	195 r, (32)	Cycle control power. If problem persists, return to factory for repair.
	Yes	No	195 r, (64)	Provide more cabinet ventilation or cooling. Check the fan; if faulty, return to factory for repair. Check to see that the heat sink is clean. Cycle control power to clear error. Return to factory for SCR voltage drop and thermistor evaluation.
	Yes	No	195 r, (128)	Line voltage is losing half cycles or SCR is not gating properly. If load is inductive, increase r d L y until error no longer occurs. Cycle control power to clear error.
	Yes	No	195 r, (256)	Three phase power is connected with incorrect phasing. Swap any two incoming phases. Cycle control power to clear error message.

Power Series Backup

There are three prompts which allow the user to manipulate the EEPROM contents: Backup Data Set, Default Data Set, and Restore Data Set. Each of these prompts have a choice of , , , , or .

There are two sets of data stored in the controller; the first is the User EEPROM and it is what is read on every power on. The second is the Backup EEPROM.

The Default Data Set prompt will update the chosen configuration parameters in the User EEPROM to values that are listed in the manual as default. It will update the chosen input and retransmit calibration parameters in the User EEPROM to the values that are stored in the Backup EEPROM by the factory.

The Backup Data Set prompt will update the chosen configuration parameters in the Backup EEPROM from the current values stored in the User EEPROM. It will NOT overwrite the calibration parameters.

The Restore Data Set prompt will update the chosen configuration parameters in the User EEPROM from the current values stored in the Backup EEPROM. It will NOT overwrite the calibration parameters.




Figure A.7 — Power Series

Modbus Register Numbers

Relative Parameter Numbers (For Absolute Numbers, add 40001 to the Relative Number.)

1	Unit Serial Number High Digits	872	Retransmit Phase Select	5103	Default Numeric Input Signal (%) Zone 1
2	Unit Serial Number Low Digits	873	Retransmit Zone Select	5104	Maximum Rate of Change (%/100msec) Zone 1
4	Software Version	876	Minimum Amps Retransmit	5105	Soft Start Time (Sec) Zone 1
5	Manufactured Date (yymm)	877	Maximum Amps Retransmit	5106	Inductive Load Factor Request Zone 1
7	Hardware Version	878	Minimum kVA Retransmit	5107	Inductive Load Current Zone 1
30	Software Build Number	879	Maximum kVA Retransmit	5110	Heater Bakeout Select (On/Off) Zone 1
50	Unit Current Rating (Amps)	880	Set Retransmit Output Low Voltage (Volts)	5111	Heater Bakeout Select Time Zone 1
51	Unit Voltage Rating (Volts)	881	Set Retransmit Output High Voltage (Volts)	5112	Current Limit Select (On/Off) Zone 1
52	Number Zones Configured	882	Set Retransmit Output Low Current (mA)	5113	Current Limit Set Point (A) Zone 1
53	Hardware Configured Type	883	Set Retransmit Output High Current (mA)	5114	Low Tolerance Set Point (A) Zone 1
54	Configuration Installed Options	950	Restore Data Set	5115	High Tolerance Set Point (A) Zone 1
55	Power Control Algorithm Select	951	Backup Data Set	5116	Heater Bakeout Overcurrent Trip Zone 1
56	Fixed Time Base (Sec)	952	Default Data Set	5201	Input Signal Method Select (dig, mA, Volt) Zone 2
57	Factory Safety Shutdown Temp	959	Enable NVOl Storage	5202	Numeric (%) Input 2 Signal
58	Load Type Select (Control Zone 1 only, 3 Phase only.)	990	Heat Sink Alarm Temp	5203	Default Numeric Input Signal (%) Zone 2
80	Voltage Compensation (On/Off)	991	Load Balance Percentage	5204	Maximum Rate of Change (%/100msec) Zone 2
85	Comms Watchdog Select (On/Off)	1350	Global Lockout	5205	Soft Start Time (Sec) Zone 2
86	Comms Watchdog Timeout (S)	1351	Control Setup Menus Lockout	5206	Inductive Load Factor Request Zone 2
87	Comms Watchdog Failure Output Power Select	1352	Options Setup Menus Lockout	5207	Inductive Load Current Zone 2
150	Analog (mA) Input 1 Signal	1353	Alarms Setup Menu Lockout	5210	Heater Bakeout Select (On/Off) Zone 2
151	Analog (V) Input 1 Signal	1354	Comms Setup Menu Lockout	5211	Heater Bakeout Select Time Zone 2
152	Line Potential (Volts) rms Line 1	1355	Retransmit Setup Menu Lockout	5212	Current Limit Select (On/Off) Zone 2
153	A/D Counts Input 1	1356	Analog Input Factory Menus Lockout	5213	Current Limit Set Point (A) Zone 2
154	Load Current (Amps) rms Line 1	1357	Retransmit Cal Factory Menu Lockout	5214	Low Tolerance Set Point (A) Zone 2
155	Single Phase 0.1 kVA Zone 1	1358	System Data Factory Menu Lockout	5215	High Tolerance Set Point (A) Zone 2
156	Load Power (kVA) Zone 1	1359	Diagnostics Factory Menu Lockout	5216	Heater Bakeout Overcurrent Trip Zone 2
157	Heater Bakeout Timeout Zone 1	1513	Display Test	5301	Input Signal Method Select (dig, mA, Volt) Zone 3
159	Output 1 Power (%)	1540	Line Loss Alarm, Most Recent Type, Line 1	5302	Numeric (%) Input 3 Signal
160	Analog (mA) Input 2 Signal	1541	Line Loss Alarm, Previous Type, Line 1	5303	Default Numeric Input Signal (%) Zone 3
161	Analog (V) Input 2 Signal	1542	Line Loss Alarm, Least Recent Type, Line 1	5304	Maximum Rate of Change (%/100msec) Zone 3
162	Line Potential (Volts) rms Line 2	1543	Line Loss Alarm, Most Recent Type, Line 2	5305	Soft Start Time (Sec) Zone 3
163	A/D Counts Input 2	1544	Line Loss Alarm, Previous Type, Line 2	5306	Inductive Load Factor Request Zone 3
164	Load Current (Amps) rms Line 2	1545	Line Loss Alarm, Least Recent Type, Line 2	5307	Inductive Load Current Zone 3
165	0.1 kVA Zone 2	1546	Line Loss Alarm, Most Recent Type, Line 3	5310	Heater Bakeout Select (On/Off) Zone 3
166	Load Power (kVA) Zone 2	1547	Line Loss Alarm, Previous Type, Line 3	5311	Heater Bakeout Select Time Zone 3
167	Heater Bakeout Timeout Zone 2	1548	Line Loss Alarm, Least Recent Type, Line 3	5312	Current Limit Select (On/Off) Zone 3
169	Output 2 Power (%)	1555	Retransmit Set Test Word	5313	Current Limit Set Point (A) Zone 3
170	Analog (mA) Input 3 Signal	1560 to 1573	Read Selected A/D Counts	5314	Low Tolerance Set Point (A) Zone 3
171	Analog (V) Input 3 Signal	1580	Select Discrete Input	5315	High Tolerance Set Point (A) Zone 3
172	Line Potential (Volts) rms Line 3	1581	Read Selected Input Value	5316	Heater Bakeout Overcurrent Trip Zone 3
173	A/D Counts Input 3	1590	Heat Sink Temp (°C)	5411	Adjust Low mA Cal Point Zone 1
174	Load Current (Amps) rms Line 3	1591	Record High Heat Sink Temp	5412	Adjust High mA Cal Point Zone 1
175	0.1 kVA Zone 3	1700	Factory Mode Request	5413	Adjust Low V Cal Point Zone 1
176	Load Power (kVA) Zone 3	1799	Factory Password Entry	5414	Adjust High V Cal Point Zone 1
177	Heater Bakeout Timeout Zone 3	1960	Accum Hours (10K - 100M)	5415	Calibrate Analog Input Request Zone 1
179	Output 3 Power (%)	1961	Accum Hours (0 - 9999)	5421	Adjust Low mA Cal Point Zone 2
180	Active Alarms	5011	Set Analog Input Low Current Scale (mA) Zone 1	5422	Adjust High mA Cal Point Zone 2
181	Heater Open alarm	5012	Set Analog Input High Current Scale (mA) Zone 1	5423	Adjust Low V Cal Point Zone 2
182	Heater Tolerance Alarm	5013	Set Analog Input Low Voltage Scale (Volts) Zone 1	5424	Adjust High V Cal Point Zone 2
183	Heat Sink Over Temperature Alarm	5014	Set Analog Input High Voltage Scale (Volts) Zone 1	5425	Calibrate Analog Input Request Zone 2
184	Line Loss Alarm	5019	Learn Input Request (Hi, Lo) Zone 1	5431	Adjust Low mA Cal Point Zone 3
185	Phase Balance Alarm	5021	Set Analog Input Low Current Scale (mA) Zone 2	5432	Adjust High mA Cal Point Zone 3
186	Load Balance Alarm	5022	Set Analog Input High Current Scale (mA) Zone 2	5433	Adjust Low V Cal Point Zone 3
187	Frequency Out of Tolerance Alarm	5023	Set Analog Input Low Voltage Scale (Volts) Zone 2	5434	Adjust High V Cal Point Zone 3
188	Line Compensation Alarm	5024	Set Analog Input High Voltage Scale (Volts) Zone 2	5435	Calibrate Analog Input Request Zone 3
189	Line Over Voltage Alarm	5029	Learn Input Request (Hi, Lo) Zone 2	5591	Baseline Voltage Learn Request Zone 1
190	Communications Watchdog Alarm	5031	Set Analog Input Low Current Scale (mA) Zone 3	5592	Baseline Voltage Learn Request Zone 2
195	Active Errors	5032	Set Analog Input High Current Scale (mA) Zone 3	5593	Baseline Voltage Learn Request Zone 3
198	Line Frequency (Hz)	5033	Set Analog Input Low Voltage Scale (Volts) Zone 3	5594	Baseline Voltage Read/Adjust Zone 1
850	Active Relay State	5034	Set Analog Input High Voltage Scale (Volts) Zone 3	5595	Baseline Voltage Read/Adjust Zone 2
851	Global Alarm Configuration	5039	Learn Input Request (Hi, Lo) Zone 3	5596	Baseline Voltage Read/Adjust Zone 3
860	Heater Open Alarm Config.	5101	Input Signal Method Select (dig, mA, Volt) Zone 1	5700	Cal Retransmit Request
861	Heater Tolerance Alarm Config.	5102	Numeric (%) Input 1 Signal	5710	Retransmit Cal mA Low
862	Over Temperature Alarm Config.			5711	Retransmit Cal mA High
863	Line Loss Alarm Configuration			5720	Retransmit Cal Volts Low
864	Phase Balance Alarm Config.			5721	Retransmit Cal Volts High
865	Load Balance Alarm Config.				
866	Frequency Out of Tolerance Alarm Configuration				
867	Voltage Compensation Alarm Config.				
868	Over Voltage Alarm Config.				
869	Comms Watchdog Alarm Configuration				
870	Retransmit Config. Select				
871	Retransmit Type Select				

Specifications (2214)

Power Bases

- Single phase, (2 SCRs)
- 3 phase, 2-leg control, (4 SCRs)
Resistive load only, zero cross firing only
- 3 phase, 3-leg control, (6 SCRs)
- 3 phase, 3-leg control, (6 SCRs) for 4 wire wye loads
- Multizone, two and three single phase zones

Output Control Options

- Zero cross contactor, V_{ac} (dc) input
- Zero cross control, fixed time base
 - Time base 1 or 4 seconds with digital programmer
- Zero cross control, variable time base
- Phase angle control and phase angle control with current limit (not for 3 phase, 2-leg models)
 - Soft start factory default 4 seconds upon power-up, and adjustable from 0.0 to 120 seconds
 - Soft start upon input signal change, output rate of change adjustable to limit max rate of change from 0.1 to 100% per 0.1 second. Factory default 10%.
- Current transformer included when required
- Line voltage compensated (variable time base and phase angle controllers only)
- Standby or non-operational mode

Output Voltage and Current Rating

- 24V~(ac) to 120V~(ac)(+10%, -15%)
- 200V~(ac) to 480V~(ac)(+10%, -15%)
- 200V~(ac) to 600V~(ac)(+10%, -15%)
- 65 through 250 amps per pole, model dependent; see Output Amperage Chart and Rating Curves
- Minimum load 1 amp rms ac
- Typical leakage current 5mA
- SCCR 200KA with fusing recommendations on page 3.6.

Alarms

- Single alarm relay
- Latching or non-latching
- Alarm silencing (inhibit) on power up for alarm
- Alarm indication LEDs, shorted SCR, open heater, fuse
- Electromechanical relay, form C contact, software configurable
 - Minimum load current 10mA @ 5V~(dc)
 - Rated resistive loads: 3 amps @ 250V~(ac) or 30V~(dc) max., inductive load rating 1.5 amps with a power factor ≥ 0.4 without contact suppression

Heater Bakeout

- For single phase (phase to neutral) and 3 phase 6 SCR models only (not for 3 phase, 2-leg models)
- Soft start with over current trip, runs until programmed bakeout time expires, then goes zero cross or phase angle firing. Factory default of 24 hours.
- Adjustable 0 - 9999 minutes with over current trip
- Internal current transformer included

Command Signal Input

Analog

- DC contactor 3.5 to 10V~(dc), must turn off at 2.5V~(dc)
- Field selectable linear voltage and current of low and high points within 0-20mA and 0-10V~(dc)
- Manual control through front panel
- Factory default 0-20mA input
- Voltage input impedance 11k Ω nominal
- Current input impedance 100 Ω nominal

Digital

- On-board digital programmer/display and optional serial communications

Retransmit

- Field selectable and scalable within 0-20mA, 800 Ω maximum load or 0-10V~(dc), 1K Ω minimum load.
The default is 4-20mA.
- Resolution:
 - mA ranges = 5 μ A nominal
 - V~(dc) = ranges 2.5mV nominal
- Calibration accuracy:
 - mA ranges = $\pm 20\mu$ A
 - V~(dc) ranges = ± 10 mV
- Temperature Stability: 100ppm $^{\circ}$ C

Digital Programmer/Display and Communications Capabilities

- Programming functions
 - Adjust input and output control type, alarms and soft start. Heater bakeout and current limit prompts also.
- Monitoring functions
 - Display input and output values along with actual output current
- Data retention of digital programmer/display upon power failure via nonvolatile memory

Serial Communications

- RS-232 for single drop control
- EIA-485 for single or multidrop control
 - 32 units maximum can be connected. With additional 485 repeater hardware, up to 247 units may be connected
- Isolated
- Modbus™ RTU protocol
- 1200, 2400, 4800, 9600, 19200 baud rates
- Data format 8 data bits, no parity, one stop bit

Controller Power Supply

- Universal line voltage input range 100 to 240V~(ac) (+10%, -15%) @ 55VA maximum
- 50/60Hz $\pm 5\%$ line frequency independent
- Controller line voltage for electronic power supply can be run on separate line voltage

Natural Convection and Fan Cooled Models

- Cabinet venting may be required

Power Dissipation (Watts)

- Approximately 1.25 watts/amp per controlled leg

Isolation

- Command signal to load and line/load to ground 2200V~(ac) minimum
- On-board semiconductor fuses provide SCR protection

Mounting

- Back panel mount on F35 models
- Other amperage ratings: Removable mounting plate
- Heat sink fins must be mounted in vertical orientation

High Current Terminals

- Touch safe
- 3/8 inch Allen head compression terminals will accept #6 AWG to 350 MCM wire. Allen wrench adapter (included) for 3/8 inch socket, or 10 mm, 6 point only.
- Torque to 180 in.-lbs. (20.3 Nm.)
- Wire strip to 30 mm (1-1/8 inch)

Controller Terminals

- Touch safe
- 2.5 mm (1/8 inch) blade screwdriver, accepts 12-22 AWG or 2 No. 22-18 AWG wires.
- Torque to 8 in.-lbs. (0.9 Nm.)
- Wire strip to 6 mm (0.24 inch)
- Requires 90C wire insulation rating on line and load terminals.

Operating Environment

- 50 $^{\circ}$ C (122 $^{\circ}$ F) base rating
 - 0 to 60 $^{\circ}$ C (32 to 140 $^{\circ}$ F) fan cooled
 - 0 to 65 $^{\circ}$ C (32 to 149 $^{\circ}$ F) natural convection cooled
- 0 to 90% RH, non-condensing
- Meets EN50178, Pollution degree 3

Storage Temperature

- -40 to 85 $^{\circ}$ C (-40 to 185 $^{\circ}$ F)

Dimensions

- Width x height x depth
 - 191 mm x 354 mm x 200 mm on N20 through F30 models (7.5 in x 14.0 in x 7.9 in)
 - 337 mm x 421 mm x 234.1 mm on F35 models (13.3 in x 16.6 in x 9.2 in)

Shipping Weight

- 10.3 kg. (23 lbs.) on N20 through F30 models
- 17.2 kg. (38 lbs.) on F35 models

Agency Approvals

- UL 508 and C-UL listed, file #E73741
- CE marked, see Declaration of Conformity on page A.14

Ordering Information

(1528)

To order, complete the code number
to the right with the information below:

Power Series = Microprocessor-Based
Solid State Power Controller

Package Style _____

C = 65 to 250 Amps

Phase _____

- 1 = 1-phase
- 2 = 3-phase, 2-leg control (4 SCRs)
- 3 = 3-phase, 3-leg control (6 SCRs)
- 4 = 3-phase, 4-wire, wye connected load
- 8 = 2 single-phase zones (specify 01 or 03 for Custom)
- 9 = 3 single-phase zones (specify 01 or 03 for Custom)

Heater Diagnostics (includes current limit) _____

- 0 = None
- 1 = Heater Diagnostics (Current Limiting and Heater Bakeout
are only available on single-phase and 3-phase, 3-leg Controllers)

Output Amperage Rating _____

(See Amperage Chart below; insert code number here.)

Output Voltage Rating _____

- A = 24 to 120V~
- B = 200 to 480V~
- C = 200 to 600V~

Communications _____


- 0 = None
- 1 = EIA/TIA 232/485 communications, isolated (field selectable)

Feedback/Retransmit _____

- 0 = None
- 1 = Load current feedback (0 to 10V or 0 to 20mA scalable retransmit output)
(Must have heater diagnostics selected.)

Custom _____

- 00 = None
- AA = No Watlow logo with agency approval marks
- AB - ZZ = Custom, consult factory for options
- 01 = Select for PC8 or PC9 using single-phase power supply, Watlow logo
- 03 = Select for PC8 or PC9 using multi-phase power supply, Watlow logo



IMPORTANT NOTES:

Phase Angle:

Phase angle and phase angle with current limit are available on single phase, and 3 phase/3-leg models only. To get current limiting, you must also order heater diagnostics.

Heater Bakeout:

Heater bakeout is available on single phase, and 3 phase/3-leg models with heater diagnostics.

Amperage Chart @ 50°C (122°F)

	Single Phase		2 Single Phase Zones 3 Phase, 2-Leg		3 Single Phase Zones 3 Phase, 3-Leg	
	Code	Amperage	Code	Amperage	Code	Amperage
Non Fan Cooled	N20	100A	N20	80A	N20	65A
	N25	140A	N25	105A	N25	85A
	N30	165A	N30	120A	N30	105A
Fan Cooled	F20	125A	F20	120A	F20	90A
	F25	200A	F25	160A	F25	140A
	F30	250A	F30	185A	F30	155A
			F35	250A	F35	225A

NOTE: User documentation may be available in French, German, Spanish, Italian, and Dutch, as well as English. Check Watlow's website (www.watlow.com/) for availability.

NOTE: See semiconductor fuses and holders on pages 2.1 and 3.6.

Index

A

A to D Failure Error A.4
Accum Hours (0 - 9999) 6.18
Accum Hours (10K - 100M) 6.18
Active Alarms 6.1
Active Relay State 6.10
Adjust High mA Cal Point Zones 1-3 6.21
Adjust High V Cal Point Zones 1-3 6.21
Adjust Low mA Cal Point Zones 1-3 6.21
Adjust Low V Cal Point Zones 1-3 6.21
Alarms 5.7
 active relay state 5.7
 global 5.7
 latched 5.7
 latched and silenced 5.7
 silencing 5.7
 standard 5.7
Alarms Setup Menu Lockout 6.16
Alarms, troubleshooting A.4-A.5
 communications watchdog alarm A.4
 frequency out of tolerance alarm A.4
 heat sink over temperature alarm A.4
 heater open alarm A.4
 heater tolerance alarm A.4
 line compensation alarm A.4
 line loss alarm A.4
 line over voltage alarm A.4
 load balance alarm A.4
 phase balance alarm A.4

Ambient Temperature Rating 2.1
Analog (mA) Input 1 Signal 6.2, 6.3
Analog (mA) Input 2 Signal 6.2, 6.3
Analog (mA) Input 3 Signal 6.3
Analog (mA) Input Signal 6.1
Analog (V) Input 1 Signal 6.2, 6.3
Analog (V) Input 2 Signal 6.2, 6.3
Analog (V) Input 3 Signal 6.3
Analog (V) Input Signal 6.1, 6.4
Analog Input Factory Menus Lockout 6.16

B

Backup A.7
Backup Data Set 6.15
Baseline Voltage 5.6
Baseline Voltage Learn Req. Zones 1-3 6.7
Baseline Voltage Read/Adj. Zones 1-3 6.7

C

Cal Retransmit Request 6.22
Calibrate Analog Input Req. Zones 1-3 6.21
Calibrate Analog Input Signal Zones 1-3 Menus 6.21
Calibrate Retransmit Menu 6.22
Comms Setup Menu Lockout 6.16
Comms Watchdog Alarm Config. 6.11
Communications 5.8
Communications Watchdog Alarm A.4
Configuration Installed Options 6.18

Control Configurations 1.2
 3 phase, 2-leg 1.2
 3 phase, 3-leg 1.2
 3 phase, multizone 1.2
 single phase 1.2
Control Setup Menus Lockout 6.16
Cooling 2.3
Current Limit Select (On/Off) Zones 1-3 6.8
Current Limit Set Point (A) Zones 1-3 6.9
Current Limiting 5.5

D

DC Contactor - Zero Cross 5.2
Default Data Set 6.15
Default Numeric Input Sig. (%) Zones 1-3 6.6
Diagnostics Factory Menu Lockout 6.17
Diagnostics Menu 6.19-6.20
Dimensions 2.2
Display Loop Errors 6.1, A.4-A.7
Display Loop Menu 4.2, 4.3
Display Phase Selection 1-3 6.4
Display Test 6.20
Display Zone Selection 6.2, 6.3

E

Enable NVOL Storage 6.16
Enclosure Guidelines 2.3
Errors, troubleshooting A.4-A.5
 A to D failure error A.4
 half cycle line loss error A.6
 heater bakeout overcurrent error A.4
 nonvolatile memory checksum error A.6
 over temperature error A.6
 phase rotation error A.6
 RAM error A.6
 shorted SCR error A.4
 system configuration error A.4

F

Factory Mode 6.20
Factory Mode Request 6.20
Factory Page Menu 4.2, 4.4
Factory Page Parameters 6.14 - 6.22
Factory Password 6.20
Factory Password Entry 6.20
Factory Safety Shutdown Temp 6.18
Fan Cooled Output Rating Curves 2.5
Fast Start Guide 5.10
Fixed Time Base (Sec) 6.5
Fixed Time Base - Zero Cross 5.1
Frequency Out of Tol. Alarm Config. 6.11
Frequency Out of Tolerance Alarm A.4
Fuse Replacement A.6

G

Global Alarm Configuration 5.7, 6.10
Global Lockout 5.6, 6.16
Global/Menu Lockouts Menu 6.16-6.17

H

Half Cycle Line Loss Error A.6
Hardware Version 6.17
Harsh Environment 2.3
Heat Sink Alarm Temp 6.18
Heat Sink Over Temperature Alarm A.4
Heat Sink Over Temperature Alarm

Configuration 6.10
Heat Sink Over Temperature Alarm Temperature 6.10
Heat Sink Temp (°C) 6.18
Heater Bakeout 5.4
Heater Bakeout Overcurrent Error A.4
Heater Bakeout Overcurrent Trip Zones 1-3 6.8
Heater Bakeout Select (On/Off) Zones 1-3 6.8
Heater Bakeout Select Time Zones 1-3 6.8
Heater Bakeout Timeout 6.2
Heater Bakeout Timeout Zone 1 6.2, 6.3
Heater Bakeout Timeout Zone 2 6.2, 6.3
Heater Bakeout Timeout Zone 3 6.3
Heater Diagnostics Feature 1.2
Heater Open Alarm A.4
Heater Open Alarm Config. 6.10
Heater Tolerance Alarm A.4
Heater Tolerance Alarm Config. 6.10
Heater Tolerance Detection 5.4
High Tolerance Set Point (A) Zones 1-3 6.9

I J

Inductive Current 6.9
Inductive Load Factor Request 6.9
Input 5.6
 signal selection 5.6
Input Signal Method Select (dig, mA, Volt) Zones 1-3 6.6
Input Wiring 3.2-3.3
 2 zone 3.3
 3 zone 3.3
 communications 3.2
 control power and alarm 3.2
 retransmit 3.2
 single zone 3.3
Installation 2.1-2.6

K

Keys and Displays 4.1

L

Learn Input Learn Req. (Hi, Lo) Zones 1-3 6.7
Line Compensation Alarm A.4
Line Frequency (Hz) 6.1
Line Loss Alarms 6.19, A.4
Line Loss Alarm Configuration 6.10
Line Over Voltage Alarm A.4
Line Potential (Volts) rms Zone 1 6.3, 6.4
Line Potential (Volts) rms Zone 2 6.3, 6.4
Line Potential (Volts) rms Zone 3 6.3, 6.4
Line Potential (Volts) rms 6.2
Line Power Wiring 3.4
Line Voltage Compensation 6.6
Load Activity Indicator 6.1
Load Balance Alarm A.4
Load Balance Alarm Config. 6.11
Load Balance Percentage 6.11
Load Current (Amps) rms 6.2
Load Current (Amps) rms Zone 1 6.3, 6.4
Load Current (Amps) rms Zone 2 6.3, 6.4
Load Current (Amps) rms Zone 3 6.4
Load Power (kVA) 6.2, 6.4
Load Power (kVA) Zone 1 6.3, 6.4

- Load Power (kVA) Zone 2 6.3, 6.4
- Load Power (kVA) Zone 3 6.4
- Load Type Select (Control Zone 1 only, 3 phase only.) 6.7
- Low Tolerance Set Point (A) Zone 1-3 6.9

M

- Maintenance 2.4
- Manufactured Date (yymm) 6.17
- Maximum Amps Retransmit 6.13
- Maximum kVA Retransmit 6.13
- Maximum Rate of Change 5.3
 - adjustable on signal change 5.3
- Maximum Rate of Change (%/100msec) Zone 1-3 6.8
- Menu Lock 5.6
- Minimum Amps Retransmit 6.13
- Minimum kVA Retransmit 6.13
- Model Number A.10
- Mounting 2.2-2.3

N

- Natural Convection Output Rating Curves 2.6
- Navigation and Software 4.1-4.4
- Nonvolatile Memory Checksum Error A.4
- Number Zones Configured 6.18
- Numeric (%) Input 1 Signal 6.2, 6.3, 6.4
- Numeric (%) Input 2 Signal 6.2, 6.3, 6.4
- Numeric (%) Input 3 Signal 6.3, 6.4
- Numeric (%) Input Signal 6.1

O

- Options Setup Menus Lockout 6.16
- Output 1 Power (%) 6.2, 6.3, 6.4
- Output 2 Power (%) 6.2, 6.3
- Output 3 Power (%) 6.2, 6.3
- Output Power (%) 6.2, 6.4
- Output Rating Curves 2.5-2.6
- Output Wiring 3.4-3.5
 - 3 phase, 2-leg, 4 SCR 3.4
 - 3 phase, 3-leg, 6 SCR, 4-wire wye 3.5
 - 3 phase, 3-leg, SCR/diode hybrid 3.5
 - multizone 3.5
 - single phase 3.4
- Over Temperature Error A.6
- Over Voltage Alarm Config. 6.11

P Q

- Phase Angle 5.2
- Phase Balance Alarm A.4
- Phase Balance Alarm Config. 6.11
- Phase Rotation Error A.6
- Power Control Algorithm Select 6.5
- Prompt Index A.13

R

- RAM Error A.6
- Read Selected Analog to Digital Counts 6.19
- Read Selected Input Value 6.20
- Record High Heat Sink Temp 6.18
- Removing the Power Series 2.4
- Restore Data Set 6.15
- Retransmit 5.9
- Retransmit Cal Factory Menu Lockout 6.16
- Retransmit Cal mA High 6.22
- Retransmit Cal mA Low 6.22

- Retransmit Cal Volts High 6.22
- Retransmit Cal Volts Low 6.22
- Retransmit Config. Select 6.12
- Retransmit Phase Select 6.13
- Retransmit Set Test Word 6.20
- Retransmit Setup Menu Lockout 6.16
- Retransmit Type Select 6.12
- Retransmit Wiring 3.2
- Retransmit Zone Select 6.13

S

- Safety Information inside front cover
- Select Analog to Digital Channel 6.19
- Select Discrete Input 6.20
- Set Analog Input High Cur. (mA) Zone 1-3 6.6
- Set Analog Input High Volt. (Volts) Zone 1-3 6.7
- Set Analog Input Low Cur. (mA) Zone 1-3 6.6
- Set Analog Input Low Volt. (Volts) Zone 1-3 6.6
- Set Retransmit Output High Cur. (mA) 6.13
- Set Retransmit Output High Volt. (Volts) 6.14
- Set Retransmit Output Low Cur. (mA) 6.13
- Set Retransmit Output Low Volt. (Volts) 6.14
- Setup Alarms Configuration Menu 6.10-6.11
- Setup Comms Configuration Menu 6.12
- Setup Control Algorithm 6.5
- Setup Control Zone 1, 2, and 3 Menus 6.6-6.7
- Setup Options Zone 1, 2, and 3 Menus 6.8-6.9
- Setup Page Menu 4.2, 4.4
- Setup Page Parameters 6.5 - 6.13
- Setup Page Select 6.5
- Setup Retransmit Configuration Menu 6.12-6.14
- Shorted SCR Error A.4
- Signal Selection 5.6
- Soft Start 5.3
 - adjustable on power up 5.3
- Soft Start Time (Sec) Zones 1-3 6.8
- Software Build Number 6.17
- Software Version 6.17
- Specification A.9
- System Configuration Error A.4
- System Data Factory Menu Lockout 6.17
- System Data Manipulation Menu 6.15

T

- Technical Assistance inside front cover
- Torque 3.1, 3.2, 3.4
- Troubleshooting A.2-A.3
- Troubleshooting Alarms and Errors A.4-A.7

U V

- Unit Address Select 6.12
- Unit Baud Rate Select 6.12
- Unit Current Rating (Amps) 6.18
- Unit Information Menu 6.17-18
- Unit Serial Number High Digits 6.17
- Unit Serial Number Low Digits 6.17
- Unit Voltage Rating (Volts) 6.17
- Variable Time Base - Zero Cross 5.2
- Voltage Compensation Alarm Config. 6.11

W X Y Z

- Warnings and Cautions inside front cover
- Warranty Information back cover
- Watchdog Failure Output Power Select 6.12
- Watchdog Select (On/Off) 6.12
- Watchdog Timeout 6.12
- Wire Bending Radius 2.1
- Wire Stripping 3.1, 3.2, 3.4
- Wiring 3.1-3.6
 - input 3.2-3.3
 - output 3.4-3.5
- Wiring Example 3.6
- Your Comments inside front cover
- Zero Cross 5.1

Prompt Index

A

Ad	Select Analog to Digital Channel 6.19
Addr	Unit Address Select 6.12
ALC	Heat Sink Alarm Temp 6.18
ALC	Heat Sink Over Temperature Alarm Temperature 6.10
AL9c	Active Relay State 6.10
AL9o	Power Control Algorithm Select 6.5
AL9o	Setup Control Algorithm Menu 6.5-6.6
ALr	Alarms Setup Menu Lockout 6.16
ALr	Setup Alarms Configuration Menu 5.7, 6.10-6.11

B

bAud	Unit Baud Rate Select 6.12
bUpP	Backup Data Set 6.15
bL U	Baseline Voltage Read/Adjust 6.7

C

C	Heat Sink Temperature (°C) 6.18
CLAR	Calibrate Analog Input Request 6.21
CLAr	Cal Retransmit Request 6.22
CF9	Retransmit Configuration Select 6.12
CIn	Analog Input Factory Menus Lockout 6.16
CIn1 , CIn2 , CIn3	Calibrate Analog Input Signal Zone 1, 2, or 3 Menus 6.21-6.22
CL A	Current Limit Set Point (A) 5.5, 6.9
CLi	Current Limit Select (On/Off) 5.5, 6.8
COP9	Comms Setup Menu Lockout 6.16
COP9	Setup Comms Configuration Menu 6.12
CnES	Read Selected Analog to Digital Counts 6.19
cont	dc contactor 5.2
Crtcr	Retransmit Cal Factory Menu Lockout 6.16
Crtcr	Calibrate Retransmit Menu 6.22
Ctr	Control Setup Menus Lockout 6.16
Ctr1 , Ctr2 , Ctr3	Setup Control Zone 1, 2, and 3 Menus 6.6-6.8
Cur	Load Current (Amps) rms 6.2
Cur1 , Cur2 , Cur3	Load Current (Amps) rms 6.3, 6.4
Cur	Maximum Amps Retransmit 6.13
Cur	Minimum Amps Retransmit 6.13
Cudd	Comms Watchdog Alarm Configuration 6.11

D

dAER	System Data Factory Menu Lockout 6.17
dAER	System Data Manipulation Menu 6.15-6.16
dAEE	Manufactured Date (yymm) 6.17
dFLt	Default Data Set 6.15
dFLt	Default Numeric Input Signal (%) 6.6
d.r9	Diagnostics Factory Menu Lockout 6.17
d.r9	Diagnostics Menu 6.19-6.20
dISP	Display Test 6.20

E F

FctY	Factory Mode Request 6.20
FctY	Factory Page 6.14 - 6.22
FrE9	Frequency Out of Tolerance Alarm Configuration 6.11
FrE9	Line Frequency (Hz) 6.1
Ftb	Fixed Time Base 5.1
Ftb	Fixed Time Base (Sec) 6.5

G

GLbL	Global Alarm Configuration 5.7, 6.10
GLOC	Global Lockout 5.6, 6.16

H

HbC	Heater Bakeout Overcurrent Trip 6.8
Hbo	Heater Bakeout Select (On/Off) 5.4, 6.8
Hbt	Heater Bakeout Timeout 6.2
Hbt1 , Hbt2 , Hbt3	Heater Bakeout Timeout 6.2, 6.3
HiT	Record High Heat Sink Temp 6.18
HrS	Accum Hours (10K - 100M) 6.18
HrS	Accum Hours (0 - 9999) 6.18
HUR	Load Power (kVA) 6.2, 6.4
HUR	Maximum kVA Retransmit 6.13
HUR	Minimum kVA Retransmit 6.13
HUR1 , HUR2 , HUR3	Load Power (kVA) 6.3, 6.4
HUER	Hardware Version 6.17

I J K

ICur	Inductive Current 6.9
In	Analog (mA or V) or Numeric (%)
In	Input Signal 6.1, 6.4
In	Input Signal Method Select (dig, mA, volt) 6.6
In	Select Discrete Input 6.20
In1 , In2 , In3	Analog (mA or V) or Numeric (%) Input Signal 6.2, 6.3
IndF	Inductive Load Factor Request 6.9
Info	Unit Information Menu 6.17-6.18

L

LlA1	Line Loss Alarm, Most Recent 6.19
LlA2 , LlA3	Line Loss 6.19
LlA3 , LlA3	Alarm Type 6.19
LlA1	Line Loss Alarm, Previous 6.19
LlA1	Line Loss Alarm, Least Recent 6.19
LbAL	Load Balance Alarm Config. 6.11
Ld.F	Load Balance Percentage 6.11
Line	Line Loss Alarm Config. 6.10
LoAd	Load Activity Indicator 6.1
LOC	Global/Menu Lockouts Menu 6.16-6.17
Lrn.A	Learn Input Learn Request (Hi, Lo) 6.7
Lrn.U	Baseline Voltage Learn Request 6.7

M N

Mn	Heater Bakeout Select Time 5.4, 6.8
nnA	Adjust High mA Cal Point 6.21
nnA	Adjust Low mA Cal Point 6.21
nnA	Retransmit Cal mA High 6.22
nnA	Retransmit Cal mA Low 6.22
nnA	Set Analog Input High Current (mA) 6.6
nnA	Set Analog Input Low Current (mA) 6.6
nVOL	Enable NVOL Storage 6.16

O

OPEn	Heater Open Alarm Config. 6.10
OPt	Config. Installed Options 6.18
OPt	Options Setup Menus Lockout 6.16
OPt1 , OPt2 , OPt3	Setup Options Zone 1, 2, and 3 Menus 6.8-6.9
OE	Heat Sink Over Temperature Alarm Configuration 6.10
OU	Over Voltage Alarm Config. 6.11
Oue	Output Power (%) 6.2, 6.4
Oue1 , Oue2 , Oue3	Output Power (%) 6.2, 6.3

P Q

P.bAL	Phase Balance Alarm Config. 6.11
PhAS	Display Phase 6.4
PhAS	Retransmit Phase Select 6.13
Ph2E	Phase Angle 5.2
PLJ	Factory Password 6.20
PLJ	Factory Password Entry 6.20
PLJr	Watchdog Failure Output Power Select (%) 6.12

R

rAER	Unit Current Rating (Amps) 6.18
rAEE	Maximum Rate of Change (%/100msec) 6.8
rAeU	Unit Voltage Rating (Volts) 6.17
rdLY	Reactance Delay 6.8
rESE	Restore Data Set 6.15
rEtr	Retransmit Set Test Word 6.20
rEtr	Retransmit Setup Menu Lockout 6.16
rEtr	Setup Retransmit Configuration Menu 6.12-6.14
re.C	Set Retransmit Output High Current (mA) 6.13
re.C	Set Retransmit Output Low Current (mA) 6.13
re.U	Set Retransmit Output High Voltage (Volts) 6.14
re.U	Set Retransmit Output Low Voltage (Volts) 6.14

S

SbLd	Software Build Number 6.17
SdC	Factory Safety Shutdown Temp 6.18
SEC	Watchdog Timeout (Sec) 6.12
SEE	Setup Page Select 6.5-6.13
Sn	Unit Serial Number High Digits 6.17
Sn	Unit Serial Number Low Digits 6.17
SoFE	Soft Start 5.3
SoFE	Soft Start Time (Sec) 6.8
SUER	Software Version 6.17

T

tOL	Heater Tolerance Alarm Configuration 6.10
tOL	High Tolerance Set Point (A) 6.9
tOL	Low Tolerance Set Point (A) 6.9
tYPE	Load Type Select 6.7
tYPE	Retransmit Type Select 6.12

U V W X Y Z

UAl	Read Selected Input Value 6.20
UC	Line Voltage Compensation 6.6
UC	Voltage Compensation Alarm Configuration 6.11
UoL	Line Potential (Volts) rms 6.2
UoL1 , UoL2 , UoL3	Line Potential (Volts) rms 6.3, 6.4
UoL	Adjust High V Cal Point 6.21
UoL	Adjust Low V Cal Point 6.21
UoL	Retransmit Cal Volts High 6.22
UoL	Retransmit Cal Volts Low 6.22
UoL	Set Analog Input High Voltage (Volts) 6.7
UoL	Set Analog Input Low Voltage (Volts) 6.6
UrEb	Variable Time Base 5.2
UJd	Watchdog Select (On/Off) 6.12
ZonC	Number Zones Configured 6.18
ZonE	Retransmit Zone Select 6.13
ZonE	Zone Display Selection 6.2, 6.3

Declaration of Conformity

Power Series Power Controller



WATLOW Winona Inc.

1241 Bundy Boulevard

Winona, Minnesota 55987 USA

Declares that the following product:

English

Designation: **Power Series Power Controller**
Model Numbers: PC (1, 2, 3, 4, 8 or 9) (0 or 1) — (N20, N25, N30, F20, F25, F30 or F35)
(A, B or C) — (0 or 1) (0 or 1) (00 or AA-ZZ)
Classification: Solid State Power Controller, Class II, Pollution Degree III
Rated Voltage: 24 to 600V~
Rated Frequency: 50/60 Hz

Meets the essential requirements of the following European Union Directive(s) using the relevant section(s) of the normalized standards and related documents shown:

2004/108/EC Electromagnetic Compatibility Directive
EN 61326: 1997 Electrical equipment for measurement, control and laboratory use - EMC requirements (Group 1, Class A)
EN 61000-4-2: 1995 Electrostatic discharge
EN 61000-4-4: 1995 Electrical fast transients
EN 61000-4-8: 1993 Magnetic fields
EN 61000-4-3: 1996 Radiated immunity
EN 61000-4-6: 1996 Conducted immunity
EN 61000-4-5: 1995 Surge immunity
EN 61000-4-11: 1994 Voltage dips, short interruptions and voltage variations immunity
ENV 50204: 1995 Cellular phone
Note 1: Use of an external filter is required to comply with EN 61326 conducted emission limits. See page 2 (reverse) for information and instructions.
Note 2: A Line Impedance Stabilization Network (LISN), not a line clamp, was used for all emissions testing.

2006/95/EC Low-Voltage Directive

EN 50178: Electronic equipment for use in power installations

The Phase Angle Control Mode option for Power Series is excluded from this declaration.

Per 2002/95/EC W.E.E. Directive  Please Recycle Properly.

These devices contain lead solder and are not RoHS compliant.
They are a Control Device and fall outside the scope of 2002/95/EC Directive.

Déclare que le produit suivant :

Français

Désignation : **Bloc de puissance Power Series**
Numéro de modèle : PC (1, 2, 3, 4, 8 ou 9) (0 ou 1) — (N20, N25, N30, F20, F25, F30 ou F35)
(A, B ou C) — (0 ou 1) (0 ou 1) (00 ou AA-ZZ)
Classification : Blocs de puissance à semi-conducteurs, Perturbations Classe II, Degré III
Tension nominale : 24 à 600 V ~
Fréquence nominale : 50/60 Hz

Sont conformes aux principales normes des directives de l'Union Européenne au regard de la (des) section(s) pertinente(s) des normes standards et documents apparentés présentés :

2004/108/EC Directive de compatibilité électromagnétique
EN 61326: 1995 Appareillage électrique pour la mesure, la commande et l'usage de laboratoire — Prescriptions relatives à la Compatibilité Electro Magnétique (groupe 1, classe A)
EN 61000-4-2: 1997 Décharge électrostatique
EN 61000-4-4: 1995 Transitoires rapides électriques
EN 61000-4-8: 1993 Champs magnétiques
EN 61000-4-3: 1996 Immunité rayonnée
EN 61000-4-6: 1996 Immunité conduite
EN 61000-4-5: 1995 Essai d'immunité aux ondes de choc
EN 61000-4-11: 1994 Essais d'immunité relatifs aux creux de tension, coupures brèves et variations de tension
EN 61000-4-5: 1995 Insensibilité aux surtensions
EN 61000-4-11: 1994 Insensibilité aux chutes subites, aux courtes interruptions et aux variations de tension
ENV 50204: 1995 Téléphone cellulaire
Remarque 1: Il est nécessaire d'utiliser un filtre externe pour se conformer aux limites d'émission par conduction de la norme EN 61326. Voir les informations et instructions au verso.
Remarque 2: Un réseau de stabilisation d'impédance de ligne (RSIL), et non pas une limite de champ, a été utilisé pour tous les tests d'émission.

2006/95/EC Directive de basse tension

EN 50178: Equipement électro unique utilisé sur des installations électriques

Les blocs de puissance en version angle de phase ne sont pas couverts par cette déclaration.

Veuillez recycler le matériel  conformément à la Directive WEEE 2002/95/CE.

Ces dispositifs contiennent de la brasure au plomb et ne sont pas conformes à la directive RoHS. Il s'agit de dispositifs de contrôle qui ne rentrent pas dans le cadre de la Directive 2002/95/EC.

(2215)

Erklärt, daß das folgende Produkt:

Deutsch

Beschreibung: **Power Series Thyristor Leistungssteller**
Modellnummern: PC (1, 2, 3, 4, 8 oder 9) (0 oder 1) — (N20, N25, N30, F20, F25, F30 oder F35) (A, B oder C) — (0 oder 1) (0 oder 1) (00 oder AA-ZZ)
Klassifikation: Halbleiter-Leistungssteller, Installationskategorie II, Emissionsgrad III
Nennspannung: 24-600 V~
Nennfrequenz: 50/60 Hz

Erfüllt die wichtigsten Normen der folgenden Anweisung der Europäischen Gemeinschaft unter Verwendung des wichtigen Abschnitts der normierten Spezifikationen und der untenstehenden einschlägigen Dokumente:

2004/108/EC EWG Elektromagnetische Verträglichkeit
EN 61326: 1997 Elektrogeräte zur Messung, Regelung und zum Laboreinsatz EMC-Richtlinien (Gruppe 1, Klasse A)
EN 61000-4-2: 1995 Elektrostatische Entladung
EN 61000-4-4: 1995 Elektrische schnelle Stöße
EN 61000-4-8: 1993 Magnetische Felder
EN 61000-4-3: 1996 Strahlungsimmunität
EN 61000-4-6: 1996 Leitungsimmunität
EN 61000-4-5: 1995 Spannungstoßimmunität
EN 61000-4-11: 1994 Immunität gegen Spannungsgefälle, kurze Unterbrechungen und Spannungsabweichungen
ENV 50204: 1995 Mobiltelefon
Hinweis 1: Die Verwendung eines externen Filters kann erforderlich sein, um der EN 61326. Siehe Seite 2 (Rückseite) für Informationen und Anweisungen.
Hinweis 2: Zur Emissionsmessung wurde ein Leitungsimpedanz-Stabilisierungsnetzwerk (LISN), keine Klemme, eingesetzt.

2006/95/EC EWG Niederspannungsrichtlinie

EN 50178: Elektronische Geräte für die Verwendung bei Starkstrominstallationen

Leistungssteller mit Phasenanschnittsteuerung sind von dieser Erklärung ausgeschlossen.

Per 2002/95/EC W.E.E. Direktive  Bitte ordnungsgemäß recyceln

Diese Geräte enthalten Blei und sind nicht RoHS-konform. Es handelt sich um Steuerungsgeräte, die nicht unter die Richtlinie 2002/95/EG fallen.

Declara que el producto siguiente:

Español

Designación: **Controlador de Potencia Power Series**
Números de Modelos: PC (1, 2, 3, 4, 8 o 9) (0 o 1) — (N20, N25, N30, F20, F25, F30 o F35) (A, B o C) — (0 o 1) (0 o 1) (00 o AA-ZZ)
Clasificación: Controlador de Potencia de Estado Sólido, Clase II, Grado Contaminado III
Tensión nominal: De 24 a 600 V
Frecuencia nominal: 50/60 Hz

Cumple con los requisitos esenciales de las siguientes Directivas de la Unión Europea, usando las secciones pertinentes de las reglas normalizadas y los documentos relacionados que se muestran:

2004/108/EC Directiva de Compatibilidad Electromagnética
EN 61326: 1997 Equipo eléctrico para medición control y uso en laboratorios - Requisitos de compatibilidad electromagnética (Grupo 1, Clase A)
EN 61000-4-2: 1995 Descarga electrostática
EN 61000-4-4: 1995 Perturbaciones transitorias eléctricas rápidas
EN 61000-4-8: 1993 Campos magnéticos
EN 61000-4-3: 1996 Inmunidad radiada
EN 61000-4-6: 1996 Inmunidad conducida
EN 61000-4-5: 1995 Sobretenión
EN 61000-4-11: 1994 Caídas de tensión, interrupciones breves y variaciones de tensión
ENV 50204: 1995 Teléfono portátil
Nota 1: Se requiere la utilización de un filtro externo para cumplir con la norma EN 61326 de límites de emisión conducidos. Léase la página 2 (reverso) para obtener más información e instrucciones.
Nota 2: En todas las pruebas de medición de emisiones se empleó una LISN (siglas en inglés de "red de estabilización de impedancia de línea") y no un estabilizador de línea.

2006/95/EC Directiva de baja tensión

EN 50178: Equipo electrónico para usar en instalaciones de generación de energía

Se excluye de esta declaración la opción de Modo de Control por Angulo de Fase del Controlador Power Series.

Reciclar correctamente  según la directiva W.E.E. 2002/95/EC.

Estos dispositivos tienen soldadura de plomo y no cumplen con la directiva RoHS. Son dispositivos de control y no están regidos por la directiva 2002/95/EC.

Raymond D. Feller III
Name of Authorized Representative

Winona, Minnesota, USA
Place of Issue

General Manager
Title of Authorized Representative

March 2002
Date of Issue



Signature of Authorized Representative

Figure 1- Tank Filter, 1Ø 230V~
Abbildung 3. Tankfilter 1Ø; 230 V~
Figure 1 - Filtre cylindrique, 1Ø 230V~
Figura 1 - Filtro de tipo tanque, 1Ø 230V~





Figure 2- Tank Filter, 3Ø 440V~
Abbildung 3. Tankfilter 3Ø; 440 V~
Figure 2 - Filtre cylindrique, 3Ø 440V~
Figura 2 - Filtro de tipo tanque, 3Ø 440V~



Note 1: Protective earth (PE) connection required to minimize EMI.
Hinweis 1: Schutzterdung (PE) erforderlich, um EMI auf ein Minimum zu halten.
Remarque 1 : connexion de terre protectrice (PE) requise pour minimiser l'interférence EMI.
Nota 1: Conexión a tierra de protección (PE) requerida para minimizar la interferencia electromagnética (EMI).

Required (EN61326) External EMI Filters for Power Series with $\geq 6A$ Loads

An external EMI filter must be used in conjunction with the Power Series.

Watlow has verified that one type of filter will suppress electromagnetic interference (EMI) created by the Power Series power controller to within the EN61326 requirements:

- 1) A tank filter supplied by Crydom, installed across the power lines, suppresses EMI on the power lines. See Figures 1 and 2.

Wiring illustrations for the filters appear on the right. See Table 1 for the correct filter:

Description	Filter #	Watlow #
	Crydom	
1Ø; 230V~	1F25	14-0019
3Ø; 440V~	3F20	14-0020

Table 1 - Power Series EMI Filters

WARNING:

The tank filter specified may suppress desirable communications carried on power lines in the 150 to 250 kHz region. The filter may suppress carrier current such as that used for infant monitors and medical alert systems. Verify that suppressed carrier current or other desirable communications on power lines creates no hazard to people or property. Failure to observe this warning could result in damage to property, and injury or death for personnel.

WARNING:

All filter installation and wiring must be performed by qualified personnel, and conform to local and national electrical codes. Failure to observe this warning could result in damage to property, and injury or death for personnel.

Filtres externes EMI (EN61326) requis pour les Power Series à des charges de $\geq 6A$

Un filtre externe EMI doit être utilisé conjointement avec le Power Series.

Watlow s'est assuré qu'un type de filtre supprimera l'interférence électromagnétique (EMI) créée par le bloc de puissance Power Series, afin de se conformer aux exigences de la norme EN61326 :

- 1) Un filtre cylindrique, fourni par Crydom, installé sur les lignes secteurs, supprime l'interférence EMI des lignes secteurs. Voir les figures 1 et 2.

Les illustrations de câblage des filtres figurent à droite. Voir le tableau 1 sur l'utilisation du filtre approprié :

Description	N° de Filtre	N° Watlow
	Crydom	
1Ø; 230V~	1F25	14-0019
3Ø; 440V~	3F20	14-0020

Tableau 1 : Filtres EMI Power Series

IMPORTANT :

Le filtre spécifié peut supprimer les communications désirables de lignes secteurs se situant entre 150 et 250 kHz. Le filtre peut supprimer le courant porteur, tel que celui utilisé sur les appareils de surveillance des nouveaux-nés et les systèmes d'alerte médicale. S'assurer que le courant porteur supprimé ou toute autre communication sur les lignes secteurs ne crée pas de danger pour les personnes ou les installations. La non-observation de cet avertissement peut entraîner des dommages matériels, des blessures ou même la mort.

IMPORTANT :

Toute l'installation et tout le câblage du filtre doivent être réalisés par un personnel qualifié et être en conformité avec les réglementations électriques locales et nationales. La non-observation de cet avertissement peut entraîner des dommages matériels, des blessures ou même la mort.

Erforderliche Entstörfilter gemäß EN 61326 für Power Series mit Laststrom $\geq 6A$.

Ein externer EMI-Filter sollte mit dem Power Series.

Watlow hat nachgewiesen, daß eine Filterart die elektro-magnetischen Störungen, die durch den Leistungssteller der Bauart Power Series hervorgerufen werden, der Norm EN61326 entsprechend unterdrückt.

- 1) Ein Tankfilter von Crydom, welcher über die Stromleitungen installiert wird, unterdrückt die elektro-magnetischen Störungen auf den Stromleitungen. Siehe Abbildungen 1 und 2.

Schaltenschemata für die Filter sind auf der rechten Seite zu sehen. Den richtige Filter finden Sie in Tabelle 1:

Beschreibung	Filter Nummer	Watlow Nummer
	Crydom	
1Ø; 230V~	1F25	14-0019
3Ø; 440V~	3F20	14-0020

Tabelle 1. Power Series EMI-Filter

WARNING:

Der angegebene Entstörfilter kann gewünschte Datenübertragungen im Bereich von 150 bis 250 kHz unterdrücken. Der Filter kann den Trägerstrom, der zum Beispiel bei Überwachungsgeräten für Kleinkinder oder medizinischen Warnsystemen verwendet wird, unterdrücken. Stellen Sie sicher, daß die Unterdrückung des Trägerstroms oder anderer gewünschter Datenübertragungen auf den Stromleitungen keine Gefahr für Personen oder Sachen darstellt. Eine Nichtbeachtung dieser Sicherheitsmaßnahme kann Sachschäden, Verletzungen oder den Tod zur Folge haben

WARNING:

Alle Filterinstallationen und Verdrahtungen müssen von qualifiziertem Personal durchgeführt werden und den bestehenden elektrischen Vorschriften entsprechen. Das Nichtbeachten dieser Warnung kann zu Sachschäden, Verletzungen oder zum Tod des Personals führen.

Filtros de interferencia electromagnética (EMI) externos (EN61326) requeridos para Power Series con cargas $\geq 6A$

Se debe usar un filtro de EMI externo junto con el Power Series.

La empresa Watlow ha verificado que hay un tipo de filtro que suprimen la interferencia electromagnética (EMI) creada por el controlador de potencia Power Series, y la mantiene dentro de los límites establecidos por los requerimientos de la EN61326:

- 1) Al instalarse un filtro de tipo tanque provisto por Crydom en paralelo con las líneas de alimentación eléctrica se suprime la interferencia electromagnética (EMI) en ellas. Véanse las Figuras 1 y 2.

Las ilustraciones de los cableados para los filtros aparecen en la derecha. Véase la Tabla 1 para seleccionar el filtro correcto:

Descripción	No. de filtro	No. Watlow
	Crydom	
1Ø; 230V~	1F25	14-0019
3Ø; 440V~	3F20	14-0020

Tabla 1 - Filtros de EMI de Power Series

¡Advertencia!

El filtro de tipo tanque especificado puede suprimir ciertas comunicaciones deseables que se envían por las líneas de alimentación eléctrica en frecuencias que van desde 150 a 250 kHz. El filtro puede suprimir corrientes portadoras, como las que se usan para monitores para bebés y sistemas de alarma médica. Verifique que la corriente portadora u otras comunicaciones deseadas suprimidas en las líneas de alimentación eléctrica no presenten peligros para las personas o la propiedad. El no observar esta advertencia puede causar daños a la propiedad, y lesiones o muerte del personal.

¡Advertencia!

Todas las instalaciones y conexiones de filtros deben ser realizadas por personal calificado y en conformidad con los códigos locales y nacionales. El no observar esta advertencia puede causar daños a la propiedad, y lesiones o muerte del personal.

Power Series Software Map

Display Loop

(See the Power Series User's Manual)

Setup Page

AL9a	Control Algorithm
AL9a	Power Control Algo Select
Ftb	Fixed Time Base
UC	Line Voltage Comp

Control Zone 1

In	Input Signal Method Select
dFLE	Default Numeric Input Sig
nnR	Set Analog Input Lo Cur
nnR	Set Analog Input Hi Cur
UoL	Set Analog Input Lo Volt
UoL	Set Analog Input Hi Volt
Lrn.R	Learn Input Learn Req
bL.U	Baseline Volt Read/Adj
Lrn.U	Baseline Volt Learn Req
TYPE	Load Type Select
rATE	Max Rate of Change
SoftE	Soft Start Time

Options Zone 1

Hbo	Heater Bakeout Select
P7.in	HBO Select Time
HbC	HBO Current Trip
CL	Cur Limit Select
CL.R	Cur Limit Set Point
LoL	Lo Tol Set Point
LoL	Hi Tol Set Point
IndF	Induct Load Factor Req
ICur	Inductive Current

Control Zone 2

In	Input Signal Method Select
dFLE	Default Numeric Input Sig
nnR	Set Analog Input Lo Cur
nnR	Set Analog Input Hi Cur
UoL	Set Analog Input Lo Volt
UoL	Set Analog Input Hi Volt
Lrn.R	Learn Input Learn Req
bL.U	Baseline Volt Read/Adj
Lrn.U	Baseline Volt Learn Req
rATE	Max Rate of Change
SoftE	Soft Start Time

Options Zone 2

Hbo	Heater Bakeout Select
P7.in	HBO Select Time
HbC	HBO Current Trip
CL	Cur Limit Select
CL.R	Cur Limit Set Point
LoL	Lo Tol Set Point
LoL	Hi Tol Set Point
IndF	Induct Load Factor Req
ICur	Inductive Current

Control Zone 3

In	Input Signal Method Select
dFLE	Default Numeric Input Sig
nnR	Set Analog Input Lo Cur
nnR	Set Analog Input Hi Cur
UoL	Set Analog Input Lo Volt
UoL	Set Analog Input Hi Volt
Lrn.R	Learn Input Learn Req
bL.U	Baseline Volt Read/Adj
Lrn.U	Baseline Volt Learn Req
rATE	Max Rate of Change
SoftE	Soft Start Time

Options Zone 3

Hbo	Heater Bakeout Select
P7.in	HBO Select Time
HbC	HBO Current Trip
CL	Cur Limit Select
CL.R	Cur Limit Set Point
LoL	Lo Tol Set Point
LoL	Hi Tol Set Point
IndF	Induct Load Factor Req
ICur	Inductive Current

Alarms Configuration

AL9a	Active Relay State
GLbL	Global Alarm
OPEn	Heater Open Alarm
LoL	Heater To Alarm
DE	Heat Sink Over Temp Alarm
ALC	Heat Sink Over Temp Alarm Temp
LineE	Line Loss Alarm
P.bAL	Phase Bal Alarm
LbAL	Load Bal Alarm
Ld.F	Load Bal Percent
FrE9	Freq Out of Tol Alarm
UC	Volt Comp Alarm
OU	Over Volt Alarm
C.Wd	Comms Watchdog Alarm

Comms Configurations

Addr	Unit Address Select
bAud	Unit Baud Rate Select
Wd	Watchdog Select
SEC	Watchdog Timeout
P.Wr	Watchdog Fail Output Pwr Sel

Retransmit Configuration

CF9	Retrans Select
TYPE	Retrans Type Select
PhAS	Retrans Phase Select
Zone	Retrans Zone Select
Cur	Min Amps Retrans
Cur	Max Amps Retrans
HUR	Min kVA Retrans
HUR	Max kVA Retrans
re.C	Set Retrans Output Lo Cur
re.C	Set Retrans Output Hi Cur
re.U	Set Retrans Output Lo Volt
re.U	Set Retrans Output Hi Volt

Factory Page

System Data Manipulation

bAuP	Backup Data Set
dFLE	Default Data Set
rESE	Restore Data Set
nUOL	Enable NVOL Storage

Global/Menu Lockouts

Loc	Global Lockout
9LOC	Control Setup Menus Lock
CEr	Options Setup Menus Lock
OPt	Alrms Setup Menu Lock
ALr	Comms Setup Menu Lock
COP7	Retrans Setup Menu Lock
reEr	Analog Input Menu Lock
CLn	Retrans Menu Lock
C.rtr	Sys Data Menu Lock
dAER	Diag Menu Lock

Unit Information

Sn	Unit Serial # Hi Digits
Sn	Unit Serial # Lo Digits
dAEE	Mfg Date
HUEr	Hardware Version
SUEr	Software Version
SbLd	Software Build #
rAeU	Unit Volt Rating
rAER	Unit Curt Rating
ZoneC	# Zones
OPE	Installed Options
C	Heat Sink Temp
ALC	Heat Sink Alarm Temp
SdC	Safety Shutdown Temp
HiC	Hi Heat Sink Temp
hrs	Accum Hours
hrs	Accum Hours

Diagnostics

Ad	Select A/D Channel
CnES	Read Selected A/D Counts

Line Loss Alarms:

L1A1	Most Recent
L2A1	Line Loss
L3A1	Alarm Type
L1A2	Previous
L2A2	Line Loss
L3A2	Alarm Type
L1A3	Least Recent
L2A3	Line Loss
L3A3	Alarm Type

dISP	Display Test
In	Select Discrete Input
URL	Read Selected Input Value
reEr	Retrans Set Test Word

The Factory Page also includes calibration parameters that are not necessary for everyday use of the controller. Calibration parameters and procedures are explained in the Power Series User's manual.

Enter your settings on a photocopy of this page.

How to Reach Us



Quality and Mission Statement:

Watlow Winona will be the world's best supplier of industrial temperature control products, services, and systems by exceeding our customers', employees', and shareholders' expectations.

Contact

Your Authorized Watlow Distributor is:

- Phone: +1 (507) 454-5300.
- Fax: +1 (507) 452-4507.
- For technical support, ask for an Applications Engineer.
- To place an order, ask for Customer Service.
- To discuss a custom option, ask for the Power Series Product Manager.

Warranty

The Watlow Power Series is warranted to be free of defects in material and workmanship for 36 months after delivery to the first purchaser for use, providing that the units have not been misapplied. Since Watlow has no control over their use, and sometimes misuse, we cannot guarantee against failure. Watlow's obligations hereunder, at Watlow's option, are limited to replacement, repair or refund of purchase price, and parts which upon examination prove to be defective within the warranty period specified. This warranty does not apply to damage resulting from transportation, alteration, misuse, or abuse.

Returns

- Call or fax Customer Service for a Return Material Authorization (RMA) number before returning a controller.
- Put the RMA number on the shipping label, along with a written description of the problem.
- A restocking charge of 20% of the net price is charged for all standard units returned to stock.

Watlow Power Series User's Manual

Watlow Winona, 1241 Bundy Boulevard, P.O. Box 5580, Winona, Minnesota USA 55987-5580,
Phone: +1 (507) 454-5300, Fax: +1 (507) 452-4507