

BENCH OVEN STAND **ASSEMBLY INSTRUCTIONS** **MODELS NB, NBS, DR, NT, NTR, AND 300 SERIES**

1. Bolt oven support angles to oven stand legs with hardware provided. Position angles of the same length across from each other. The support angles will not touch in the corners of the legs. The support angles should be installed with slotted leg pointing downward.
2. On all Models, the legs extend above the oven support surface (See illustration). The four (4) support angles have slots for adjustment. Assemble the stand fully extended and leave the hardware slightly loose. After the oven is placed on the stand, squeeze the tops of the stand legs close to the oven and fully tighten the hardware.
3. All oven stands have bolt down provisions inside the leg bottoms. After the oven and stand are in place, you must bolt the stand securely to the factory floor.

