

HOW TO SET LE7M 7-DAY TIMER

A. <u>SETTING CURRENT DATE AND TIME:</u>

- 1. Press and hold MODE and SET keys for 3 seconds until "t.AJ" is displayed on screen.
- 2. Press **SET**.
- Press
 or
 to adjust year and advance to month by pressing
 ...
- 4. Press

 or

 to adjust month and press

 SET.
- Press or to AM or PM and advance to hour by pressing .
- Press ▲ or ▼ to select minute and press SET.
- 8. Press and hold **MODE** for 3 seconds to return to RUN mode.

B. <u>SETTING WEEKLY ON/OFF PROGRAM FOR OUTPUT 1:</u>

- 1. Each output can be programmed up to 24 times.
- 2. Verify Output 1 switch is in "AUTO" position
- 3. Press and hold MODE for 3 seconds until "PROG P1" is displayed.
- Press SET.
- 5. Press **SET** for "**ON/OFF**" control.
- 6. Use the arrow keys to select which days you want Output 1 ON.
 - a. Press **b** to advance days.
 - b. Press ▲ or ▼ to select days.
- 7. Press **SET**.
- 8. Use the arrow keys to adjust ON time.
 - a. Press to advance between hours and minutes.
 - b. Press **▲** or **▼** to change time.
- 9. Press SET.
- 10. Press **SET** to verify days you want to turn Output 1 OFF.
- 11. Use the arrow keys to adjust OFF time.
 - a. Press to advance between hours and minutes.
 - b. <u>Press ▲ or ▼ to change time.</u>
- 12. Press **SET** to complete programming.
- 13. Press and hold **MODE** for 3 seconds to return to RUN mode.

C. WEEKLY ON/OFF PROGRAM MODIFY FOR OUTPUT 1:

- 1. Press CHECK for 1 second to enter CHECK mode.
- 2. Press **SET** for 3 seconds until "**Edt**" is shown on lower display.
- 3. Press **SET** to modify program.



HOW TO SET LE7M 7-DAY TIMER (CONT.)

D. WEEKLY ON/OFF PROGRAM DELETE FOR OUTPUT 1:

- 1. Press CHECK for 1 second to enter CHECK mode.
- 2. Press **SET** for 3 seconds until "**Edt**" is shown on lower display.
- 3. Press ▲ or▼ until "Clr" is shown on lower display.
- 4. Press **SET**.
- 5. Press and hold **SET** tom return to CHECK mode.