

-SPECIAL CABINET OVEN, Serial No. 411457
for rotating baskets of aluminum and stainless steel parts while drying

- maximum operating temperature: 500°F
- workspace dimensions: 48" wide x 48" deep x 48" high
- 40 KW installed in Incoloy sheathed tubular heating elements
- 3300 CFM, 2 HP recirculating blower providing combination airflow
- 4" insulated walls
- Type 304, 2B finish stainless steel interior
- internal rotating framework with two (2) stainless steel roller assemblies each with clamp to hold basket in place
- variable speed 2 HP drive (0-5 RPM) with brake motor and limit switch to stop baskets in upright position



THE GRIEVE CORPORATION

500 Hart Road, Round Lake, Illinois 60073-2898 USA
(847) 546-8225 Fax: (847) 546-9210

No. 801