

BELT CONVEYOR OVEN, Serial No. 650143  
for curing coatings and heat shrinking plastic

- maximum operating temperature: 500°F
- workspace dimensions: 30" wide x 96" deep x 24" high
- 2' long open belt loading zone
- 8' long insulated heat zone with recirculated airflow
- 2½' long open unloading zone
- 48 KW installed in Nichrome wire heating elements
- 24" wide, 1" x 1" 304 stainless steel flat wire conveyor belt with ¼ HP motor drive, variable from 0.9 to 17.6 inches per minute

- 4200 CFM, 3 HP recirculating blower providing vertical downward airflow
- 4" insulated walls
- Type 304, 2B finish stainless steel interior
- stainless steel exterior with #4 brush finish
- PVC electrical conduit
- remote control panel
- 325 CFM stainless steel powered forced exhauster
- six (6) point thermocouple jack panel through oven wall



**THE GRIEVE CORPORATION**

500 Hart Road, Round Lake, Illinois 60073-2898 USA  
(847) 546-8225 Fax: (847) 546-9210

**No.853**