

**GAS-HEATED TUNNEL OVEN,**  
Serial No. 660436  
for drying water from aluminum parts  
hanging from monorail conveyor

- maximum operating temperature: 350°F
- workspace dimensions: 30" wide x 192" deep x 66" high
- 24" long insulated, unheated entrance vestibule
- 144" long insulated heat zone with recirculated airflow
- 24" long insulated, unheated exit vestibule
- oven hung from ceiling; remote control panel
- 500,000 BTU/HR installed in a modulating natural gas burner
- 6000 CFM, 5-HP recirculating blower providing vertical downward airflow
- 4" thick insulated walls
- bottom mounted heat chamber
- aluminized steel interior and exterior
- interior supports for customer's monorail
- 24" wide x 72" high access door for heat chamber and work space
- safety equipment required by IRI, FM and National Fire Protection Association Standard 86 for gas-heated equipment including 650 CFM 1/2-HP powered forced exhauster



**THE GRIEVE CORPORATION**

500 Hart Road, Round Lake, Illinois 60073-2898 USA  
(847) 546-8225 Fax: (847) 546-9210

**No. 878**