

MODIFIED MODEL B3-850 HIGH TEMPERATURE WALK-IN OVEN, Serial No. 420077
for heat treating parts on rollout shelves

- maximum operating temperature: 850°F
- workspace dimensions: 72" wide x 78" deep x 78" high
- 100 KW installed in Incoloy sheathed tubular heating elements
- 10,000 CFM, 7½-HP recirculating blower providing combination airflow
- 8" thick insulated walls comprised of 2" of 1900°F block and 6" of 10 lb/cf density rockwool
- top mounted heat chamber
- inner and outer door gaskets; inner gasket seals directly against door plug; outer gasket seals against front face of oven
- doors equipped with expansion joints on inner face to guarantee uniform sealing at all temperatures
- aluminized steel interior and exterior
- three (3) rollout shelves, 60" wide x 72" long rated 400 lbs. loading each
- digital programming and recording temperature controller
- manual reset excess temperature controller with separate contactors
- recirculating blower air flow safety switch
- SCR power controller



THE GRIEVE CORPORATION

500 Hart Road, Round Lake, Illinois 60073-2898 USA
(847) 546-8225 Fax: (847) 546-9210

No.902