

SPECIAL WALK-IN OVEN, Serial No. 660458

For use in curing rubber parts

- maximum operating temperature: 500°F
- work space dimensions: 52" wide x 48" deep x 48" high
- 350,000 BTU/HR installed in a modulating natural gas burner
- 4200 CFM, 3-HP recirculating blower providing horizontal airflow
- 4" insulated walls
- top mounted heat chamber
- type 304 stainless steel interior with continuously backwelded seams
- stainless steel exterior with #4 brushed finish
- safety equipment required by IRI, FM and National Fire Protection Association Standard 86 for gas-heated equipment including 650 CFM, 1/2-HP powered forced exhauster
- motorized damper on exhaust for accelerated cooling
- digital programming temperature controller
- 10" diameter circular chart recorder
- 4" insulated floor with two (2) pair truck wheel guide tracks on top of floor
- shelf trucks with supports on 3-1/2" centers - two (2) per batch
- transfer dolly to carry two (2) trucks including oven-to-dolly latch and dolly-to-truck latch
- fused disconnect switch
- oven exhaust discharges into scrubber unit using recirculated water (1-1/2-HP pump) sprayed into exhaust to remove particulates
- 304 stainless steel scrubber construction with brass piping



THE GRIEVE CORPORATION

500 Hart Road, Round Lake, Illinois 60073-2898 USA
(847) 546-8225 Fax: (847) 546-9210

No. 920