

WALK-IN OVEN Serial No. 83332A0405

for curing large composite parts

- maximum operating temperature: 350° F
- workspace dimensions: 10' wide x 32' deep x 8' high
- 1,200,000 BTU/HR installed in a modulating natural gas burner
- 49,000 CFM total from two (2) 20-HP recirculating blowers providing combination airflow
- 4" insulated walls
- removable top mounted heat chamber

- oven body split into four (4) sections for shipment with mating angle iron frames for easy reassembly in the field
- aluminized steel interior and exterior
- safety equipment required by IRA, FM and National Fire Protection Association Standard 86 for gas-heated equipment
- 8000 CFM powered forced exhauster for quick purge and cool down
- motorized dampers on intake and exhaust for accelerated cooling
- 10" diameter circular chart recording and programming temperature controller



THE GRIEVE CORPORATION

500 Hart Road, Round Lake, Illinois 60073-2898 USA
(847) 546-8225 Fax: (847) 546-9210

No.996