



**THREE LEVEL ROTARY HEARTH OVEN,
Serial No. 10220A1210**

for curing sealant on molded plastic parts

- maximum operating temperature: 500 F
- work space dimensions: 36" wide x 32" deep x 30" high
- 24 KW installed in Incoloy sheathed tubular heating elements
- 30" diameter three level hearth constructed from perforated steel sheet
- hearth driven by 1/4-HP motor through gear reducer with torque limiting device
- 1000 CFM, 1-HP recirculating blower providing horizontal airflow, front to rear
- 6" insulated walls
- Type 304, 2B finish stainless steel interior
- 8" wide x 23" high front access opening
- digital indicating temperature controller
- manual reset excess temperature controller with separate contactors
- recirculating blower air flow safety switch
- integral leg stand
- disconnect switch
- proximity switch and twelve tooth sprocket to index hearth 1/12 rotation each index



THE GRIEVE CORPORATION

500 Hart Road, Round Lake, Illinois 60073-2898 USA
(847) 546-8225 Fax: (847) 546-9210

No.1029