

**MODEL HC-1250 HIGH TEMPERATURE CABINET
OVEN, Serial No. 540027**

for heating metal parts to remove deposits

- maximum operating temperature: 1250F
- work space dimensions: 50" wide x 50" deep x 50" high
- 160 KW installed in Incoloy sheathed tubular heating elements
- 6000 CFM, 5-HP recirculating blower providing horizontal airflow
- 10" thick insulated walls comprised of 2" of 1900F block and 8" of 10 lb/cf density rockwool
- top mounted heat chamber
- aluminized steel exterior
- type 304, 2B finish stainless steel interior
- safety equipment for handling flammable solvents including explosion venting door hardware
- digital indicating temperature controller
- manual reset excess temperature controller with separate contactors
- insulated floor reinforced for 1000 lb. loading at 1/4" 304 stainless steel plate



THE GRIEVE CORPORATION

500 Hart Road, Round Lake, Illinois 60073-2898 USA
(847) 546-8225 Fax: (847) 546-9210

No.975