

## MODIFIED MODEL AB-850 2-COMPARTMENT

**UNIVERSAL OVEN, Serial No. 350723** for machine shop

- maximum operating temperature: 850F
- work space dimensions: 36" wide x 36" deep x 36" high each zone
- 24 KW (12 KW per zone) installed in Incoloy sheathed tubular heating elements
- 600 CFM, 1/2-HP recirculating blowers providing front to rear universal airflow in each compartment
- 6" insulated walls
- aluminized steel interior and exterior

- type 304, 2B finish stainless steel interior
- double doors
- digital indicating temperature controller, one for each compartment
- manual reset excess temperature controllers with separate contactors
- recirculating blower air flow safety switches
- 10" diameter circular chart recorder, one for each compartment, to record part temperature
- three (3) roller shelves rated 200 lbs. loading
- integral leg stand



**THE GRIEVE CORPORATION**

500 Hart Road, Round Lake, Illinois 60073-2898 USA  
(847) 546-8225 Fax: (847) 546-9210

**No.979**