MODEL WRH6106-500 HORIZONTAL AIRFLOW WALK-IN OVEN, Serial No. 93100A0108

for composite curing

- -maximum operating temperature: 500° F
- -work space dimensions: 6' wide x 10' deep x 6-1/2' high
- -100 KW installed in Incoloy sheated tubular heating elements
- -10,000 CFM, 10-HP recirculating blower providing horizontal airflow

- -four port vacuum manifold with pressure gauge and hand valve at each port
- -resin trap leading to vacuum pump
- -solenoid valve to bleed air into manifold
- -two (2) stage rotary vane vacuum pump rated 10 CFM
- -digital programming temperature controller
- -SCR power controller

