

HIGH TEMPERATURE WALK IN OVEN, Serial No. 113176A1014
for holding weldments at temperature before welding

- maximum operating temperature: 900°F
- workspace dimensions: 108" wide x 120" long x 115" high
- 300 KW installed in Incoloy sheathed tubular heating elements
- 30,000 CFM, 30 HP recirculating blower providing front to rear airflow



- 9" insulated walls consisting of isolated inner oven completely surrounded by insulation to eliminate heat transfer
- aluminized steel interior and exterior
- inner and outer door gaskets; inner gasket seals directly against door plug; outer gasket seals directly against 3/8" steel plate oven front
- digital programming temperature controller
- manual reset excess temperature controller with separate contactors
- recirculating blower air flow safety switch
- 10" diameter circular chart recorder
- 4" insulated floor with hard points to support load



THE GRIEVE CORPORATION

500 Hart Road, Round Lake, Illinois 60073-2898 USA
(847) 546-8225 Fax: (847) 546-9210

No.1037