MODEL HD-306030-GF-RR GAS FIRED HEAVY DUTY FURNACE, Serial No. 114731A0415 for heat treating

-maximum operating temperature: 2000°F -workspace dimensions : 30" wide x 60" deep x 30" high -750,000 BTU/HR installed in four (4) modulating natural gas burners with floor mounted combustion air blower -burners fire below hearth

-9" thick insulated walls comprised of 5" thick 2300°F ceramic fiber and 4" 1900°F block insulation; 8 1/2" floor insulation comprised of 4 1/2" of 2300°F firebrick and 4" of 1900°F block insulation

-two lanes of roller rails supported by firebrick piers

-air operated platform with roller rails to bridge from loading table to work space

-1/4" plate steel exterior reinforced with structural steel

-1/2" steel face plate at doorway

-air operated vertical lift door

-safety equipment required by IRI, FM and National Fire Protection Association Standard 86 for gas-heated equipment -free standing 390 CFM high pressure combustion blower

-digital indicating temperature controller

-manual reset excess temperature controller with seperate contactors



