

ROTARY HEARTH OVEN, Serial No. 660374

for preheating and curing powder coating on electric motor parts

- maximum operating temperature: 500°F
- workspace dimensions: 54" wide x 54" deep x 72" high
- 350,000 BTU/HR installed in a modulating natural gas burner
- Two (2) 48" diameter hearths constructed from rolled angles and covered with perforated metal
- hearth driven by 1/8 HP motor through gear reducer with torque limiting device
- hearth to rotate for 15 seconds every time motor operated
- vertical lift loading door is opened and closed
- 4200 CFM, 3 HP recirculating blower providing horizontal airflow
- 4" insulated walls
- aluminized steel interior and exterior
- safety equipment required by IRI, FM and National Fire Protection Association Standard 86 for gas-fired equipment including 325 CFM 1/8 HP powered forced exhauster



THE GRIEVE CORPORATION

500 Hart Road, Round Lake, Illinois 60073-2898 USA
(847) 546-8225 Fax: (847) 546-9210

No.816