

**MODEL AF-1000 HIGH TEMPERATURE UNIVERSAL OVEN,
Serial No. 380040**

for cleaning and heat treating fuel nozzles

- maximum operating temperature: 1000°F
- workspace dimensions: 24" wide x 36" deep x 24" high
- 24 KW installed in Incoloy sheathed tubular heating elements
- 1000 CFM, ¾ HP recirculating blower providing universal airflow
- 8" insulated walls
- aluminized steel interior and exterior
- inner and outer door gaskets; inner gasket seals directly against door plug; outer gasket seals directly against front face of oven
- digital indicating temperature controller
- manual reset excess temperature controller with separate contactors
- recirculating blower air flow safety switch
- integral leg stand



THE GRIEVE CORPORATION

500 Hart Road, Round Lake, Illinois 60073-2898 USA
(847) 546-8225 Fax: (847) 546-9210

No. 818