

**VERTICAL AIRFLOW WALK-IN OVEN, Serial No. 660505**

for curing coatings on Titanium screens

- maximum operating temperature: 1000F
- work space dimensions: 72" wide x 156" deep x 96" high
- 360 KW installed in Incoloy sheathed tubular heating elements
- 24,500 CFM, 20-HP recirculating blower providing vertical downward airflow
- 8" insulated walls
- removable top mounted heat chamber
- type 304L, 2B finish stainless steel interior
- stainless steel exterior with #4 brushed finish

- double doors front and rear
- inner and outer door gaskets; inner gasket seals directly against door plug; outer gasket seals directly against front face of oven
- safety equipment for handling flammable solvents including explosion venting door hardware
- digital programming temperature controller
- manual reset excess temperature controller with separate contactors
- recirculating blower air flow safety switch
- SCR power controller
- 6" insulated floor with truck wheel guide tracks



**THE GRIEVE CORPORATION**

500 Hart Road, Round Lake, Illinois 60073-2898 USA  
(847) 546-8225 Fax: (847) 546-9210

**No.946**