

**MODIFIED MODEL AB-500 2-COMPARTMENT
UNIVERSAL OVEN, Serial No. 350722**

for machine shop

- maximum operating temperature: 500F
- work space dimensions: 30" wide x 36" deep x 36" high each zone
- 13.2 KW (6.6 KW per zone) installed in Nichrome wire heating elements
- 600 CFM, 1/2-HP recirculating blowers providing front to rear universal airflow in each compartment
- 4" insulated walls

- aluminized steel exterior
- type 304, 2B finish stainless steel interior
- double doors
- digital indicating temperature controller, one for each compartment
- manual reset excess temperature controllers with separate contactors
- recirculating blower air flow safety switches
- 10" diameter circular chart recorder, one for each compartment, to record part temperature
- integral leg stand



THE GRIEVE CORPORATION

500 Hart Road, Round Lake, Illinois 60073-2898 USA
(847) 546-8225 Fax: (847) 546-9210

No.978