

MODIFIED MODEL CBH-350 FLOOR LEVEL CABINET OVEN, Serial No. 430253

for curing flat urethane sheets

- maximum operating temperature: 350F
- work space dimensions: 48" wide x 48" deep x 60" high
- 18 KW installed in Nichrome wire heating elements
- 2000 CFM, 2-HP recirculating blowers providing horizontal air flow
- 4" insulated walls
- top mounted heat chamber
- type 304, 2B finish stainless steel interior
- stainless steel exterior with #4 brushed finish
- double doors front and rear
- sealing flange to allow oven to seal in wall between clean room and fabrication area
- digital indicating temperature controller
- manual reset excess temperature controller with separate contactors
- recirculating blower air flow safety switch
- 30 hour shut down timer
- 2" insulated floor



THE GRIEVE CORPORATION

500 Hart Road, Round Lake, Illinois 60073-2898-USA
(847) 546-8225 Fax: (847) 546-9210

No.981