

**GAS-FIRED VERTICAL AIR FLOW WALK-IN OVEN,
Serial No. 87801A0706 for drying molded fiber parts**

- maximum operating temperature: 500 F
- work space dimensions: 48" wide x 48" deep x 72" high
- 800,000 BTU/HR installed in a modulating natural gas burner
- 4200 CFM, 3-HP recirculating blower providing vertical upward air flow from duct beneath loading truck
- 4" insulated walls
- aluminized steel exterior
- type 304, 2B finish stainless steel interior with continuously welded seams
- safety equipment required by IRI, FM and National Fire Protection Association Standard 86 for gas-heated equipment including 975 CFM, powered forced exhauster
- digital programming temperature controller
- digital shut down timer with audible alarm
- insulated floor with truck wheel guide tracks
- fused disconnect switch
- 8 point internal thermocouple jack panel wired to jack panel on face of control panel



THE GRIEVE CORPORATION
500 Hart Road, Round Lake, Illinois 60073-2898 USA
(847) 546-8225 Fax: (847) 546-9210

No.1003