

FOUR DOOR CABINET OVEN, Serial No. 89840A0207

for stress relieving stainless steel parts

- maximum operating temperature: 500 F
- work space dimensions: four (4) compartments 20" wide x 28" deep x 36" high
- 30 KW installed in Incoloy sheathed tubular heating elements
- 6000 CFM, 5-HP recirculating blower providing independent horizontal airflow in each compartment
- 4" insulated walls
- aluminized steel exterior
- type 304, 2B finish stainless steel interior

- digital indicating temperature controller
- manual reset excess temperature controller with separate contactors
- recirculating blower air flow safety switch
- shelf truck with supports on 4" centers
- transfer dolly including oven-to-dolly latch to hold trays for loading onto supports in oven
- stainless steel loading trays with holes to hold customer's parts



THE GRIEVE CORPORATION

500 Hart Road, Round Lake, Illinois 60073-2898 USA
(847) 546-8225 Fax: (847) 546-9210

No.1011