

**SPECIAL CABINET OVEN,  
with two (2) tiers of four (4) doors,  
Serial No. 92308A1007**  
for curing rubber parts

- maximum operating temperature: 350 F
- eight (8) work space openings:  
36" wide x 6-1/4" high x 24" deep each  
with roller supported shelf
- 45 KW installed in Incoloy sheathed  
tubular heating elements
- 7800 CFM, 5-HP recirculating blower  
providing horizontal airflow to common  
central duct
- 4" insulated walls
- top mounted heat chamber with access  
doors
- aluminized steel interior and exterior
- 200 lb. capacity shelves extend 24" in  
front of oven for loading
- safety equipment for handling flammable  
solvents (including explosion venting door  
hardware)

- digital indicating temperature controller
- manual reset excess temperature controller with separate contactors
- recirculating blower air flow safety switch
- programmable timer interlocked to each door via proximity switch
- green lights for each door to indicate time complete



**THE GRIEVE CORPORATION**

500 Hart Road, Round Lake, Illinois 60073-2898 USA  
(847) 546-8225 Fax: (847) 546-9210

**No.1013**