

ELECTRICALLY-HEATED WALK-IN OVEN, S/N 93057A1207
for curing coatings on large discs

- maximum operating temperature: 500 F
- work space dimensions: 20' wide x 20' deep x 112" high
- oven body sectioned in four pieces for shipping
- 260 KW installed in Incoloy sheathed tubular heating elements

- 66,000 CFM total from two (2) 30-HP recirculating blowers providing combination airflow
- 6" insulated walls
- aluminized steel interior and exterior
- safety equipment for handling flammable solvents (including explosion venting door hardware)
- motorized dampers on intake and exhaust for accelerated cooling
- SCR power controller
- 2" insulated floor with truck wheel guide tracks



THE GRIEVE CORPORATION

500 Hart Road, Round Lake, Illinois 60073-2898 USA
(847) 546-8225 Fax: (847) 546-9210

No.1019