



**CLASS 100 CLEAN ROOM CABINET OVEN, Serial No. 98128A0909**

for curing small rubber pieces in rotating drums

- maximum operating temperature: 550 F
- work space dimensions: 26" wide x 26" deep x 60" high
- two (2) motorized stainless steel shafts cantilevered through rear wall with drum coupling device
- four (4) 18" diameter x 18" deep perforated stainless steel drums with internal stirring paddles and access door on one end
- 36 KW installed in Incoloy sheathed tubular heating elements
- 2000 CFM, 2-HP recirculating blower providing horizontal airflow
- 6" insulated walls
- top mounted heat chamber
- type 304, 2B finish stainless steel interior with 1/2" inside radius corners, seams welded, ground and polished
- automatic door switch to shut off heaters and drum drive when door is opened
- safety equipment for handling flammable solvents
- 24" x 24" x 6" thick HEPA fresh air filter with 2" prefilters
- two (2) 24" x 24" x 12" thick stainless steel high temperature HEPA recirculating filter
- minihelic pressure gauge and validation port across each set of filters
- solid state heater control relays
- circuit breaker disconnect switch



**THE GRIEVE CORPORATION**

500 Hart Road, Round Lake, Illinois 60073-2898 USA  
(847) 546-8225 Fax: (847) 546-9210

**No.1023**