

MODIFIED UNIVERSAL OVEN, Serial No. 101892A1210

for preheating acrylic and polycarbonate plastic sheets
prior to forming

- maximum operating temperature: 550 F
- work space dimensions: 34" wide x 120" deep x 48" high
- 60 KW installed in Incoloy sheathed tubular heating elements
- 4200 CFM, 3-HP recirculating blower providing horizontal, front to rear, airflow
- 6" insulated walls
- aluminized steel exterior
- Type 304, 2B finish stainless steel interior
- four (4) front access doors with automatic door switches to shut off heat and blower when door is opened
- four (4) structural steel slide beds to support plastic sheets
- digital indicating temperature controller
- manual reset excess temperature controller with separate contactors
- recirculating blower air flow safety switch
- SCR power controller
- eight (8) auxiliary thermocouples connected to selector switch and temperature indicator



THE GRIEVE CORPORATION

500 Hart Road, Round Lake, Illinois 60073-2898 USA
(847) 546-8225 Fax: (847) 546-9210

No.1026