

MODIFIED MODEL WTC566-500 WALK-IN OVEN, Serial No. 106923A0812

for curing large parts in molds

- maximum operating temperature: 500 F
- work space dimensions: 62" wide x 79" deep x 45" high
- two (2) lane roller conveyor inside oven and outside oven for loading
- 60 KW heat input installed in Incoloy sheathed tubular heating elements
- 6000 CFM, 5-HP recirculating blower providing combination airflow
- 6" insulated walls
- top mounted heat chamber
- aluminized steel interior and exterior
- electrically operated vertical lift door on rear
- 62" wide x 45" high front access doors
- digital indicating temperature controller
- manual reset excess temperature controller with separate contactors
- recirculating blower air flow safety switch
- SCR power controller
- insulated floor
- integral stand
- disconnect switch



THE GRIEVE CORPORATION

500 Hart Road, Round Lake, Illinois 60073-2898 USA
(847) 546-8225 Fax: (847) 546-9210

No.1032