

INERT ATMOSPHERE WALK IN OVEN, Serial No. 112395A0714
for annealing polyurethane tubing

- maximum operating temperature: 500 F
- work space dimensions: 60" wide x 72" deep x 84" high
- 40 KW installed in Incoloy sheathed tubular heating elements
- 4200 CFM, 3-HP recirculating blowers providing vertical downward airflow
- 6" insulated walls

- aluminized steel exterior with white epoxy paint
- Type 304, 2b finish stainless steel interior with continuously backwelded seams
- inert atmosphere construction including pressure regulator, flow meter, pressure gauge, inner oven walls sealing directly against 1/2" thick silicone rubber door seal, blower shaft seal, positive latching door hardware, adjustable offset door hinges, outlet with pressure relief, interior seams welded gas-tight, all wall penetrations fitted with compression fittings
- digital programming temperature controller
- Honeywell eZtrend paperless recorder
- 4" insulated floor with truck wheel guide tracks on top of floor



THE GRIEVE CORPORATION

500 Hart Road, Round Lake, Illinois 60073-2898 USA
(847) 546-8225 Fax: (847) 546-9210

No.1038