

**MODEL B1-1200 HIGH TEMPERATURE WALK-IN OVEN, Serial No.420066**

for heat treating steel parts

- maximum operating temperature: 1200°F
- workspace dimensions: 48" wide x 72" deep x 72" high
- 120 KW installed in Incoloy sheathed tubular heating elements
- 10,000 CFM, 7-1/2 HP recirculating blower providing combination airflow
- 10" thick insulated walls comprised of 2" of 1900°F block and 8" of 10 lb. density rockwool
- aluminized steel exterior
- 16 ga. stainless steel interior
- 325 CFM powered forced exhauster
- digital indicating temperature controller
- manual reset excess temperature controller with separate contactors
- recirculating blower air flow safety switch
- Partlow Versa, 4 pen, circular chart recorder
- 7" insulated floor with truck wheel guide tracks



**THE GRIEVE CORPORATION**

500 Hart Road, Round Lake, Illinois 60073-2898 USA  
(847) 546-8225 Fax: (847) 546-9210

**No.835**