

SPECIAL ELECTRICALLY HEATED OVEN, Serial No. 660420

for drying small parts in tray

- maximum operating temperature: 250°F
- holds one (1) stainless steel tray 6" wide x 18" long x 6" deep with perforated bottom
- tray sets on drip trap/air diffuser which is removable for cleaning
- 3 KW installed in Incoloy sheathed tubular heating elements
- 300 CFM, 1/3-HP recirculating blower providing vertical airflow upward through tray
- 2" insulated walls
- Type 304, 2B finish stainless steel interior
- digital indicating temperature controller
- manual reset excess temperature controller with separate contactors
- recirculating blower air flow safety switch



THE GRIEVE CORPORATION

500 Hart Road, Round Lake, Illinois 60073-2898 USA
(847) 546-8225 Fax: (847) 546-9210

No.861