

**MODIFIED MODEL B3-1000 HIGH TEMPERATURE WALK-IN,  
Serial No. 420079** for heat cleaning of large valve bodies

- maximum operating temperature: 1000°F
- work space dimensions: 60" wide x 120" deep x 78" high
- 880,000 BTU/HR installed in a modulating natural gas burner
- 12,500 CFM, 10-HP recirculating blower providing combination airflow
- 8" thick insulated walls comprised of 2" of 1900°F block and 6" of 10 lb/cf density rockwool
- top mounted heat chamber

- 16 ga aluminized steel interior; 16 ga stainless steel heat chamber interior; 16 ga aluminized steel exterior
- inner and outer door gaskets; inner gasket seals directly against door plug; outer gasket seals directly against front face of oven
- safety equipment required by IRI, FM and National Fire Protection Association Standard 86 for gas-heated equipment including 1500 CFM 2-HP powered forced exhauster
- digital programming temperature controller
- 6" insulated floor with truck wheel guide tracks
- flatbed loading truck, 8000 lb capacity



**THE GRIEVE CORPORATION**

500 Hart Road, Round Lake, Illinois 60073-2898 USA  
(847) 546-8225 Fax: (847) 546-9210

**No.910**