

MODIFIED MODEL WTH566-650 INDIRECT GAS-FIRED WALK-IN OVEN, Serial No. 411893
for evaporating water from plastic

- maximum operating temperature: 650F
- workspace dimensions: 60" wide x 72" deep x 72" high
- 500,000 BTU/HR installed in a modulating natural gas burner firing into an alloy radiant tube
- 6000 CFM, 5-HP recirculating blower providing horizontal airflow
- 5" insulated walls
- top mounted heat chamber
- aluminized steel exterior
- type 304, 2B finish stainless steel interior
- safety equipment required by IRI, FM and National Fire Protection Association Standard 86 for gas-heated equipment
- 1500 CFM stainless steel powered forced exhauster
- motorized dampers on intake and exhaust for accelerated cooling
- digital programming temperature controller
- manual reset excess temperature controller with separate contactors
- recirculating blower airflow safety switch
- 10" diameter circular chart recorder
- insulated floor with truck wheel guide tracks



THE GRIEVE CORPORATION

500 Hart Road, Round Lake, Illinois 60073-2898 USA
(847) 546-8225 Fax: (847) 546-9210

No.948