

**MODIFIED MODEL WTC446-500 WALK-IN OVEN,  
Serial No. 411999**

for rotating baskets of rubber parts during curing

- maximum operating temperature: 500F
- work space dimensions: 36" wide x 60" deep x 60" high
- 40 KW installed in Incoloy sheathed tubular heating elements
- 4200 CFM, 3-HP recirculating blower providing combination airflow
- 4" insulated walls
- top mounted heat chamber
- aluminized steel interior and exterior
- single front door
- access door in heat chamber to allow heaters to be cleaned
- motorized roller rack with two levels of 4" diameter driven rollers supported by metallized carbon bearings each level of driven rollers to hold two (2) 20" diameter stainless steel perforated drums rotating at 6 RPM
- rollers driven through sprockets and roller chain exterior to oven at rear; 3/4-HP AC motor with inverter variable speed control, gear reducer and torque limiter
- 10" diameter circular chart recording and programming temperature controller
- manual reset excess temperature controller with separate contactors
- recirculating blower air flow safety switch



**THE GRIEVE CORPORATION**

500 Hart Road, Round Lake, Illinois 60073-2898 USA  
(847) 546-8225 Fax: (847) 546-9210

**No.973**