

MODIFIED MODEL HA-850 CABINET OVEN, Serial No. 79407A0204

for baking paint samples

- maximum operating temperature: 850F
- work space dimensions: 20" wide x 20" deep x 20" high
- 10 KW installed in Incoloy sheathed tubular heating elements
- 19" diameter hearth constructed from 304 stainless steel with 1" studs on 1" centers to support painted coupons
- hearth driven by 1/4-HP motor through gear reducer with torque limiting device variable from 1 to 27 RPM
- 600 CFM, 1/2-HP recirculating blower providing horizontal airflow
- 4" insulated walls
- aluminized steel exterior
- type 304, 2B finish stainless steel interior
- silhouette plate with removable cover inside door opening
- safety equipment for handling flammable solvents including explosion venting door hardware



THE GRIEVE CORPORATION

500 Hart Road, Round Lake, Illinois 60073-2898 USA
(847) 546-8225 Fax: (847) 546-9210

No.987