



HY-1250 HIGH TEMPERATURE HORIZONTAL AIR FLOW CABINET OVEN, Serial No. 119716A0517 for heat treating

- maximum operating temperature: 1250°F
- workspace dimensions: 38" wide X 38" deep X 38" high
- 350,000 BTU/HR installed in a modulating natural gas burner
- 2000 CFM, 2 HP recirculating blower providing horizontal airflow
- 12" thick insulated walls comprised of 2" of 2300°F ceramic blanket and 10" of 10 lb/cf density rockwool
- aluminized steel exterior
- 16 ga stainless steel interior
- inner and outer door gaskets; inner gasket seals directly against door plug; outer gasket seals directly against front face of oven
- safety equipment required by IRI, FM and National Fire Protection Association Standard 86 for gas-heated equipment
- 325 CFM powered forced exhauster
- digital indicating temperature controller



THE GRIEVE CORPORATION

500 Hart Road, Round Lake, Illinois 60073-2898 USA
(847) 546-8225 Fax: (847) 546-9210

No.1045