

MODEL CLD-500 CLASS 100 CLEAN ROOM CABINET OVEN, Serial No. 730011
for drying coating on printed circuit boards

- maximum operating temperature: 260°F (127°C)
- workspace dimensions: 36" wide x 36" deep x 39" high
- 20 KW installed in Incoloy sheathed tubular heating elements
- 1000 CFM, 1½ HP recirculating blower providing horizontal airflow
- 4" insulated walls
- Type 304, 2B finish stainless steel interior with continuously backwelded seams
- exterior finished with white epoxy paint
- #4 brushed stainless steel door cover and control panel face
- safety equipment for handling flammable solvent including explosion venting door hardware
- 30" x 24" x 6" thick stainless steel high temperature HEPA recirculating filter
- digital indicating, programming temperature controller
- SCR power controller



THE GRIEVE CORPORATION

500 Hart Road, Round Lake, Illinois 60073-2898 USA
(847) 546-8225 Fax: (847) 546-9210

No. 797