

SPECIAL TOP LOADING OVEN, Serial No. 590045

for testing oil field down hole equipment

- maximum operating temperature: 500°F
- workspace dimensions: 185" wide x 18" deep x 24" high
- 34.8 KW installed in Nichrome wire heating elements
- 4000 CFM, total from two (2) 2 HP recirculating blowers providing horizontal front to rear airflow

- 4" insulated walls
- aluminized steel interior and exterior
- reinforced 1/4" steel plate workspace floor to hold 3600 lbs. distributed load
- motor operated rear hinged door
- oven supported on six (6) swivel casters with swivel locks and brakes
- digital indicating temperature controller
- manual reset excess temperature controller with separate contactors
- recirculating blower air flow safety switch



THE GRIEVE CORPORATION

500 Hart Road, Round Lake, Illinois 60073-2898 USA
(847) 546-8225 Fax: (847) 546-9210

No.868