

**MODIFIED MODEL TB-500, Serial No. 641368**

for curing parts hanging from rods

- maximum operating temperature: 500°F
- workspace dimensions: 48" wide x 36" deep x 96" high
- 24 KW installed in Nichrome wire heating elements
- 1000 CFM, 1-HP recirculating blower providing vertical upward airflow
- 4" insulated walls
- oven sectioned to fit in 5' wide x 8' deep x 6'8" elevator
- aluminized steel exterior
- Type 304, 2B finish stainless steel interior
- digital indicating temperature controller
- manual reset excess temperature controller with separate contactors
- recirculating blower airflow safety switch
- 10" diameter circular chart recorder



**THE GRIEVE CORPORATION**

500 Hart Road, Round Lake, Illinois 60073-2898 USA  
(847) 546-8225 Fax: (847) 546-9210

**No.899**