

**VERTICAL CONVEYOR HUMIDITY CHAMBER, Serial No. 650175**  
for curing silicone rubber

- maximum relative humidity:  
90% at 100°F
- workspace dimensions: 36" wide x  
45" deep x 119" high
- self-contained humidifier with  
30 lb./hour capacity
- fourteen (14) stainless steel trays  
supported at each side by heavy-duty  
stainless steel roller chain; driven by a  
1/2-HP motor, trays indexed into  
load/unload position
- 600 CFM, 1/2-HP recirculating blower  
providing vertical upward airflow
- 4" insulated walls
- top mounted heat chamber
- aluminized steel exterior
- Type 304, 2B finish stainless steel  
interior with continuously backwelded  
seams
- all interior drive components  
304 stainless steel
- two (2) independent doors for access  
to workspace and heat chamber
- loading table and light curtain at  
load/unload position
- viewing window at load/unload position
- JIC/NEMA 12 electrical standards
- digital indicating humidity controller  
calibrating relative humidity



**THE GRIEVE CORPORATION**

500 Hart Road, Round Lake, Illinois 60073-2898 USA  
(847) 546-8225 Fax: (847) 546-9210

**No.904**