

**SPECIAL WALK-IN OVEN, Serial No. 660466**

for curing rubber parts

- maximum operating temperature: 500°F
- work space dimensions: 30" wide x 48" deep x 57" high
- 175,000 BTU/HR installed in a modulating natural gas burner
- 2,000 CFM, 2-HP recirculating blower providing horizontal airflow
- 4" insulated walls
- top mounted heat chamber
- Type 430 stainless steel interior with continuously backwelded seams
- stainless steel exterior with #4 brushed finish
- motorized dampers on intake and exhaust for accelerated cooling

- 10" diameter circular chart recorder
- safety equipment required by IRI, FM and National Fire Protection Association Standard 86 for gas-heated equipment including 325 CFM 1/3-HP powered forced exhauster
- 4" insulated floor with truck wheel guide tracks on top of floor
- shelf truck with supports on 3-1/2" centers
- fused disconnect switch
- ten (10) permanently mounted survey thermocouples connected to jack strip at control panel
- oven exhauster discharges into scrubber unit using recirculated water (1-1/2-HP pump) sprayed into exhaust to remove particulates
- 304 stainless steel scrubber construction with brass piping



**THE GRIEVE CORPORATION**

500 Hart Road, Round Lake, Illinois 60073-2898 USA  
(847) 546-8225 Fax: (847) 546-9210

**No. 909**