

**MODIFIED MODEL HA-500 CABINET OVEN, Serial No. 470234**

for use in curing rubber parts

- maximum operating temperature: 500°F
- work space dimensions: 20" wide x 20" deep x 26" high
- 10 KW installed in Incoloy sheathed tubular heating elements
- 600 CFM, 1/2-HP recirculating blower providing horizontal airflow
- 4" insulated walls
- Type 430, stainless steel interior with continuously backwelded seams
- stainless steel exterior with #4 brushed finish
- 325 CFM powered forced exhauster
- motorized damper on exhaust for accelerated cooling
- digital indicating temperature controller
- 10" diameter circular chart recorder
- fused disconnect switch
- eight (8) permanently mounted survey thermocouples connected to jack strip on control panel
- oven exhaust discharges into scrubber unit using recirculated water (1-1/2-HP pump) sprayed into exhaust to remove particulates
- 304 stainless steel scrubber construction with brass piping



**THE GRIEVE CORPORATION**

500 Hart Road, Round Lake, Illinois 60073-2898 USA  
(847) 546-8225 Fax: (847) 546-9210

**No. 912**