

BELT CONVEYOR OVEN, Serial No. 650187

for curing rubber

- maximum operating temperature: 500F
- workspace dimensions: 36" wide x 68" deep x 15" high
- 6" long open belt loading zone
- 12" long insulated, unheated entrance vestibule
- 60" long insulated heat zone with recirculated airflow
- 12" long insulated, unheated exit vestibule
- 175,000 BTU/HR installed in a modulating natural gas burner
- 30" wide, 1" x 1" flat wire conveyor belt with 1/4-HP motor drive, variable from 1 to 20 inches per minute
- 3300 CFM, 2-HP recirculating blower providing vertical downward airflow
- 4" insulated walls
- aluminized steel interior
- stainless steel exterior with #4 brushed finish
- digital indicating temperature controller
- fused disconnect switch



THE GRIEVE CORPORATION

500 Hart Road, Round Lake, Illinois 60073-2898 USA
(847) 546-8225 Fax: (847) 546-9210

No.937