

**TOP LOADING OVEN, Serial No. 590059**

for testing electronic components

- maximum operating temperature: 500F
- work space dimensions: 312" wide x 24" deep x 24" high
- 70 KW installed in Nichrome wire heating elements
- 8000 CFM total from four (4) 2-HP recirculating blowers providing horizontal rear to front air flow
- 4" insulated walls

- aluminized steel interior and exterior
- motor operated rear hinged door opening the front and top of oven
- floor or workspace reinforced for 7200 lbs. loading at 1/4" plate surface
- digital programming temperature controller with two (2) channels providing two (2) zones of control
- two (2) manual reset excess temperature controllers with separate contactors
- four (4) recirculating blower air flow safety switches



**THE GRIEVE CORPORATION**

500 Hart Road, Round Lake, Illinois 60073-2898 USA  
(847) 546-8225 Fax: (847) 546-9210

**No.955**